

COSMO® CUBE

Hardware Computer – Quick Reference Manual – v1 Pilot Build

DOCUMENT	LOT-COSMO-CUBE-MANUAL
CLASS	PILOT UNIT / NOT FOR COMMERCIAL RESALE
S-2	VADIK MARMELODOV
VERSION	1.0 – 2026-08-02

01 // WHAT IT IS

COSMO® Cube is a flat hardware computer – a two-piece stainless steel slab, 40×40mm × 5mm, that pairs to lot-systems.com and shows exactly one autonomous notification at a time. When LOT decides something is worth telling you – “Coffee time!”, a weather change, a memory question ready – the Cube's screen shows it. Nothing else competes for the screen. There is no feed, no unread count, no app to open.

02 // IN THE BOX

COSMO® Cube	1 unit, Side A (mirror) facing up out of the box
Wireless charging pad	Not included – any Qi-compliant charging pad works
This manual	Quick-reference only – full technical specs live at docs/corporate and docs/technical in the LOT Systems repository

03 // SETUP

1. Charge	Place the Cube on any Qi wireless charging pad. No cable, no port.
2. Pair	On lot-systems.com, open Pair a device . A 6-digit code appears.
3. Connect	The Cube broadcasts a setup Wi-Fi network on first boot. Join it from your phone, enter your home Wi-Fi credentials and the 6-digit code.
4. Done	The screen shows the LOT wordmark once paired. It is now listening for notifications.

COSMO® CUBE

Hardware Computer – Quick Reference Manual – v1 Pilot Build

DOCUMENT	LOT-COSMO-CUBE-MANUAL
CLASS	PILOT UNIT / NOT FOR COMMERCIAL RESALE
S-2	VADIK MARMELADOV
VERSION	1.0 – 2026-08-02

04 // USING THE CUBE

Side A – mirror	Polished stainless. No controls. This is the face you leave showing on a desk.
Side B – brushed	Camera, screen, and one button, labeled COPY .
The screen	Shows the single latest notification from lot-systems.com. Clears to idle when the notification expires – a blank screen is normal, not an error.
COPY – short press	Logs “seen” back to your Log tab on lot-systems.com. One press, one log line. No confirmation screen – a single blink on the device is the only feedback; check the Log tab from any device to see it recorded.
COPY – long press	Hold for >1.5 seconds to trigger a photo snapshot from the on-board camera, sent to lot-systems.com on request only. The Cube never captures on a timer.

05 // WEATHER SENSOR

A sensor inside Side B reads ambient temperature, humidity, and air pressure directly at the Cube's location – a hyperlocal reading, distinct from the city-level weather already shown elsewhere on lot-systems.com. No setup required; readings upload automatically in the background.

06 // CHARGING & CARE

Charging	Wireless (Qi) only. There is no port, cable, or opening on the shell – this is by design, not a missing feature.
Cleaning	Wipe both stainless faces with a soft, dry or slightly damp cloth. Avoid abrasives on Side A – the mirror finish scratches like any polished steel.
Water	The seam is sealed against dust and incidental moisture. The Cube is not rated for submersion or dishwashing.

07 // PILOT UNIT NOTICE

This unit is part of a closed, 100-unit pilot production run. It has not completed FCC/CE certification and is not offered for commercial resale. Firmware updates are delivered automatically over Wi-Fi; do not disconnect power during an update (the screen indicates update-in-progress and will not show a live notification during that window).

AUTHORIZED BY S-2 // VADIK MARMELODOV — LOT SYSTEMS CORPORATION