

LOT® Pager – User Manual v1.0

LOT Systems Corporation · COSMO® Hardware Division
Product code: LOT-PAGER-01

What's in the box

- 1x LOT® Pager (58mm stainless steel puck)
- 1x Charging Plate (40mm x 40mm silver-anodized aluminum)
- 1x USB-C cable (charges the plate, not the Pager directly)
- 1x Quick-start card

Before you begin

The LOT® Pager has two faces:

- **The polished face** – mirror-finish stainless steel. No buttons, no screen. This is the face you leave turned toward the room.
- **The device face** – matte stainless steel, with a small round screen, a camera window, and one button marked **COPY**.

There is nothing to charge inside the Pager itself except by setting it on its Charging Plate – it has no charging port of its own.

Setup

1. Plug the Charging Plate into any USB-C power source.
2. Set the Pager on the plate, device face up or down – either works, the plate charges through either face.
3. Open lot-systems.com on your phone or computer, go to **Settings** → **Hardware** → **Pair a Pager**.
4. Follow the on-screen pairing steps. Your Pager's screen will show a pairing symbol until setup is complete.
5. Once paired, place the Pager wherever you'll see it – a desk, a nightstand, a kitchen counter.

Using your Pager

Notifications. Your Pager receives short messages from your LOT® Memory Engine – things like "Coffee time!" or "Air's good. Crack a window." Messages appear on the screen for a short time, then the screen

goes dark again. There is nothing to dismiss, nothing to scroll, and nothing accumulates while you're away.

The COPY button. Press it any time you want a moment logged straight to your Log tab on lot-systems.com – no phone, no typing. Your Pager connects on its own and sends the entry. A checkmark on the screen means it went through; a dash means it's queued and will send once your Pager reconnects.

The camera. The camera only activates when you press COPY, or briefly and privately on-device to decide whether to wake the screen for you. It never records continuously, and nothing it sees is stored on the device past that moment.

Care

- The polished face shows fingerprints – a soft cloth restores the finish. Avoid abrasive cleaners.
- The device face is sealed against splashes (not submersion) – wipe with a damp cloth if needed.
- Both faces are 316L stainless steel – dishwasher-safe materials, but the Pager itself is not a dishwasher-safe object (it has a battery and a screen inside).

Battery

Your Pager charges wirelessly through its Charging Plate. A full charge lasts about 5 days under typical use (20-40 notifications a day). There is no way to check battery level on the device screen by design – pair it with your account and check status from Settings → Hardware instead.

Support

Questions or issues: reach your LOT® Systems account team through the in-app support channel at lot-systems.com.

*LOT® Pager – LOT Systems Corporation · Made in the USA
brand.lot-systems.com*

LOT® PAGER – USER MANUAL v1.0 · PRODUCT CODE LOT-PAGER-01
© 2025–2026 LOT SYSTEMS. ALL RIGHTS RESERVED.