

Smart Device User Manual & Operating Instructions

Model: AI-RAG-2026 | Comprehensive Quick Reference and Support Guide

Chapter 1: Quick Start & Initial Setup

This chapter covers everything you need to unbox, connect, and set up your device for the first time.

Step 1: Unboxing & Package Verification

Ensure the package contains: the main unit, 45W USB-C power adapter, Ethernet cable, and quick warranty card.

Step 2: Connecting Power

Plug the USB-C adapter into the power port on the rear panel. Connect to an AC wall outlet (100V - 240V). The status indicator LED will glow solid blue once ready.

Step 3: Network & Wi-Fi Configuration

Open your smartphone or PC Wi-Fi settings, select the network named **Device-Setup-xxxx**, and open **http://setup.local** in any browser. Select your home Wi-Fi network (2.4 GHz or 5 GHz) and enter your password. Once connected, the LED indicator transitions to solid green.

Chapter 2: Daily Operations & Account Management

Step 1: Account Login & Dashboard

Access the management console at **http://localhost:8080**. Sign in using your registered admin username and password.

Step 2: Password Reset Procedure

To reset your password, navigate to **Settings > Account Security > Reset Password**. Enter your current password, type your new 8-character password containing at least one uppercase letter and one number, and click Save. Alternatively, click **Forgot Password** on the login screen to receive a secure 6-digit one-time code via email.

Step 3: Routine Maintenance & Cleaning

Keep ventilation vents dust-free using a dry microfiber cloth. Avoid liquid sprays or abrasive cleaners. Always disconnect power prior to cleaning.

Chapter 3: Safety Guidelines & Precautions

Adhere to the following safety precautions to prevent hardware damage, fire risk, or injury:

- **Temperature:** Operate the device between 10°C and 35°C (50°F to 95°F). Keep away from direct sunlight and heat sources.
- **Moisture & Water:** The unit is not waterproof. Do not expose to rain, liquids, high humidity, or steam.

- **Power Specifications:** Use only the supplied 45W certified power adapter. Using incompatible adapters may void warranty.
- **Emergency Shutdown:** In case of smoke, unusual noise, or excessive heat, immediately unplug the power cable from the wall outlet.

Chapter 4: Troubleshooting & Frequently Asked Questions (FAQ)

Issue 1: Device Does Not Power On

Verify the power cable is firmly seated into the device and wall socket. Check whether the socket switch is turned on. Hold the power button down for 10 seconds to force a power cycle.

Issue 2: Wi-Fi Connection Fails or Drops

Confirm your Wi-Fi password is correct. Move the unit within 15 feet of the router. If connection drops persist, restart both your home router and the unit.

Issue 3: How to Perform a Factory Reset

Locate the small reset pinhole on the rear panel. Insert a paperclip and hold the button for 5 seconds until the LED blinks amber. The unit will reboot and restore default factory settings.