Added monitor commands

The monitor is Assist09 with four commands added. All of them use letters that stock Assist09 does not use (it already uses B, C, D, E, G, L, M, N, O, P, R, S, T, V and W). The ROM image is `rom-images/Monolithic-Flex-Assist09-BIOS-Format-Loader_v7`.

Command	Name	Runs at	Source
`F`	Boot FLEX	`$CD00`	`monitor/Assist09-Flex.asm`, `rtc/Assist09_Flex_RTC.asm`, `rtc/Flex_DatePatch.asm`
`X`	Format	`$E900`	`cf-tools/FlexFormat.asm`
`U`	Upload	`$EE00`	`flex-bios/Flex_BIOS_DiskLoader.asm`
`K`	Clock	`$C000`	`rtc/RTC_Set.asm`

F — boot FLEX

Starts FLEX, with the date taken from the real-time clock.

1. Reads the RTC and prints it as `DD/MM/YY HH:MM:SS`. If the clock is unset or holds an impossible date, it prints a message instead.
2. Writes the date into FLEX's date bytes (`$CC0E`–`$CC10`).
3. Arms the RTC's 1-minute interrupt, so the date stays current without anyone typing `DATE`.
4. Waits for the console to finish printing, then starts FLEX.

FLEX skips its "date?" prompt when the date has been set. If the clock can't be read, FLEX starts with whatever date it already had and the interrupt stays off. Use `K` to set the clock.

X — format

Starts the disk formatter, which formats the CF card for FLEX. It writes a new, empty FLEX disk: the System Information Record, an empty directory, and a free-space chain over the rest of the card. **This erases the disk.**

U — upload

Starts the disk loader. Once it is running, send a disk image from the host over the serial link and it is written to the CF card, sector by sector. In A09Studio use the **Disk Image…** tool (or **Send to CF…** from the Disk Builder or DSK Browser). This overwrites the target drive.

K — clock

Starts the clock program, for setting the time and date from scratch or for checking a new board. **Starting it stops and resets the clock.** At its prompt:

Key	Action
`S`	Set the time
`E`	Set the date (`DD MM YY`)
`I`	Toggle the 1-minute interrupt
`Q`	Quit back to the monitor

After setting the clock, use `F` to boot FLEX with the new date.

Reset and entry points

Entry	Address	What it does
Reset	`BOOT` (reset vector)	Copies the ROM to RAM, switches the ROM off, masks the RTC interrupt and sets up the console. If BASIC is in the ROM (the byte at `$9C00` is `$7E`, a `JMP`), it starts BASIC; otherwise it starts Assist09.
Monitor	`$E03C`	Enters Assist09. FLEX's `MON` command and the clock program's `Q` jump here.
From BASIC	`[$FFF0]` (`MONENT`)	Rebuilds the monitor's work page, then enters Assist09 if `A`=0 or boots FLEX (as `F` does) if `A`=`'F'`. Used by BASIC's `MONITOR` and `FLEX` commands.

`$FFF0` is the 6809's reserved vector, which the CPU never uses, so it is free to hold this address. Reaching the monitor from BASIC this way means BASIC needs no addresses inside the monitor. BASIC itself is not part of this repository; see basic-port.md.

Notes

- The formatter, loader and clock program sit in ROM above or away from user RAM, so `$0000`–`$BFFF` stays free (`$0000`–`$9BFF` if BASIC is in the ROM). The clock program at `$C000` is restored from the ROM image on every reset.
- The monitor masks the RTC interrupt at reset, so a cold power-up can't fire it before `F` has installed the handler.