

Added monitor commands

The monitor is Assist09 with four commands added. All of them use letters that stock Assist09 does not use (it already uses B, C, D, E, G, L, M, N, O, P, R, S, T, V and W). The ROM image is `rom-images/Monolithic-Flex-Assist09-BIOS-Format-Loader_v6`.

Command	Name	Runs at	Source
F	Boot FLEX	\$CD00	monitor/Assist09-Flex.asm , rtc/Assist09_Flex_RTC.asm , rtc/Flex_DatePatch.asm
X	Format	\$E900	cf-tools/FlexFormat.asm
U	Upload	\$EE00	flex-bios/Flex_BIOS_DiskLoader.asm
K	Clock	\$C000	rtc/RTC_Set.asm

F — boot FLEX

Starts FLEX, with the date taken from the real-time clock.

1. Reads the RTC and prints it as `DD/MM/YY HH:MM:SS`. If the clock is unset or holds an impossible date, it prints a message instead.
2. Writes the date into FLEX's date bytes (`$CC0E` – `$CC10`).
3. Arms the RTC's 1-minute interrupt, so the date stays current without anyone typing `DATE`.
4. Waits for the console to finish printing, then starts FLEX.

FLEX skips its "date?" prompt when the date has been set. If the clock can't be read, FLEX starts with whatever date it already had and the interrupt stays off. Use `K` to set the clock.

x — format

Starts the disk formatter, which formats the CF card for FLEX. It writes a new, empty FLEX disk: the System Information Record, an empty directory, and a free-space chain over the rest of the card. **This erases the disk.**

u — upload

Starts the disk loader. Once it is running, send a disk image from the host over the serial link and it is written to the CF card, sector by sector. In A09Studio use the **Disk Image...** tool (or **Send to CF...** from the Disk Builder or DSK Browser). This overwrites the target drive.

K — clock

Starts the clock program, for setting the time and date from scratch or for checking a new board.

Starting it stops and resets the clock. At its prompt:

Key	Action
S	Set the time
E	Set the date (DD MM YY)
I	Toggle the 1-minute interrupt
Q	Quit back to the monitor

After setting the clock, use **F** to boot FLEX with the new date.

Notes

- The formatter, loader and clock program sit in ROM above or away from user RAM, so `$0000 – $BFFF` stays free. The clock program at `$C000` is restored from the ROM image on every reset.
- The monitor masks the RTC interrupt at reset, so a cold power-up can't fire it before **F** has installed the handler.