

HVAC-C500 Maintenance Manual

Product: Commercial HVAC System | Model: HVAC-C500 | Document Type: MAINTENANCE_MANUAL

1. Air Filter Replacement Procedure

How to replace the HVAC air filter on HVAC-C500:

- 1. Turn OFF main electrical disconnect switch on HVAC service panel.
- 2. Unlatch side filter access door.
- 3. Slide out dirty MERV 13 filter panels (Size 24x24x2 inches).
- 4. Insert new MERV 13 filter panels with airflow arrows pointing toward blower fan.
- 5. Latch access door and restore power.