

ESTABLISH DRAWING 03/29/01 BL BI. MX200 MANUAL TRANSFER

FIRST MARE TON STORE BY NOT THE STORE DATE The Transfer switch will transfer either direction by depression of YN (Normal) or YE (Emergency) Pushbutton. REVISIONS DESCRIPTION YE (J4 PIN 10) YN (J4 PIN 9) S12 (J4 PIN 13) The switch maintains position selected, even if the selected power fails. (J2 PIN 3) ...P9XPNNG ...V-1143 ...P9B10VN ..P9XPNNG ..V-1144 ..P9B10VN PUSHBUTTON TO
EMERGENCY (YE)
GND
(J2 PIN 3)
(J4 PIN 10) GND O O (J4 PIN 9) 1. Mount, wire and label the pushbuttans on cabinet front. CONNECTION DIAGRAM INSTRUCTIONS PUSHBUTTON TO NORMAL (YN) OPERATION CABINET FRONT LEGEND SCHEMATIC PROGRAMMING NOTES IN FIELD PROGRAMMING MENU: ENABLE (\$12) AUTO/MANUAL OPTION. RE < ξ WIRE CONNECTION
 POINT LEGEND

