

Assembler Debug Help

00

00

00

52

00

1D

FF

00

Flag

S 0

Z 1

AC 0

P 1

C 0

Load me at

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

LXI H, 2050H

MOV C, M

DCR C

LOOP1: LXI H, 2051H

MOV B, C

LOOP2: MOV A, M

INX H

CMP M

JNC NOSWAP

MOV D, M

MOV M, A

DCX H

MOV M, D

INX H

NOSWAP: DCR B

JNZ LOOP2

DCR C

JNZ LOOP1

HLT

Hex Conversion

Hex

0

To Dec

00

Port Value

00

Memory

Data

Stack

Keypad

Memory

Start

2500

Address (Hex)	Address	Data
09C4	2500	2
09C5	2501	7
09C6	2502	8
09C7	2503	9
09C8	2504	12
09C9	2505	35
09CA	2506	0
09CB	2507	0
09CC	2508	0
09CD	2509	0
09CE	2510	0
09CF	2511	0
09D0	2512	0
09D1	2513	0
09D2	2514	0
09D3	2515	0

Line No	Assembler Message
0	Program assembled successfully