# Traxster Robot Assignment API

Version 1.0 (2016)

Petri Kannisto

Tampere University of Technology

# 1 ROBOT CLASS

# 1.1 GETSENSORVALUE

Gets a raw sensor value.

In	int id	Pin ID.
Return	double	Sensor value.

#### 1.2 SETMOTORSPEED

Sets motor speeds.

In	int leftMotorSpeed	Left motor speed.
In	int rightMotorSpeed	Right motor speed.
Return	-	

# 1.3 READPIN

Reads the state of a pin.

In	int id	Pin ID.
Return	bool	Pin state.

# 1.4 WRITEPIN

Writes the state of a pin.

In	int id	Pin ID.
In	bool state	Pin state.
Return	-	