

GMMK Pro — maxma keymap

Base layer is stock ANSI except the right column and the Y/Z swap. Hold **Fn** for everything below — the keys that do something light up green.

Right column & base changes

Below the knob	Del · Ins · Home · End
Right of T	types z
Right of X	types y
Page Up / Down	moved to the Fn layer

Y/Z swapped to match German keycaps on a US Windows layout. Everything else stays US.

The knob

Turn	Volume
Press	Mute
Fn + turn	Colour (hue) — previews live
Fn + press	Backlight on / off
Ctrl + turn	Jump word by word
Shift + turn	Select word by word
Alt + turn	Previous / next track

Fn — media & system

F1 ... F4	Prev · Play/Pause · Next · Stop
F5 F6 F7	Mute · Vol– · Vol+
F8	Mic mute → sends Ctrl+Alt+Shift+M
F9 F10	Scroll Lock · Pause/Break
Backspace	Delete
N	Num Lock
K	NKRO on / off (this session)
S	SOCD cleaner arm / disarm
PrtSc	Bootloader (for flashing)

F8 does nothing until you bind Ctrl+Alt+Shift+M as the mute hotkey in Discord / OBS / Teams. No keyboard can mute a mic on its own.

Fn — navigation & lighting

Arrows ↑ ↓	Page Up / Page Down
Arrows ← →	Home / End
Ins Home	Page Up / Page Down
– =	Brightness down / up
Esc tap	Reset lighting to defaults
Esc hold 2s	Wipes everything — see below

What the lights mean

● Green = key	All normal
● Red = key	SOCD armed, or NKRO off
● Green Caps	Caps Lock on
● Blue N	Num Lock on
● Red F9	Scroll Lock on
● Magenta WASD	SOCD armed
● Amber K	NKRO off (while Fn held)
● Blinking red	About to wipe — let go now

Both side bars stay the baseline colour. Every indicator sits on the key it refers to. The **=** key has a dead blue LED channel, so it is driven red/green only — that is why it is the status light.

SOCD cleaner — read this

Banned in Counter-Strike 2 and Valorant. Both moved against this class of feature in 2024. Using it there risks your account. It is your call and your responsibility.

What it does	A+D and W+S: last key pressed wins, instantly
At every boot	Off. Always. Never on by accident
Arm / disarm	Fn + S
While armed	WASD magenta, = key red

Fn+Esc — the two resets

Tap	Lighting back to defaults. Safe
Hold ~1.5s	Board blinks red — warning
Let go on red	Nothing happens. Escape hatch
Hold 2s+	Wipes EEPROM: VIA remaps, lighting, all

The red flash starts half a second before the wipe point on purpose — see it, let go, nothing is lost.

Flashing — the trap

VIA means the board types from EEPROM, not from the firmware. Flash a changed keymap normally and **nothing happens** — it keeps using the stored one. Always mass-erase:

Bootloader	Fn + PrtSc
Then	<code>dfu-util -a 0 -d 0483:df11 -s 0x08000000:mass-erase:force -D firmware.bin</code>
Prebuilt .bin	GitHub → Actions → newest run → Firmware