

EC2x&EG2x&EG9x&EM05 Series

QCFG AT Commands Manual

LTE Standard Products

Version: 1.6

Date: 2026-04-27

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

No. 8 Waipojing Road, Sijing Town, Songjiang District, Shanghai 201601, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<https://www.quectel.com/contact/>.

For technical support, or to report documentation errors, please visit:

<https://www.quectel.com/tech-support/>.

Or email us at: support@quectel.com.

Legal Notices

We provide this document to support your product design. You are required to design your products based on the specifications and parameters set forth herein. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. You acknowledge and agree that we may add to, amend, or restate this document at any time at our sole discretion without any prior notice to you, and such additions, amendments, or restatements shall be binding upon you.

Use and Disclosure Restrictions

License Agreements

The recipient of any hardware, software, materials, or documentation provided by us shall keep such content confidential, unless expressly authorized by us. The recipient shall not disclose, access, or use any part of the received content for any purpose other than the execution and implementation of the intended project.

Copyright

Our and third-party products hereunder may contain copyrighted materials, including but not limited to protected content, hardware, software, and documentation owned by us or applicable third parties. Unless prior written consent is obtained, you shall not access, use, or disclose any documents or information provided by us, nor shall you copy, reproduce, republish, display, translate, distribute, merge, modify, or create derivative works from any such copyrighted materials. We and the applicable third party retain exclusive rights to all copyrighted materials. No license to any patents, copyrights, trademarks, or service marks shall be granted or transferred. For the avoidance of doubt, no form of purchase shall be construed as granting any license beyond a normal, non-exclusive, royalty-free license to use the product. We reserve the right to pursue legal action against any violation of confidentiality obligations,

unauthorized use, or any other unlawful or malicious use of the aforementioned documents and information.

Trademarks

Unless otherwise expressly provided, nothing in this document shall be construed as conferring any rights to use any trademark, trade name, name, abbreviation, or counterfeit thereof owned by us or any third party in advertising, publicity, or any other contexts.

Third-Party Rights

You understand that this document may refer to hardware, software, and/or documentation owned by one or more third parties (“third-party materials”). Use of such third-party materials is subject to all applicable restrictions and obligations set forth herein.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing, course of performance, or usage of trade.

Privacy Policy

To enable product functionality, certain device data may be uploaded to our or third-party servers, including those operated by carriers, chipset suppliers, or servers designated by you. We strictly comply with applicable laws and regulations and will retain, use, disclose, or otherwise process relevant data solely for the purpose of enabling product functionality, or as permitted by applicable laws. Before interacting with any third party regarding data exchange, please be informed of and understand their privacy and data security policies.

Disclaimer

- a) We shall not be liable for any damages resulting from failure to comply with applicable operational or design specifications.
- b) We shall bear no liability for any inaccuracies or omissions in this document, nor for any damages arising from the use of the information contained herein.
- c) While we make every effort to ensure the integrity, accuracy, and timeliness of the features and functions under development, errors or omissions may nevertheless occur. Unless otherwise provided in a valid written agreement, we make no warranties of any kind, express, implied, or statutory, and disclaim all liability for any loss or damage arising from the use of any features or functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage is foreseeable.
- d) We assume no legal responsibility for the accessibility, safety, accuracy, availability, legality, or completeness of any information, content, advertising, commercial offers, products, services, or materials on third-party websites or third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2026. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2021-04-15	Wythe Wang/ Alessa Tang/ Colin Cui	Creation of the document
1.0	2022-05-30	Wythe Wang/ Alessa Tang/ Colin Cui	First official release
1.1	2023-06-27	Clauz Lu/ Colin Cui	- Added the applicable modules: EG21-GL and EG25-GL. - Updated the response to AT+QCFG=? (Chapter 2.1). - Added the example for AT+QCFG="band" (Chapter 5.4).
1.2	2024-12-02	Logan Hong	- Updated the declaration of AT command examples (Chapter 1.5). - Updated IP addresses in the examples (Chapters 5.36 and 5.40).
1.3	2025-02-25	Jason Liao	Added AT+QCFG="nwscanseq" (Chapters 2.1, 5.43).
1.4	2025-12-11	Allan Liu	- Updated the note for AT+QCFG="ppp/sleep_ri" (Chapter 3.13). - Deleted AT+QCFG="sarcfg" (details can be found in <i>Quectel_EC2x&EG2x&EG9x_Series_Power_Back-off_Application_Note</i>). - Deleted the following AT commands since details can be found in <i>Quectel_EC2x&EG2x&EG9x&EM05_Series_Software_Thermal_Management_Guide</i>. - AT+QCFG="thermal/txpwrlimt" - AT+QCFG="thermal/modem" - AT+QCFG="thermal/limit_rates"

1.5	2026-03-03	Lorcan Man	Updated AT+QCFG="disrplmn" (Chapter 5.32).
			1. Updated the parameter about AT+QCFG="urc_cause_support" (Chapter 5.19).
1.6	2026-04-27	Jason Liao	2. Added AT+QCFG="eps_only_creg_real" (Chapter 5.44).
			3. Added the Release Cause Text List of AT+QCFG="urc_cause_support" (Chapter 14.1).

Contents

About the Document.....	3
Contents	5
Table Index.....	9
1 Introduction	10
1.1. Applicable Modules	10
1.2. Definitions	11
1.3. AT Command Syntax.....	11
1.4. AT Command Responses.....	12
1.5. Declaration of AT Command Examples	12
2 Test Command	13
2.1. AT+QCFG Extended Configuration Settings	13
3 General Commands	18
3.1. AT+QCFG="apready" Set AP_Ready Behavior	18
3.2. AT+QCFG="sleepind/level" Configure the Output Level of the SLEEP_IND Pin.....	19
3.3. AT+QCFG="wakeupin/level" Configure Whether to Wake up the Module Through WAKEUP_IN Pin.....	20
3.4. AT+QCFG="urc/ri/ring" Set RI Behavior When RING URC is Presented	21
3.5. AT+QCFG="urc/ri/smsincoming" Set RI Behavior When Incoming SMS URCs are Presented	23
3.6. AT+QCFG="urc/ri/other" Set RI Behavior When Other URCs are Presented.....	24
3.7. AT+QCFG="risignalttype" RI Signal Output Carrier	25
3.8. AT+QCFG="urc/delay" Delay URC Indication Output	26
3.9. AT+QCFG="urc/cache" Enable/Disable URC Cache	27
3.10. AT+QCFG="urc/poweron" Set Output URC of Power-on.....	28
3.11. AT+QCFG="divctl" Configure Primary and Rx-diversity under LTE/WCDMA.....	30
3.12. AT+QCFG="bootup" Enable/Disable Services in Linux.....	31
3.13. AT+QCFG="ppp/sleep_ri" Enable/Disable Waking up the Module through the RI Pin Indication after PPP Establishment	32
3.14. AT+QCFG="urc/ri/pin" Configure UART Pins Corresponding to RI	33
3.15. AT+QCFG="icf" Configure Main UART.....	33
3.16. AT+QCFG="urcdelay" Configure URC Delay	34
3.17. AT+QCFG="fast/poweroff" Enable/Disable Fast Power-Off.....	35
3.18. AT+QCFG="sleep/datactrl" Configure Data Cache Mode	37
3.19. AT+QCFG="rf/tuner_cfg" Set the Mapping between RF Tuner and RF Bands	38
3.20. AT+QCFG="mms_rec_control" Save/Discard the MMS.....	39
4 Audio Commands	41
4.1. AT+QCFG="tone/incoming" Enable Ring Tone	41
4.2. AT+QCFG="pcmclk" Configure PCM_CLK	42
4.3. AT+QCFG="codec/powsave" Set PSM for ALC5616 Codec	43

5	Network Commands	45
5.1.	AT+QCFG="gprsattach" Configure GPRS Attach Mode	45
5.2.	AT+QCFG="nwscanmode" Configure Network Search Mode	46
5.3.	AT+QCFG="servicedomain" Configure Service Domain	47
5.4.	AT+QCFG="band" Configure Band	48
5.5.	AT+QCFG="rrc" Configure RRC Release Version	50
5.6.	AT+QCFG="msc" Configure MSC Release Version	51
5.7.	AT+QCFG="sgsn" Configure UE SGSN Release Version	51
5.8.	AT+QCFG="hsdpacat" Configure HSDPA Category	52
5.9.	AT+QCFG="hsupacat" Configure HSUPA Category	53
5.10.	AT+QCFG="pdp/duplicatechk" Establish Multi-PDN with Same APN	54
5.11.	AT+QCFG="disable_backoff_lte" Disable Backoff LTE	55
5.12.	AT+QCFG="airplanecontrol" Enter/Exit Airplane Mode via W_DISABLE# Pin	55
5.13.	AT+QCFG="epcflag" Set EPC Capability Value in Attach Request	58
5.14.	AT+QCFG="lte/bandprior" Set Searching Priority of LTE Band	59
5.15.	AT+QCFG="plmn/addinfbdn" Add Current PLMN to FPLMN	60
5.16.	AT+QCFG="cops_no_mode_change" Enable/Disable the Switch under AT+COPS=1	61
5.17.	AT+QCFG="hplmn/search_timer" Configure HPLMN Search Interval	61
5.18.	AT+QCFG="tdd/config" Get the LTE-TDD Configuration	62
5.19.	AT+QCFG="urc_cause_support" Report Rejection Cause	63
5.20.	AT+QCFG="dhcpcpkfltr" Filter DHCP Package	64
5.21.	AT+QCFG="oostimer" Set Mode for OOS Network Searching	65
5.22.	AT+QCFG="apn/blocked" Configure APN Block Mode	66
5.23.	AT+QCFG="redir/3gtolte" Configure Redirection Mode	67
5.24.	AT+QCFG="rssi" Configure Delta Threshold of RSSI Change	68
5.25.	AT+QCFG="roamservice" Configure Roaming Service	69
5.26.	AT+QCFG="fast_dormancy" Dynamically Control the RRC Connection	70
5.27.	AT+QCFG="airplane" Configure Airplane Mode	70
5.28.	AT+QCFG="rrc/control" Configure the Feature of RRC Connection Control	72
5.29.	AT+QCFG="nwscanmodeex" Configure Network Searching Mode	73
5.30.	AT+QCFG="assign_plmn_in_limit_search" Specify Operator for Camping on a Cell with Limited Service	74
5.31.	AT+QCFG="iprulectl" Configure the Gateway Address Generation Rule	75
5.32.	AT+QCFG="disrplmn" Configure RPLMN and RPLMNACT for Network Searching	76
5.33.	AT+QCFG="lte/preferfre" Set Preferred Frequency	78
5.34.	AT+QCFG="cops_control" Enable/Disable Configurations of AT+COPS	79
5.35.	AT+QCFG="map_rej_cause7_to_cause14" Enable/Disable Network Rejection Cause Mapping	80
5.36.	AT+QCFG="netmaskset" Enable/Disable Customized Netmask	81
5.37.	AT+QCFG="pingdiscard" Configure Whether to Discard Ping Packet	82
5.38.	AT+QCFG="urc/ri/restart" Configure RI Pulse Timer	83
5.39.	AT+QCFG="ping/ri" Configure Ping Detection Function	84
5.40.	AT+QCFG="defaultdns" Configure Default DNS for PDP Context	85
5.41.	AT+QCFG="lpm/dataind" Configure Wake-up Mechanism	86

5.42.	AT+QCFG="roamserviceex" Control Relevant Functions in Roaming State	88
5.43.	AT+QCFG="nwscanseq" Configure RATs Searching Sequence	89
5.44.	AT+QCFG="eps_only_creg_real" Configure CS Registration Reporting Mode in EPS-only Scenario	90
6	PS Commands.....	92
6.1.	AT+QCFG="ntp" Specify the Maximum Re-transmission Counts and the Interval for NTP	92
6.2.	AT+QCFG="TCP/SendMode" Configure TCP Sending Mode	93
6.3.	AT+QCFG="tcp/windowsize" Configure TCP Window Available Size	94
7	CS Commands.....	95
7.1.	AT+QCFG="amrcodec" Configure AMR Codec	95
7.2.	AT+QCFG="frhrcodec" Configure GSM EFR/HR/FR Codec.....	96
7.3.	AT+QCFG="bip/auth" Configure PDP Authentication Type in BIP Process	97
7.4.	AT+QCFG="SMS/ListMsgMap" List Message Map.....	98
7.5.	AT+QCFG="ims/ut" Enable/Disable IMS/UT Function	99
7.6.	AT+QCFG="ims" Configure IMS Function.....	101
7.7.	AT+QCFG="ltesms/format" Set SMS Format in LTE Mode	102
7.8.	AT+QCFG="volte_disable" Enable/Disable VoLTE.....	103
7.9.	AT+QCFG="sms/omadm" Set OMADM Message Parsing Mode	104
7.10.	AT+QCFG="imsreg/iptype" Configure the IP Type for IMS Registration	105
7.11.	AT+QCFG="sim/recovery" Configure (U)SIM Card Hot-plug	106
7.12.	AT+QCFG="siminvalidrecovery" Enable/Disable Re-attach Request.....	107
7.13.	AT+QCFG="roaming/voicecall" Enable/Disable Voice Call in Roaming Mode	108
7.14.	AT+QCFG="voice_busytone" Control Busy Tone Playback	109
7.15.	AT+QCFG="call_control" Enable/Disable Module Voice Call Feature.....	110
8	PPP Command	112
8.1.	AT+QCFG="ppp/termframe" Enable/Disable the PPP TERM Frame Sending	112
9	USB Commands.....	114
9.1.	AT+QCFG="usbnet" Configure the Network Card Type Interface	114
9.2.	AT+QCFG="usbcfg" Configure VID, PID and Porting Settings	115
9.3.	AT+QCFG="usbee" Control the USB Device Loading	116
9.4.	AT+QCFG="usbmode" Get USB Mode	117
9.5.	AT+QCFG="spi/set" Configure SPI or UART Driver.....	118
9.6.	AT+QCFG="usbenum/seoctl" Enable Optimization of USB Enumeration Failure	119
10	CDMA Commands.....	121
10.1.	AT+QCFG="cdma/pppauth" Set PPP Authentication Optimization under CDMA	121
10.2.	AT+QCFG="ehrpdp" Configure CDMA Mode.....	122
10.3.	AT+QCFG="cdmasms/cmtformat" Set CMT Format of CDMA SMS PDU.....	123
11	SMS Commands.....	125
11.1.	AT+QCFG="urcport/sms" Set URC Output Port of Short Message	125
11.2.	AT+QCFG="sms_retry" Configure SMS Retry Period and Interval.....	126
11.3.	AT+QCFG="sms_control" Enable/Disable Delivering or Submitting SMS	128

12	Appendix References	130
13	Appendix Summary of <err>.....	133
14	Appendix List of Cause	136
14.1.	Release Cause Text List of AT+QCFG="urc_cause_support"	136

Table Index

Table 1: Applicable Modules	10
Table 2: Types of AT Commands	11
Table 3: Related Document	130
Table 4: Terms and Abbreviations	130
Table 5: Different Coding Schemes of +CME ERROR: <err>	133
Table 6: List of ESM Cause	136
Table 7: List of EMM Cause	138
Table 8: List of MO SMS CP Cause	140
Table 9: List of GMM Cause	140
Table 10: List of MM Cause	142
Table 11: List of SM Cause	143

1 Introduction

This document introduces Quectel QCFG commands applicable for EC2x family, EG2x family, EG9x family and EM05 series modules to query and configure UE settings.

1.1. Applicable Modules

Table 1: Applicable Modules

Module Family	Module
EC2x	EC20-CE
	EC21 Series
	EC25 Series
EG2x	EG21-G
	EG25-G
	EG21-GL
	EG25-GL
EG9x	EG91 Series
	EG95 Series
-	EM05 Series

NOTE

The actual support of the specific **AT+QCFG** is subject to the result of executing **AT+QCFG=?** by using the corresponding firmware version.

1.2. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on the command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals its previous value or the default settings, unless otherwise specified.
- **Underline** Default setting of a parameter.

1.3. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

AT+QCFG implemented by EC2x family, EG2x family, EG9x family and EM05 series modules is in “Extended” syntax, as illustrated below.

● Extended

There are several types of extended commands as shown in the following table:

Table 2: Types of AT Commands

Command Type	Syntax	Description
Test Command	AT+<cmd>=?	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	AT+<cmd>?	Check the current parameter value of the corresponding command.
Write Command	AT+<cmd>=<p1>[,<p2>[,<p3>[...]]]	Set user-definable parameter value.
Execution Command	AT+<cmd>	Return a specific information parameter or perform a specific action.

Multiple commands can be placed on a single line using a semi-colon (;) between commands. In such cases, only the first command should have **AT** prefix. Commands can be in upper or lower case.

Spaces should be ignored when you enter AT commands, except in the following cases:

- Within quoted strings, where spaces are preserved;
- Within an unquoted string or numeric parameter;
- Within an IP address;
- Within the AT command name up to and including a =, ? or =?.

On input, at least a carriage return is required. A newline character is ignored so it is permissible to use carriage return/line feed pairs on the input.

If no command is entered after the **AT** token, **OK** will be returned. If an invalid command is entered, **ERROR** will be returned.

Optional parameters, unless explicitly stated, need to be provided up to the last parameter being entered.

1.4. AT Command Responses

When the AT command processor has finished processing a line, it will output **OK**, **ERROR** or **+CME ERROR: <err>** to indicate that it is ready to accept a new command. Solicited information responses are sent before the final **OK**, **ERROR** or **+CME ERROR: <err>**.

Responses will be in the format of:

```
<CR><LF>+CMD1:<parameters><CR><LF>  
<CR><LF>OK<CR><LF>
```

1.5. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there is a correlation among these examples, or that they should be executed in a given sequence. The URLs, domain names, IP addresses, usernames/accounts, and passwords (if any) in the AT command examples are provided for illustrative and explanatory purposes only, and they should be modified to reflect your actual usage and specific needs.

2 Test Command

2.1. AT+QCFG Extended Configuration Settings

AT+QCFG Extended Configuration Settings	
Test Command AT+QCFG=?	Response ... +QCFG: "apready",(list of supported <enable>s),(list of supported <level>s),(list of supported <interval>s) +QCFG: "sleepind/level",(list of supported <value>s) +QCFG: "wakeupin/level",(list of supported <value>s),(list of supported <enable>s) +QCFG: "urc/ri/ring",(list of supported <typeri>s),(list of supported <pulse_duration>s),(list of supported <active_duration>s),(list of supported <inactive_duration>s),(list of supported <ring_no_disturbing>s),(list of supported <pulse_count>s) +QCFG: "urc/ri/smsincoming",(list of supported <typeri>s),(list of supported <pulse_duration>s),(list of supported <pulse_count>s) +QCFG: "urc/ri/other",(list of supported <typeri>s),(list of supported <pulse_duration>s),(list of supported <pulse_count>s) +QCFG: "risignalttype",(list of supported <RI_signal_type>s) +QCFG: "urc/delay",(list of supported <enable>s) +QCFG: "urc/cache",(list of supported <enable>s) +QCFG: "urc/poweron",(list of supported <n>s) +QCFG: "divctl",(list of supported <sys_mode>s),(list of supported <diversity_info>s) +QCFG: "bootup",<name>,(list of supported <enable>s) +QCFG: "ppp/sleep_ri",(list of supported <on_off>s),(list of supported <RI_interval>s) +QCFG: "urc/ri/pin",(list of supported <pin_name>s) +QCFG: "icf",(list of supported <data_bit>s),(list of supported <stop_bit>s),(list of supported <parity_mode>s)

+QCFG: "urcdelay",(list of supported <mode>s),(list of supported <delay_time>s)

+QCFG: "fast/poweroff",(list of supported <n>s)

+QCFG: "sleep/datactrl",(list of supported <dev>s),(list of supported <time_out>s),(list of supported <flag>s)

+QCFG: "rf/tuner_cfg",<index>,<lte bands>,<wcdma bands>,<gsm bands>]

+QCFG: "mms_rec_control",(list of supported <n>s)

+QCFG: "tone/incoming",(list of supported <enable>s)

+QCFG: "pcmclk",(list of supported <enable>s)

+QCFG: "codec/powsave",(list of supported <status>s)

+QCFG: "gprsattach",(list of supported <attach_mode>s)

+QCFG: "nwscanmode",(list of supported <scan_mode>s),(list of supported <effect>s)

+QCFG: "servicedomain",(list of supported <service>s),(list of supported <effect>s)

+QCFG: "band",(list of supported <bandval>s),(list of supported <ltebandval>s),(list of supported <tdsbandval>s),(list of supported <effect>s)

+QCFG: "rrc",(list of supported <rrcr>s)

+QCFG: "msc",(list of supported <mscr>s)

+QCFG: "sgsn",(list of supported <sgsnr>s)

+QCFG: "hsdpacat",(list of supported <HSDPA_cat>s)

+QCFG: "hsupacat",(list of supported <HSUPA_cat>s)

+QCFG: "pdp/duplicatechk",(list of supported <enable>s)

+QCFG: "disable_backoff_lte",(list of supported <value>s)

+QCFG: "airplanecontrol",(list of supported <enable>s)

+QCFG: "epcflag",(list of supported <n>s)

+QCFG: "lte/bandprior",(list of supported <band1>s),(list of supported <band2>s),(list of supported <band3>s)

+QCFG: "plmn/addinfbdn",(list of supported <enable>s)

+QCFG: "cops_no_mode_change",(list of supported <value>s)

+QCFG: "hplmn/search_timer",(list of supported <timer>s)

+QCFG: "tdd/config",(list of supported <assign>s),(list of supported <pattern>s)

+QCFG: "urc_cause_support",(list of supported <bit_mask_value>s)

+QCFG: "dhcppktfltr",(list of supported <disable>s)

+QCFG: "oostimer",<timer1>,<timer2>,<timer3>

+QCFG: "apn/blocked",(list of supported <block_mode>s),(list of supported <NV_mode>s)

+QCFG: "redir/3gtolte",(list of supported <redir_mode>s),(list of supported <NV_flag>s),list of

supported <NV_value>s)
 +QCFG: "rssi", (list of supported <threshold>s)
 +QCFG: "roamservice", (list of supported <roam_mode>s), (list of supported <effect>s)
 +QCFG: "fast_dormancy", (list of supported <op>s), (list of supported <duration>s)
 +QCFG: "airplane", (list of supported <n>s)
 +QCFG: "rrc/control", (list of supported <enable>s), (list of supported <crcc>s), (list of supported <trrc>s), (list of supported <wai_time>s), (list of supported <bar_opt>s), (list of supported <conn_est_latency>s)
 +QCFG: "nwscanmodeex", (list of supported <mode>s)
 +QCFG: "assign_plmn_in_limit_search", (list of supported <enable>s), <plmn>
 +QCFG: "iprulectl", (list of supported <type>s)
 +QCFG: "disrplmn", (list of supported <RPLMN_disable>s), (list of supported <RPLMNact_disable>s)
 +QCFG: "lte/preferfre", op, index, band, bandwidth, earfcn, mcc, mnc
 +QCFG: "cops_control", (list of supported <enable>s)
 +QCFG: "map_rej_cause7_to_cause14", (list of supported <flag>s)
 +QCFG: "netmaskset", (list of supported <enable>s), <netmask>
 +QCFG: "pingdiscard", (list of supported <en>s)
 +QCFG: "urc/ri/restart", (list of supported <enable>s)
 +QCFG: "ping/ri", (list of supported <enable>s), (list of supported <mode>s)
 +QCFG: "defaultdns", (list of supported <enable>s), <dns1>[, <dns2>]]
 +QCFG: "lpm/dataind", (list of supported <enable>s), (list of supported <mask>s)
 +QCFG: "roamserviceex", (list of supported <roammode>s)
 +QCFG: "ntp", (list of supported <cnt>s), (list of supported <interval>s)
 +QCFG: "nwscanseq", (list of supported <scanseq>s), (list of supported <effect>s)
 +QCFG: "TCP/SendMode", (list of supported <mode>s)
 +QCFG: "tcp/windowsize", (list of supported <buffer>s), (list of supported <window_size>s)
 +QCFG: "amrcodec", (list of supported <preference>s)
 +QCFG: "frhrcodec", (list of supported <preference>s)
 +QCFG: "bip/auth", (list of supported <n>s)

	+QCFG: "SMS/ListMsgMap",(list of supported <msgtype>s) +QCFG: "ims/ut",(list of supported <n>s) +QCFG: "ims",(list of supported <ims_conf>s) +QCFG: "ltesms/format",(list of supported <n>s) +QCFG: "volte_disable",(list of supported <n>s) +QCFG: "sms/omadm",(list of supported <n>s) +QCFG: "imsreg/iptype",(list of supported <n>s) +QCFG: "sim/recovery",(list of supported <recovery_count>s),(list of supported <auto_detect_period>s),(list of supported <auto_detect_count>s) +QCFG: "siminvalidrecovery",(list of supported <enable>s),(list of supported <timer>s),(list of supported <counter>s) +QCFG: "roaming/voicecall",(list of supported <voicecall_mode>s) +QCFG: "voice_busytone",(list of supported <mode>s) +QCFG: "call_control",(list of supported <disableMO>s),(list of supported <disableMT>s) +QCFG: "ppp/termframe",(list of supported <flag>s) +QCFG: "usbnet",(list of supported <net>s) +QCFG: "usbcfg",<vid>,<pid>,<diag>,<nmea>,<at_port>,<modem>,<rmnet>,<adb>,<uac> +QCFG: "usbee",<enable> +QCFG: "usbmode",(list of supported <n>s) +QCFG: "spi/set",(list of supported <flag>s) +QCFG: "usbenum/seoctl",(list of supported <enable>s) +QCFG: "cdma/pppauth",(list of supported <n>s) +QCFG: "ehrpd",(list of supported <mode>s) +QCFG: "cdmasms/cmtformat",[(list of supported <n>s)] +QCFG: "urcport/sms",(list of supported <n>s) +QCFG: "sms_retry",(list of supported <interval>s),(list of supported <period>s) +QCFG: "sms_control",(list of supported <submit>s),(list of supported <deliver>s) ... OK
Maximum Response Time	300 ms
Characteristics	-

NOTE

The above only shows an example for the command response. The response of the command varies according to the module used.

3 General Commands

3.1. AT+QCFG="apready" Set AP_Rdy Behavior

The command queries and configures the behavior of AP_READY pin. An external MCU can change the AP_READY pin level as needed.

When there is a URC to be reported, if the AP_READY pin level is invalid, the URC is buffered first, and the AP_READY pin level will be detected periodically with the configured detection period. The URC will be output when the AP_READY pin level becomes valid. The pulse signal generated on the MAIN_RI pin can still be output according to the configured mode, and the pulse signal will not be buffered.

AT+QCFG="apready" Set AP_Rdy Behavior	
Write Command AT+QCFG="apready" [<enable>,<level>,<interval>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "apready",<enable>,<level>,<interval> OK If any of the optional parameters is specified, set the AP_READY behavior: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are not saved.

Parameter

<enable>	Integer type. Enable/disable AP_READY behavior.
0	Disable
1	Enable

<level>	Integer type. Valid level of indicator pin. This parameter only takes effect when the AP_READY detection function is enabled, and determines the default level of AP_READY. 0 Low level 1 High level
<interval>	Integer type. Detection period. Unit: ms. Range:100–3000. Default value: 500. This parameter only takes effect when AP_READY detection function is enabled. When AP_READY level is invalid and a URC is reported, this parameter is used as detection interval to check whether the indicator pin level is valid.

NOTE

1. Maximally 15 URCs can be buffered. When the number of URC exceeds 15, the oldest one in the buffer will be cleared to store the new URC.
2. The **RING** URC is buffered only once for each call process.

Example

```
AT+QCFG="apready",1,0,800
OK
AT+QCFG="apready"
+QCFG: "apready",1,0,800
OK
```

3.2. AT+QCFG="sleepind/level" Configure the Output Level of the SLEEP_IND Pin

This command configures the output level of the SLEEP_IND pin when the module is in sleep mode.

AT+QCFG ="sleepind/level" Configure the Output Level of the SLEEP_IND Pin

Write Command	Response
AT+QCFG="sleepind/level"[,<value>]	If the optional parameter is omitted, query the current setting: +QCFG: "sleepind/level",<value>
	OK
	If the optional parameter is specified, set the output level of the SLEEP_IND pin: OK

	If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is saved automatically.

Parameter

<value>	Integer type. It indicates the output level after the module enters sleep mode.
0	When the module enters sleep mode, SLEEP_IND pin outputs high level
1	When the module enters sleep mode, SLEEP_IND pin outputs low level

Example

```

AT+QCFG="sleepind/level",0 //SLEEP_IND pin outputs high level.
OK
AT+QCFG="sleepind/level"
+QCFG: "sleepind/level",0 //Query the current setting.
OK

```

3.3. AT+QCFG="wakeupin/level" Configure Whether to Wake up the Module Through WAKEUP_IN Pin

This command configures whether to wake up the module through WAKEUP_IN pin.

AT+QCFG="wakeupin/level" Configure Whether to Wake up the Module Through WAKEUP_IN Pin	
Write Command AT+QCFG="wakeupin/level"[,<value>[,<enable>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "wakeupin/level",<value>,<enable> OK If any of the optional parameters is specified, configure whether to wake up the module through WAKEUP_IN pin: OK If there is any error:

	ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are saved automatically.

Parameter

<value>	Integer type. Set WAKEUP_IN pin to low or high level to wake up the module. 0 Set WAKEUP_IN pin to low level 1 Set WAKEUP_IN pin to high level
<enable>	Integer type. Enable or disable whether to wake up the module through WAKEUP_IN pin. 0 Disable 1 Enable

Example

```

AT+QCFG="wakeupin/level",0 //Set WAKEUP_IN pin to low level to wake up the module.
OK
AT+QCFG="wakeupin/level" //Query the current setting.
+QCFG: "wakeupin/level",0,0
OK

```

3.4. AT+QCFG="urc/ri/ring" Set RI Behavior When RING URC is Presented

AT+QCFG="urc/ri/ring", AT+QCFG="urc/ri/smsincoming" (Chapter 3.5) and AT+QCFG="urc/ri/other" (Chapter 3.6) control the RI (ring indicator) behavior when a URC is reported. These configurations will be stored into NV automatically.

The ring indicator is active low. AT+QCFG="urc/ri/ring" specifies the RI behavior when URC **RING** is presented to indicate an incoming call.

The sum of **<active_duration>** and **<inactive_duration>** determines the interval time of **RING** indications when a call is coming.

AT+QCFG="urc/ri/ring" Set RI Behavior When RING URC is Presented

Write Command AT+QCFG="urc/ri/ring",<typeri>[,<pulse_duration>[,<active_duration>[,<inactive_duration>[,<ring_no_disturbing>[,<pulse_count>]]]]]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "urc/ri/ring",<typeri>,<pulse_duration>,<active_duration>,<inactive_duration>,<ring_no_disturbing>,<pulse_count> OK If any of the optional parameters is specified, set the RI behavior when RING URC is presented: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are saved automatically.

Parameter

<typeri>	String type. RI behavior when URCs are presented.
"off"	No change. Ring indicator keeps inactive
"pulse"	Pulse. Pulse width is determined by <pulse_duration>
"always"	Change to active. RI behavior can be restored to inactive by AT+QIR . See document [1] for details about the command
"auto"	When "RING" is presented to indicate an incoming call, the ring indicator changes to and keeps active. When ring of the incoming call ends, either answering or hanging up the incoming call, the ring indicator will change to inactive
"wave"	When RING is presented to indicate an incoming call, the ring indicator outputs a square wave. Both <active_duration> and <inactive_duration> are used to set parameters of the square wave. When the ring of incoming call ends, either answering or hanging up the incoming call, the ring indicator will change to inactive
<pulse_duration>	Integer type. Set the pulse width. Range: 1–2000. Default value: 120. Unit: ms. This parameter is only valid when <typeri> is "pulse". If this parameter is not needed, it can be set as null.

<active_duration>	Integer type. The active duration of the square wave. Range: 1–10000. Default value: 1000. Unit: ms. This parameter is only valid when <typeri> is "wave".
<inactive_duration>	Integer type. Set the inactive duration of the square wave. Range: 1–10000. Default value: 5000. Unit: ms. This parameter is only valid when <typeri> is "wave".
<ring_no_disturbing>	String type. Set whether the ring indicator behavior could be disturbed. This parameter is only valid when <typeri> is configured to "auto" or "wave". For example, when <typeri> is "wave", if the square wave does not need to be disturbed by other URCs (including SMS related URCs), then <ring_no_disturbing> should be set to "on". "off" RI behavior can be disturbed by other URCs when the behavior is caused by an incoming call ringing "on" RI behavior cannot be disturbed by other URCs when the behavior is caused by an incoming call ringing
<pulse_count>	Integer type. The count of pulse. This parameter is only valid when <typeri> is "pulse". Range: 1–5. Default value: 1. The interval time between two pulses is equal to <pulse_duration>.
<err>	Integer type. Error code. See Chapter 13 .

3.5. AT+QCFG="urc/ri/smsincoming" Set RI Behavior When Incoming SMS URCs are Presented

This command specifies the RI (ring indicator) behavior when related incoming message URCs are presented. Related incoming message URCs list: **+CMTI**, **+CMT**, **+CDS** and **+CBM**.

AT+QCFG="urc/ri/smsincoming" Set RI Behavior When Incoming SMS URCs are Presented

Write Command	Response
AT+QCFG="urc/ri/smsincoming"[,<typeri>[,<pulse_duration>[,<pulse_count>]]]	If the optional parameters are omitted, query the current setting: +QCFG: "urc/ri/smsincoming",<typeri>,<pulse_duration>,<pulse_count> OK If any of the optional parameters is specified, set the RI behavior when incoming SMS URCs are presented: OK If there is any error:

	ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are saved automatically.

Parameter

<typeri>	String type. RI behavior when URCs are presented. "off" No change. Ring indicator keeps inactive "pulse" Pulse. Pulse width is determined by <pulse_duration> "always" Change to active. RI behavior can be restored to inactive by AT+QIR
<pulse_duration>	Integer type. Set the width of pulse. Range: 1–2000. Default value: 120. Unit: ms. This parameter is only valid when <typeri> is "pulse".
<pulse_count>	Integer type. The count of pulse. This parameter is only valid when <typeri> is "pulse". Range: 1–5. Default value: 1. The interval time between two pulses is equal to <pulse_duration> .
<err>	Integer type. Error code. See Chapter 13 .

3.6. AT+QCFG="urc/ri/other" Set RI Behavior When Other URCs are Presented

This command specifies the RI (ring indicator) behavior when other URCs are presented.

AT+QCFG="urc/ri/other" Set RI Behavior When Other URCs are Presented	
Write Command AT+QCFG="urc/ri/other",<typeri>,<pulse_duration>,<pulse_count>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "urc/ri/other",<typeri>,<pulse_duration>,<pulse_count> OK If any of the optional parameter is specified, set the RI behavior when other URCs are presented: OK

	If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are saved automatically.

Parameter

<typeri>	String type. RI behavior when URCs are presented. "off" No change. Ring indicator keeps inactive "pulse" Pulse. Pulse width is determined by <pulse_duration>
<pulse_duration>	Integer type. Set the width of pulse. Range: 1–2000. Default value: 120. Unit: ms. This parameter takes effect only when <typeri> is "pulse".
<pulse_count>	Integer type. The count of pulse. This parameter is only valid when <typeri> is "pulse". Range: 1–5. Default value: 1. The interval time between two pulses is equal to <pulse_duration> .
<err>	Integer type. Error code. See Chapter 13 .

3.7. AT+QCFG="risignalttype" RI Signal Output Carrier

This command specifies the RI (ring indicator) signal output carrier.

AT+QCFG="risignalttype" RI Signal Output Carrier	
Write Command AT+QCFG="risignalttype",<RI_signal_type>	Response If the optional parameter is omitted, query the current setting: +QCFG: "risignalttype",<RI_signal_type> OK If the optional parameter is specified, set the RI signal output carrier: OK If there is any error: ERROR Or +CME ERROR: <err>

Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is saved automatically.

Parameter

<RI_signal_type>	String type. RI signal output carrier. "respective" The ring indicator behaves on the port where URC is presented, and the port can be obtained by AT+QURCCFG="urcport" . See document [1] for details about the command If URC is presented on UART port, it is physical ring line. If URC is presented on USB modem port, it is virtual ring line. If URC is presented on USB AT port, no ring line for USB AT port which does not support ring line. "physical" No matter which port URC is presented on, the RI pin will have a ring jump
<err>	Integer type. Error code. See Chapter 13 .

Example

```
AT+QCFG="risignalttype"
+QCFG: "risignalttype","respective"

OK
AT+QCFG="risignalttype","physical"
OK
AT+QCFG="risignalttype"
+QCFG: "risignalttype","physical"

OK
```

3.8. AT+QCFG="urc/delay" Delay URC Indication Output

This command delays the output of URC indication until ring indicator pulse ends.

AT+QCFG="urc/delay" Delay URC Indication Output	
Write Command AT+QCFG="urc/delay"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urc/delay",<enable> OK

	If the optional parameter is specified, set when the URC indication is outputted: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is saved automatically.

Parameter

<enable>	Integer type. <u>0</u> URC indication will be outputted when ring indicator pulse starts 1 URC indication will be outputted when ring indicator pulse ends (only effective when the type of ring indicator is "pulse". See AT+QCFG="urc/ri/ring", AT+QCFG="urc/ri/smsincoming" or AT+QCFG="urc/ri/other" for details)
<err>	Integer type. Error code. See Chapter 13 .

3.9. AT+QCFG="urc/cache" Enable/Disable URC Cache

AT+QCFG="urc/cache" Enable/Disable URC Cache	
Write Command AT+QCFG="urc/cache"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urc/cache",<enable> OK If the optional parameter is specified, enable/disable URC cache: OK If there is any error: ERROR Or +CME ERROR: <err>

Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is not saved.

Parameter

<enable>	Integer type. Enable/disable URC cache. 0 Disable 1 Enable
<err>	Integer type. Error code. See Chapter 13 .

Example

```

AT+QCFG="urc/cache"
+QCFG: "urc/cache",0      //Disable URC cache.

OK
AT+QCFG="urc/cache",1     //Enable URC cache.
OK
AT+QCFG="urc/cache"
+QCFG: "urc/cache",1

OK
//Make a call and send two messages to the module.
AT+QCFG="urc/cache",0     //Disable URC cache.
OK

```

3.10. AT+QCFG="urc/poweron" Set Output URC of Power-on

AT+QCFG="urc/poweron" Set Output URC of Power-on

Write Command AT+QCFG="urc/poweron"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urc/poweron",<n> OK If the optional parameter is specified, set output URC of power-on: OK
---	--

	If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<n>	Integer type. Enable/disable URC output of power-on.
0	Enable
1	Disable

Example

```

AT+QCFG="urc/poweron"
+QCFG: "urc/poweron",0           //Query the current configuration of URC output.

OK
AT+CFUN=0
OK
AT+CFUN=1
OK

+CPIN: READY

+QUSIM: 1

+QIND: SMS DONE

+QIND: PB DONE
AT+QCFG="urc/poweron",1         //Disable URC output.
OK
AT+CFUN=0
OK
AT+CFUN=1
OK
//No URC output.
AT+QCFG="urc/poweron"
+QCFG: "urc/poweron",1

OK

```

3.11. AT+QCFG="divctl" Configure Primary and Rx-diversity under LTE/WCDMA

AT+QCFG="divctl" Configure Primary and Diversity under LTE/WCDMA	
Write Command AT+QCFG="divctl",<sys_mode>[,<diversity_info>]	Response If the optional parameter is omitted, query the current setting: +QCFG:"divctl",<sys_mode>,<diversity_info> OK If the optional parameter is specified, configure primary and Rx-diversity under LTE/WCDMA: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	-

Parameter

<sys_mode>	String type. Network mode. "lte" LTE "wcdma" WCDMA
<diversity_info>	Integer type. Rx-diversity chain information. 0 Enable Rx-diversity chains 0 and 1 (PRX and DRX respectively) 1 Signal information is available on Rx-diversity chain 0 (PRX) 2 Signal information is available on Rx-diversity chain 1 (DRX)

Example

AT+QCFG="divctl","lte" +QCFG: "divctl","lte",0	//Query the current configuration under LTE.
OK AT+QCFG="divctl","lte",1	//Open LTE PRX, and close DRX.
OK	

3.12. AT+QCFG="bootup" Enable/Disable Services in Linux

This command enables/disables the services in Linux, such as the web services.

AT+QCFG="bootup" Enable/Disable Services in Linux	
Write Command AT+QCFG="bootup"[,<name>,<enable>]	Response If the optional parameters are omitted, list the range supported by <name>: +QCFG: "bootup",<sfe,wlan-services,web-services> OK If the optional parameters are specified, enable/disable services in Linux: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<name>	String type. Service name.	
	sfe	Shortcut forward engine
	web-services	WEB service
	wlan-services	WLAN service
<enable>	Integer type. Set/query the services status.	
	0	Disable the services status
	1	Enable the services status
	2	Query the services status

Example

```

AT+QCFG="bootup"
+QCFG: "bootup",<sfe,wlan-services,web-services>

OK
AT+QCFG="bootup",web-services,0
OK

```

3.13. AT+QCFG="ppp/sleep_ri" Enable/Disable Waking up the Module through the RI Pin Indication after PPP Establishment

AT+QCFG="ppp/sleep_ri" Enable/Disable Waking up the Module through the RI Pin Indication after PPP Establishment	
Write Command AT+QCFG="ppp/sleep_ri", <on_off>,<RI_interval>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "ppp/sleep_ri",<on_off>,<RI_interval> OK If any of the optional parameters is specified, enable or disable waking up the module through the RI pin after PPP establishment: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are not saved.

Parameter

<on_off>	Integer type. Enable/Disable waking up the module through the RI pin when receiving data after PPP establishment. 0 Disable 1 Enable
<RI_interval>	Integer type. RI level jump interval. Unit: ms. Range: 500–50000. Default value: 1000.

NOTE

Under PPP, when the module is awakened from the sleep, the RI pin will generate a high-level pulse.

3.14. AT+QCFG="urc/ri/pin" Configure UART Pins Corresponding to RI

AT+QCFG="urc/ri/pin" Configure UART Pins Corresponding to RI	
Write Command AT+QCFG="urc/ri/pin"[,<pin_name>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urc/ri/pin",<pin_name> OK If the optional parameter is specified, configure UART pins corresponding to RI: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is saved automatically.

Parameter

<pin_name>	String type. UART pin name. "uart_ri" "uart_dcd"
-------------------------	--

3.15. AT+QCFG="icf" Configure Main UART

This command configures the data bit, stop bit, parity bit of main UART.

AT+QCFG="icf" Configure Main UART	
Write Command AT+QCFG="icf"[,<data_bit>,<stop_bit>,<parity_mode>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "icf",<data_bit>,<stop_bit>,<parity_mode> OK If the optional parameters are specified, set the main UART: OK

	If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<data_bit>	Integer type. The supported data bit per char. 0 5 data bits per char 1 6 data bits per char 2 7 data bits per char <u>3</u> 8 data bits per char
<stop_bit>	Integer type. The supported stop bit. 0 0.5 stop bit <u>1</u> 1 stop bit 2 1.5 stop bits 3 2 stop bits
<parity_mode>	Integer type. The supported parity mode. <u>0</u> NO_PARITY 1 ODD_PARITY 2 EVEN_PARITY 3 SPACE_PARITY

Example

```

AT+QCFG="icf"
+QCFG: "icf",3,1,0      //Default UART configuration: 8 data bits per char, 1 stop bits, NO_PARITY.

OK
AT+QCFG="icf",2,1,1    //Configure main UART: 7 data bits per char, 1 stop bits, ODD_PARITY.
OK

```

3.16. AT+QCFG="urcdelay" Configure URC Delay

This command enables/disables URC delay report and URC delay time. When this feature is enabled, URC will be reported after the delay time.

AT+QCFG="urcdelay" Configure URC Delay

Write Command AT+QCFG="urcdelay"[,<mode>,<delay_time>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "urcdelay",<mode>,<delay_time> OK If the optional parameters are specified, configure URC delay: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are saved automatically.

Parameter

<mode>	Integer type. Disable/enable URC delay feature. <u>0</u> Disable 1 Enable
<delay_time>	Integer type. URC delay time. Range: 0–10000. Unit: ms. Default value: 100.

Example

```
AT+QCFG="urcdelay"
+QCFG: "urcdelay",0,0      //URC delay is disabled by default.

OK
AT+QCFG="urcdelay",1,3000  //Enable URC delay feature and delay URC for 3 s.
OK
```

3.17. AT+QCFG="fast/poweroff" Enable/Disable Fast Power-Off

AT+QCFG="fast/poweroff" Enable/Disable Fast Power-Off

Write Command	Response
---------------	----------

AT+QCFG="fast/poweroff"[,<n>]	If the optional parameter is omitted, query the current setting: +QCFG: "fast/poweroff",<n> OK If the optional parameter is specified, enable/disable fast power-off: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is saved automatically.

Parameter

<n>	Integer type. Enable/disable fast power-off. <u>0</u> Disable 1 Enable
<err>	Integer type. Error code. See Chapter 13 .

Example

```

AT+QCFG="fast/poweroff"           //Query the current setting.
+QCFG: "fast/poweroff",0

OK
AT+QCFG="fast/poweroff",1         //Enable fast power-off.
OK
AT+QCFG="fast/poweroff"
+QCFG: "fast/poweroff",1         //Fast power-off is enabled.

OK

```

3.18. AT+QCFG="sleep/datactrl" Configure Data Cache Mode

This command configures data cache mode when the module is in sleep mode.

AT+QCFG="sleep/datactrl" Configure Data Cache Mode	
Write Command AT+QCFG="sleep/datactrl"[,<dev>[,<time_out>[,<flag>]]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "sleep/datactrl",<dev>,<time_out>,<flag> OK If any of the optional parameters are specified, set the data cache mode when the module is in sleep mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configurations are not saved.

Parameter

<dev>	Integer type. The type of the device to be cached. (e.g. 5 = 1 + 4, indicates caching the data that from UART1 and USB AT port when the module is in sleep mode.) <u>0</u> No device. Disable data cache 1 UART1 2 USB modem port (Not supported currently) 4 USB AT port (Not supported currently)
<time_out>	Integer type. The maximum time to cache the data that from the specified output port. If time reaches the set time, the data will be output. Default value: 300. Unit: ms.
<flag>	Integer type. The flag of automatic sending data when USB status changes (not supported currently). 0 When the USB changes to the normal state, the data sending will not be triggered <u>1</u> When USB changes from DISCONNECT or SUSPEND to CONFIGURED, the module will send the cached data immediately
<err>	Integer type. Error code. See Chapter 13 .

NOTE

When all the following conditions are met, the module judges that the host is in the sleep mode.

- DTR condition: DTR sleep control is enabled with high level. If DTR sleep control is disabled, this condition can be ignored.
- USB condition: the status of USB is DISCONNECT or SUSPEND.
- **AT+QSCLK** is configured to 1.

Example

```
AT+QCFG="sleep/datactrl",1,800,0 //Enable data caching when the module is in sleep mode.
                                   The caching port is UART1. Timeout is 800 ms.
```

OK

```
AT+QCFG="sleep/datactrl"
```

```
+QCFG: "sleep/datactrl",0,300,1 //Query the current setting, which is disabled.
```

OK

3.19. AT+QCFG="rf/tuner_cfg" Set the Mapping between RF Tuner and RF Bands

AT+QCFG="rf/tuner_cfg" Set the Mapping between RF Tuner and RF Bands

Write Command

```
AT+QCFG="rf/tuner_cfg"[,<index>,<lte
bands>,<wcdma bands>,<gsm bands>]
```

Response

If the optional parameters are omitted, query the current setting:

```
+QCFG: "rf/tuner_cfg",<index>,<lte bands>,<wcdma b
ands>,<gsm bands>
```

OK

If the optional parameters are specified, set the mapping between RF tuner and RF bands:

OK

If there is any error:

ERROR

Maximum Response Time

300 ms

Characteristics

This command takes effect after the module is rebooted.
The configurations are saved automatically.

Parameter

<index>	Integer type. Pin level status. Range: 0–3. 0 Pin 144 at low level, pin 143 at low level 1 Pin 144 at low level, pin 143 at high level 2 Pin 144 at high level, pin 143 at low level 3 Pin 144 at high level, pin 143 at high level
<lte bands>	String type. LTE bands, and the separator is comma. E.g., "1,3,5".
<wcdma bands>	String type. WCDMA bands, and the separator is comma. E.g., "1,3,5".
<gsm bands>	String type. GSM bands, and the separator is comma. E.g., "1,3,5".

Example

```
AT+QCFG="rf/tuner_cfg" //Query the current setting.
+QCFG: "rf/tuner_cfg",0,"1,2,3,4,8,25,39","1,2,4,8","8,3,2"
"rf/tuner_cfg",1,"5,18,19,20,26","5,6,19","5"
"rf/tuner_cfg",2,"12,13,28"
"rf/tuner_cfg",3,"7,38,40,41"
```

OK

//Set the LTE bands, i.e., pin 144 at high level and pin 143 at low level.

```
AT+QCFG="rf/tuner_cfg",2,"2,12,13, 25,28","5, 8"
```

OK

```
AT+QCFG="rf/tuner_cfg" //Query the current setting.
+QCFG: "rf/tuner_cfg", 0,"1, 3, 4, 8, 39","1, 2","8, 3, 2"
"rf/tuner_cfg",1,"5,18,19,20,26","5,6,19","5"
"rf/tuner_cfg",2,"2,12,13, 25,28","5,8"
"rf/tuner_cfg",3,"7,38,40,41"
```

OK

3.20. AT+QCFG="mms_rec_control" Save/Discard the MMS

AT+QCFG="mms_rec_control" Save/Discard the MMS

Write Command

```
AT+QCFG="mms_rec_control" [<n>]
```

Response

If the optional parameter is omitted, query the current setting:
+QCFG: "mms_rec_control",<n>

OK

	If the optional parameter is specified, set whether to discard the MMS: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<n>	Integer type. Whether to discard the MMS.
<u>0</u>	Save the MMS
1	Discard the received MMS

Example

```

AT+QCFG="mms_rec_control",1 //Discard the received MMS.
OK
AT+QCFG="mms_rec_control" //Query the current setting.
+QCFG: "mms_rec_control",1
OK

```

4 Audio Commands

4.1. AT+QCFG="tone/incoming" Enable Ring Tone

AT+QCFG="tone/incoming" Enable Ring Tone	
Write Command AT+QCFG="tone/incoming" [,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "tone/incoming",<enable> OK If the optional parameter is specified, enable ring tone: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<enable>	Integer type. Enable/disable the ring tone.
	0 Disable ring tone
	1 Enable Nokia ring tone
	2 Enable ring tone
<err>	Integer type. Error code. See Chapter 13 .

Example

```
AT+QCFG="tone/incoming"           //Ring tone is disabled.
+QCFG: "tone/incoming",0
```

```
OK
AT+QCFG="tone/incoming",1 //Enable the ring tone.
OK
AT+QCFG="tone/incoming" //Ring tone is enabled.
+QCFG: "tone/incoming",1
OK
```

4.2. AT+QCFG="pcmclk" Configure PCM_CLK

This command enables or disables PCM_CLK.

AT+QCFG="pcmclk" Configure PCM_CLK	
Write Command AT+QCFG="pcmclk"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "pcmclk",<enable> OK If the optional parameter is specified, configure PCM_CLK: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<enable>	Integer type. Enable/disable PCM_CLK. <u>0</u> Disable PCM_CLK. In decimal, the value is 0; In hexadecimal, the value is 0x0 <u>1</u> Enable PCM_CLK. In decimal, the value is 1; In hexadecimal, the value is 0x1
<err>	Integer type. Error code. See Chapter 13 .

NOTE

The output frequency depends on **<clock>** of **AT+QDAI**. If enabled, PCM_CLK will be able to output

square wave, and the frequency is 2048 kHz; the PCM_SYNC will be able to output pulse shape, and the frequency is 8 kHz. See **document [1]** for the details of the command.

4.3. AT+QCFG="codec/powsave" Set PSM for ALC5616 Codec

The command enables/disables the PSM (power saving mode) for ALC5616 codec.

AT+QCFG="codec/powsave" Set PSM for ALC5616 Codec	
Write Command AT+QCFG="codec/powsave",<status>	Response If the optional parameter is omitted, query the current setting: +QCFG: "codec/powsave",<status> OK If the optional parameter is specified, enable/disable PSM for ALC5616 codec: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<satus>	Integer type. Enable/disable the PSM. 0 Disable 1 Enable
<err>	Integer type. Error code. See Chapter 13 .

NOTE

The configuration will take effect during the next calling.

Example

```
AT+QCFG="codec/powsave",1      //Enable the PSM for ALC5616 codec.  
OK  
AT+QCFG="codec/powsave"  
+QCFG: "codec/powsave",1      //Query the current power saving mode.  
OK
```

5 Network Commands

5.1. AT+QCFG="gprsattach" Configure GPRS Attach Mode

This command specifies the mode to attach GPRS when UE is powered on. This configuration is valid only after the module is restarted.

AT+QCFG="gprsattach" Configure GPRS Attach Mode	
Write Command AT+QCFG="gprsattach"[,<attach_mode>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "gprsattach",<attach_mode> OK If the optional parameter is specified, set the GPRS attach mode: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<attach_mode>	Integer type. The mode to attach GRPS when UE is powered on. 0 Attach manually <u>1</u> Attach automatically
<err>	Integer type. Error code. See Chapter 13 .

5.2. AT+QCFG="nwscanmode" Configure Network Search Mode

This command specifies the network mode to be searched.

AT+QCFG="nwscanmode" Configure Network Search Mode	
Write Command AT+QCFG="nwscanmode"[,<scan_mode>[,<effect>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "nwscanmode",<scan_mode> OK If any of the optional parameters is specified, set the network mode to be searched: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	<effect> determines when the command takes effect. The configuration is be saved automatically.

Parameter

<scan_mode>	Integer type. RAT. 0 AUTO 1 GSM only 2 WCDMA only 3 LTE only 4 TD-SCDMA only 5 UMTS only 6 CDMA only 7 HDR only 8 CDMA and HDR only
<effect>	Integer type. When the command to take effect. 0 Take effect after UE is rebooted <u>1</u> Take effect immediately
<err>	Integer type. Error code. See Chapter 13 .

5.3. AT+QCFG="servicedomain" Configure Service Domain

This command queries and configures the registered service domain.

AT+QCFG="servicedomain" Configure Service Domain	
Write Command AT+QCFG="servicedomain"[,<service>[,<effect>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "servicedomain",<service> OK If any of the optional parameters is specified, set the service domain of UE: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	<effect> determines when the command takes effect. The configuration is saved automatically.

Parameter

<service>	Integer type. Service domain of UE. 0 CS only 1 PS only <u>2</u> CS & PS
<effect>	Integer type. When to take effect. 0 Take effect after UE is rebooted <u>1</u> Take effect immediately
<err>	Integer type. Error code. See Chapter 13 .

5.4. AT+QCFG="band" Configure Band

This command specifies the preferred frequency bands to be searched of UE.

AT+QCFG="band" Configure Band	
Write Command AT+QCFG="band"[,<bandval>,<ltebandval>,<tdsbandval>,<effect>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "band",<bandval>,<ltebandval>,<tdsbandval> OK If any of the optional parameters is specified, set the band: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	<effect> determines when the command takes effect. The configurations are saved automatically.

Parameter

<bandval>	A hexadecimal value that specifies the GSM and WCDMA frequency bands. e.g. 00000013 = 00000001 (GSM900) + 00000002 (GSM1800) + 00000010 (WCDMA2100) 00000000 No change 00000001 GSM 900 MHz 00000002 GSM 1800 MHz 00000004 GSM 850 MHz 00000008 GSM 1900 MHz 00000010 WCDMA 2100 MHz 00000020 WCDMA 1900 MHz 00000040 WCDMA 850 MHz 00000080 WCDMA 900 MHz 00000100 WCDMA 800 MHz 00000200 WCDMA 1700 MHz 0000FFFF Any frequency band
<ltebandval>	A hexadecimal value that specifies the LTE frequency band. If it is set to 0 or 0x40000000, it means not to change LTE frequency band. (e.g.: 0x15 = 0x1 (LTE B1) + 0x4 (LTE B3) + 0x10 (LTE B5))

	0x1 (CM_BAND_PREF_LTE_EUTRAN_BAND1)	LTE B1
	0x4 (CM_BAND_PREF_LTE_EUTRAN_BAND3)	LTE B3
	0x10 (CM_BAND_PREF_LTE_EUTRAN_BAND5)	LTE B5
	0x40 (CM_BAND_PREF_LTE_EUTRAN_BAND7)	LTE B7
	0x80 (CM_BAND_PREF_LTE_EUTRAN_BAND8)	LTE B8
	0x80000 (CM_BAND_PREF_LTE_EUTRAN_BAND20)	LTE B20
	0x7FFFFFFFFFFFFFFFFF (CM_BAND_PREF_ANY)	Any frequency band
<tdsbandval>	A hexadecimal value that specifies the TD-SCDMA frequency band. If it is set to 0 or 0x40000000, it means not to change TD-SCDMA frequency band. e.g.: 0x21 = 0x1 (TDS BCA) + 0x20 (TDS BCF)	
	0x1 (CM_BAND_PREF_TDS_BANDA)	TDS BCA
	0x2 (CM_BAND_PREF_TDS_BANDB)	TDS BCB
	0x4 (CM_BAND_PREF_TDS_BANDC)	TDS BCC
	0x8 (CM_BAND_PREF_TDS_BANDD)	TDS BCD
	0x10 (CM_BAND_PREF_TDS_BANDE)	TDS BCE
	0x20 (CM_BAND_PREF_TDS_BANDF)	TDS BCF
<effect>	Integer type. When to take effect.	
	0	Take effect after UE is rebooted
	1	Take effect immediately
<err>	Integer type. Error code. See Chapter 13 .	

Example

```

AT+QCFG="band" //Read the factory band settings and save it on host side.
+QCFG: "band",0xbff,0x1e00b0e18df,0x0

OK
AT+QCFG="band",0,1,0 //Fix module to LTE band 1, GSM/WCDMA band is not changed.
OK
AT+QCFG="band"
+QCFG: "band",0xbff,0x1,0x0

OK
AT+QCFG="band",bff,00b0e18df,0 //Restore the band back in terms of factory band settings saved
                                at beginning.

OK

```

5.5. AT+QCFG="rrc" Configure RRC Release Version

This command specifies the RRC release version.

AT+QCFG="rrc" Configure RRC Release Version	
Write Command AT+QCFG="rrc"[,<rrcr>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "rrc",<rrcr> OK If the optional parameter is specified, set the RRC release version: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<rrcr>	Integer type. RRC release version.
0	R99
1	R5
2	R6
3	R7
4	R8
5	R9
<err>	Integer type. Error code. See Chapter 13 .

5.6. AT+QCFG="msc" Configure MSC Release Version

This command specifies the UE MSC release version.

AT+QCFG="msc" Configure MSC Release Version	
Write Command AT+QCFG="msc",[,<mscr>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "msc",<mscr> OK If the optional parameter is specified, set the MSC release version: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<mscr>	Integer type. MSC release version. 0 Forces the UE to always behave as an R97/R98 mobile 1 Forces the UE to always behave as an R99 mobile 2 Causes the UE's behavior to be dynamic
<err>	Integer type. Error code. See Chapter 13 .

5.7. AT+QCFG="sgsn" Configure UE SGSN Release Version

This command specifies the UE SGSN release version. This configuration is valid only after the module is restarted.

AT+QCFG="sgsn" Configure UE SGSN Release Version	
Write Command AT+QCFG="sgsn",[,<sgsnr>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "sgsn",<sgsnr>

	OK If the optional parameter is specified, set the SGSN release version: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<sgsnr>	Integer type. SGSN release version. 0 Forces the UE to always behave as an R97/R98 mobile 1 Forces the UE to always behave as an R99 mobile <u>2</u> Causes the UE's behavior to be dynamic
<err>	Integer type. Error code. See Chapter 13 .

5.8. AT+QCFG="hsdpacat" Configure HSDPA Category

This command specifies the HSDPA category.

AT+QCFG="hsdpacat" Configure HSDPA Category	
Write Command AT+QCFG="hsdpacat"[,<HSDPA_cat>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "hsdpacat",<HSDPA_cat> OK If the optional parameter is specified, set the HSDPA category: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms

Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.
-----------------	---

Parameter

<HSDPA_cat>	Integer type. HSDPA category. 6 Category 6 8 Category 8 10 Category 10 12 Category 12 14 Category 14 18 Category 18 20 Category 20 <u>24</u> Category 24
<err>	Integer type. Error code. See Chapter 13 .

5.9. AT+QCFG="hsupacat" Configure HSUPA Category

This command specifies the HSUPA category. This configuration is valid only after the module is restarted.

AT+QCFG="hsupacat" Configure HSUPA Category	
Write Command AT+QCFG="hsupacat"[,<HSUPA_cat>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "hsupacat",<HSUPA_cat> OK If the optional parameter is specified, set the HSUPA category: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<HSUPA_cat>	Integer type. HSUPA category.
	5 Category 5
	6 Category 6
<err>	Integer type. Error code. See Chapter 13 .

5.10. AT+QCFG="pdp/duplicatechk" Establish Multi-PDN with Same APN

This command allows/refuses establishing multi-PDN with the same APN profile.

AT+QCFG="pdp/duplicatechk" Establish Multi-PDN with Same APN	
Write Command AT+QCFG="pdp/duplicatechk"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "pdp/duplicatechk",<enable> OK If the optional parameter is specified, allow/refuse establishing multi-PDN with the same APN profile: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<enable>	Integer type.
	0 Refuse to establish multi-PDN with the same APN profile
	1 Allowed to establish multi-PDN with the same APN profile
<err>	Integer type. Error code. See Chapter 13 .

5.11. AT+QCFG="disable_backoff_lte" Disable Backoff LTE

This command configures whether to disable backoff LTE when Voice/SMS is not available because of the unavailable SRLTE.

AT+QCFG="disable_backoff_lte" Disable Backoff LTE	
Write Command AT+QCFG="disable_backoff_lte"[,<value>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "disable_backoff_lte",<value> OK If the optional parameter is specified, disable backoff LTE: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<value>	Integer type. Enable/disable backoff LTE.
<u>1</u>	Enable
0	Disable

5.12. AT+QCFG="airplanecontrol" Enter/Exit Airplane Mode via W_DISABLE# Pin

This command enters or exits airplane mode via the W_DISABLE# pin and queries the current setting. If the airplane mode is enabled, the module enters the airplane mode when the pin is pulled down and enters normal mode when the pin is pulled up. Also, URC **+QIND: airplanestatus,<status>** is outputted before module entering or exiting the airplane mode.

AT+QCFG="airplanecontrol" Enter/Exit Airplane Mode via W_DISABLE# Pin	
Write Command AT+QCFG="airplanecontrol"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "airplanecontrol",<enable>,<status> OK If the optional parameter is specified, module enters/exits airplane mode via W_DISABLE# pin: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<enable>	Integer type. Whether to enable airplane mode. <u>0</u> Disable airplane mode 1 Enable airplane mode. Enter airplane mode when W_DISABLE# pin changes to active and exits airplane mode when W_DISABLE# pin changes to inactive URC +QIND: airplanestatus,<status> is reported when W_DISABLE# pin status changes. It is not allowed to exit airplane mode by AT+CFUN=1 when W_DISABLE# pin is active. 2 Enable airplane mode. Enter airplane mode when W_DISABLE# pin changes to active and exit airplane mode when W_DISABLE# pin changes to inactive URC +QIND: airplanestatus,<status> is reported when W_DISABLE# pin status changes. It is not allowed to exit airplane mode by AT+CFUN=1 or QMI when W_DISABLE# pin is active.
<status>	Integer type. Enter/exit airplane mode. <u>0</u> Exit 1 Enter

NOTE

See the corresponding hardware design of each module for more information about W_DISABLE# pin.

Example

```

AT+QCFG="airplanecontrol" //Query the current setting.
+QCFG: "airplanecontrol",0,0

OK
//Pull down W_DISABLE# pin.
AT+QCFG="airplanecontrol",1 //Enable airplane mode.
OK

+QIND: airplanestatus,1 //Enter airplane mode because W_DISABLE# pin is pulled down.

AT+CFUN? //In airplane mode.
+CFUN: 4

OK

//Pull up W_DISABLE# pin.
+QIND: airplanestatus,0 //Exit airplane mode.

AT+CFUN? //In normal mode.
+CFUN: 1

OK
//Reboot the modem.
AT+QCFG="airplanecontrol" //Query the current setting. This setting still takes effect after reboot.
+QCFG: "airplanecontrol",1,0

OK

//Pull down W_DISABLE# pin.
+QIND: airplanestatus,1 //Enter airplane mode.

AT+CFUN? //In airplane mode.
+CFUN: 4

OK

```

5.13. AT+QCFG="epcflag" Set EPC Capability Value in Attach Request

AT+QCFG="epcflag" Set EPC Capability Value in Attach Request	
Write Command AT+QCFG="epcflag",<n>	Response If the optional parameter is omitted, query the current setting: +QCFG: "epcflag",<n> OK If the optional parameter is specified, set EPC capability value in attach request: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<n>	Integer type. Value of EPC capability.
<u>0</u>	In LTE mode, set value of EPC capability in attach request information to 0
<u>1</u>	In LTE mode, set value of EPC capability in attach request information to 1

Example

```

AT+QCFG="epcflag"           //Query the value of EPC capability.
+QCFG: "epcflag",1

OK
AT+QCFG="epcflag",0         //Set value of EPC capability to 0.
OK
AT+QCFG="epcflag"
+QCFG: "epcflag",0         //Query the value of EPC capability.

OK

```

5.14. AT+QCFG="lte/bandprior" Set Searching Priority of LTE Band

AT+QCFG="lte/bandprior" Set Searching Priority of LTE Band	
Write Command AT+QCFG="lte/bandprior"[,<band1>][,<band2>][,<band3>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "lte/bandprior",<band1>[,<band2>][,<band3>] OK If any of the optional parameters is specified, set the searching priority of LTE band: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<band1>	Integer type. Band ID of the first preferred LTE band. Range: 1–43.
<band2>	Integer type. Band ID of the second preferred LTE band. Range: 1–43.
<band3>	Integer type. Band ID of the third preferred LTE band. Range: 1–43.
<err>	Integer type. Error code. See Chapter 13 .

Example

```

AT+QCFG="lte/bandprior",7,5,41 //Set searching order priority of LTE band.
OK
//Reboot the module.
AT+QCFG="lte/bandprior" //Read searching priority of LTE band.
+QCFG: "lte/bandprior",07,05,41
OK

```

5.15. AT+QCFG="plmn/addinfbdn" Add Current PLMN to FPLMN

AT+QCFG =AT+QCFG="plmn/addinfbdn" Add Current PLMN to FPLMN	
Write Command AT+QCFG="plmn/addinfbdn",[,<enable> >]	Response If the optional parameter is omitted, query the current setting: +QCFG: "plmn/addinfbdn",<enable> OK If the optional parameter is specified, add the current PLMN to FPLMN: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<enable>	Integer type. Configure whether to add the current PLMN into FPLMN event if it is in the EHPLMN. <u>0</u> Do not add 1 Add
-----------------------	--

Example

```

AT+QCFG="plmn/addinfbdn" //Query the current value.
+QCFG: "plmn/addinfbdn",0

OK
AT+QCFG="plmn/addinfbdn",1 //Add the current PLMN to FPLMN event.
OK
AT+QCFG="plmn/addinfbdn" //Query the current value.
+QCFG: "plmn/addinfbdn",1

OK

```

5.16. AT+QCFG="cops_no_mode_change" Enable/Disable the Switch under AT+COPS=1

AT+QCFG="cops_no_mode_change" Enable/Disable the Switch under AT+COPS=1	
Write Command AT+QCFG="cops_no_mode_change" [,<value>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "cops_no_mode_change",<value> OK If the optional parameter is specified, enable/disable the switch under AT+COPS=1 : OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<value>	Integer type. Enable/disable the switch under automatic mode in AT+COPS=1 (See document [1] for details about the command).
<u>1</u>	Disable
0	Enable

5.17. AT+QCFG="hplmn/search_timer" Configure HPLMN Search Interval

AT+QCFG="hplmn/search_timer" Configure HPLMN Search Interval	
Write Command AT+QCFG="hplmn/search_timer" [,<timer>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "hplmn/search_timer",<timer> OK

	If the optional parameter is specified, set HPLMN search interval: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<timer> Integer type. HPLMN search interval. Range: 1–71582. Unit: minute.

NOTE

The HPLMN search timer is started if the PLMN registered by the UE is different from HPLMN and EHPLMN.

5.18. AT+QCFG="tdd/config" Get the LTE-TDD Configuration

This command gets the LTE-TDD configuration.

AT+QCFG="tdd/config" Get the LTE-TDD Configuration	
Write Command AT+QCFG="tdd/config"	Response +QCFG: "tdd/config",<assign>,<pattern> OK
Maximum Response Time	300 ms
Characteristics	-

Parameter

<assign> Integer type. LTE-TDD subframe assignment. Range: 0–6.

<pattern> Integer type. LTE-TDD special subframe pattern. Range: 0–8.

5.19. AT+QCFG="urc_cause_support" Report Rejection Cause

This command controls whether to report the URC of the cause (ESM/EMM/CP) when the network rejects the module.

AT+QCFG="urc_cause_support" Report Rejection Cause	
Write Command AT+QCFG="urc_cause_support"[,<bit_mask_value>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urc_cause_support",<bit_mask_value> OK If the optional parameter is specified, report the rejection code: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	-

Parameter

<bit_mask_value>	Integer type. Indicate the value of the setting. Range: 0–63. 0 Do not report network rejection code. Bit 0: 0x01 namely value 1. Support ESM cause (+ESM ERROR: <cid>,<causeID>) report. Bit 1: 0x02 namely value 2. Support EMM cause report. Bit 2: 0x04 namely value 4. Support CP cause report. Bit 3: 0x08 namely value 8. Support GMM cause report. Bit 4: 0x10 namely value 16. Support MM cause report. Bit 5: 0x20 namely value 32. Support SM cause (+SM ERROR: <causeID>) report. Certain reports above-mentioned can be freely combined.
<cid>	Integer type. PDP context identifier. A numeric parameter which specifies a particular PDP context definition.
<causeID>	Integer type. Error code in integer format. For more details, please refer to Chapter 14.1 .

Example

```
AT+QCFG="urc_cause_support",63
OK
+SM ERROR: 8
+MM ERROR: 2
+GMM ERROR: 1
+CP ERROR: 96
+EMM ERROR: 15
+ESM ERROR: 1,27 // ProfileID: 1, causeID:27 - Unknown APN (Missing or unknown APN)
```

5.20. AT+QCFG="dhcppktnlfr" Filter DHCP Package

This command configures whether DHCP package is filtered.

AT+QCFG="dhcppktnlfr" Filter DHCP Package	
Write Command	Response
AT+QCFG="dhcppktnlfr"[,<disable>]	If the optional parameter is omitted, query the current setting: +QCFG: "dhcppktnlfr",<disable>
	OK
	If the optional parameter is specified, filter DHCP package: OK
	If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<disable>	Integer type.
	0 The UDP DHCP package is parsed by local stack after the module gets IP address
	1 The UDP DHCP package is shipped to the external network after the module gets IP address

Example

```

AT+QCFG="dhcppktnl" //Query the current value.
+QCFG: "dhcppktnl",0

OK
AT+QCFG="dhcppktnl",1 //Ship the UDP DHCP package to the external network after the
                        module gets IP address.

OK
AT+QCFG="dhcppktnl" //Current value is changed to 1.
+QCFG: "dhcppktnl",1

OK

```

5.21. AT+QCFG="oostimer" Set Mode for OOS Network Searching

AT+QCFG="oostimer" Set Mode for OOS Network Searching	
Write Command AT+QCFG="oostimer" [<timer1>,<timer2>,<timer3>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "oostimer",<timer1>,<timer2>,<timer3> OK If the optional parameters are specified, set the mode for OOS network searching: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<timer1>	Integer type. In OOS state, search the network 10 times with <timer1> as a cycle first. Default value: 30. Unit: second.
<timer2>	Integer type. If the network cannot be found within <timer1>, search the network 10 times with <timer2> as a cycle. Default value: 45. Unit: second.

<timer3> Integer type. If the network cannot be found within **<timer2>**, keep searching the network with **<timer3>** as a cycle. Default value: 60. Unit: second.

Example

```
AT+QCFG="oostimer",5,5,5
OK
```

5.22. AT+QCFG="apn/blocked" Configure APN Block Mode

AT+QCFG="apn/blocked" Configure APN Block Mode	
Write Command AT+QCFG="apn/blocked"[,<block_mode>,<NV_mode>]]	Response If the optional parameters are omitted, query the current setting: +QCFG:"apn/blocked",<block_mode>,<NV_mode> OK If the optional parameters are specified, configure APN block mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<block_mode> Integer type. Configure whether all the APNs blocked by the network is allowed to be written to NV.

- 0 Allowed
- 1 Not allowed

<NV_mode> Integer type.

- 0 Query all APNs that are blocked
- 1 Delete all APNs that are blocked

Example

```

AT+QCFG="apn/blocked" //Query the current setting.
+QCFG: "apn/blocked",0,0

OK
AT+QCFG="apn/blocked",0,1 //All the APNs blocked by the network are allowed to be written to
                             NV, and delete them.
OK
    
```

5.23. AT+QCFG="redir/3gtolte" Configure Redirection Mode

AT+QCFG="redir/3gtolte" Configure Redirection Mode	
Write Command AT+QCFG="redir/3gtolte"[,<redir_mode>,<NV_flag>,<NV_value>]]	Response If the optional parameter is omitted, query the current setting: +QCFG:"redir/3gtolte",<redir_mode>,<NV_flag>,<NV_value> OK If the optional parameter is specified, set redirection mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<redir_mode>	Integer type. Configure the redirection mode.	
	0	Do not allow the module to redirect LTE from 3G once it is rejected by the network when try to register LTE
	1	Allow the module to redirect LTE from 3G if it is rejected by the network when it tries to register to LTE
<NV_flag>	Integer type. EPS storage supported flag.	
	0	Not get EPS storage supported value from NV
	1	Get EPS storage supported value from NV

<NV_value>	Integer type. Indicate whether to support EPS storage.
<u>0</u>	Not support
1	Support

Example

```

AT+QCFG="redir/3gtolte"           //Query the current setting.
+QCFG: "redir/3gtolte",0,0,0

OK
AT+QCFG="redir/3gtolte",1         //Allow the module to redirect LTE from 3G.
OK

```

5.24. AT+QCFG="rssi" Configure Delta Threshold of RSSI Change

AT+QCFG="rssi" Configure Delta Threshold of RSSI Change	
Write Command AT+QCFG="rssi"[,<threshold>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "rssi",<threshold> OK If the optional parameter is specified, configure delta threshold of RSSI change: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<threshold>	Integer type. The delta threshold of RSSI change. Range: 0–20. Default value: 5. Unit: dBm.
--------------------------	---

5.25. AT+QCFG="roamservice" Configure Roaming Service

This command enables or disables the roaming service.

AT+QCFG="roamservice" Configure Roaming Service	
Write Command AT+QCFG="roamservice"[,<roam_mode>,<effect>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "roamservice",<roam_mode> OK If any of the optional parameters is specified, set the roaming service: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	<effect> determines when the command takes effect. The configuration is saved automatically.

Parameter

<roam_mode>	Integer type. The roaming service mode. 1 Disable roaming service 2 Enable roaming service <u>255</u> Auto mode
<effect>	Integer type. When the command take effect. 0 Take effect after UE reboots <u>1</u> Take effect immediately
<err>	Integer type. Error code. See Chapter 13 .

5.26. AT+QCFG="fast_dormancy" Dynamically Control the RRC Connection

This command dynamically controls the RRC connection under WCDMA network.

AT+QCFG="fast_dormancy" Dynamically Control the RRC Connection	
Write Command AT+QCFG="fast_dormancy"[, <op>[,<duration>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "fast_dormancy",<op>[,<duration>] OK If any of the optional parameters is specified, dynamically control the RRC connection: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. Whether to save the parameter configuration is determined by <op>.

Parameter

<op>	Integer type. <u>0</u> Disable the feature of fast dormancy 1 Query whether there is data in the period of <duration>; If not, disconnect RRC automatically 2 Disconnect RRC immediately 3 If the network support T323 timer, query if there is data in the period of T323 timer; If not, disconnect RRC automatically
<duration>	Integer type. Only valid when <op> is 1. Range: 1–65535. Default value: 5. Unit: second.

5.27. AT+QCFG="airplane" Configure Airplane Mode

AT+QCFG="airplane" Configure Airplane Mode	
Write Command AT+QCFG="airplane",<n>	Response If the optional parameter is omitted, query the current setting:

	+QCFG: "airplane",<n> OK If the optional parameter is specified, set the airplane mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<n>	Integer type. Airplane mode.
0	Use default setting at EFS file
1	Force to enter airplane mode
2	Force to exit airplane mode

Example

```

AT+QCFG="airplane"           //Query the current setting.
+QCFG: "airplane",0

OK
AT+QCFG="airplane",1         //Force to enter airplane mode.
OK
//Reboot the modem.
AT+QCFG="airplane"           //It is forced to enter airplane mode.
+QCFG: "airplane",1

OK
  
```

5.28. AT+QCFG="rrc/control" Configure the Feature of RRC Connection Control

AT+QCFG="rrc/control" Configure the Feature of RRC Connection Control	
Write Command AT+QCFG="rrc/control" [<enable>,<ccrc>,<trrc>,<wait_time>,<bar_opt>,<conn_est_latency>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "rrc/control",<enable>,<ccrc>,<trrc>,<wait_time>,<bar_opt>,<conn_est_latency> OK If the optional parameters are specified, set the feature of RRC connection control: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable/disable RRC connection control. 0 Disable 1 Enable
<ccrc>	Integer type. Counter to track number of RRC connection failures. Range: 0–60. Default value: 0.
<trrc>	Integer type. Amount of time the serving cell is barred after <ccrc> occurs. Range: 0–60. Default value: 0.
<wait_time>	Integer type. The waiting time to add the cell blacklist after RRC failure. Range: 0–300. Default value: 0.
<bar_opt>	Integer type. Enable/disable barring optimization. 0 Disable 1 Enable
<conn_est_latency>	Integer type. The delay time to start a new RRC connection establishment procedure. Range: 0-60. Default value: 0.

NOTE

The cause of the random-access failure reported by the RRC to the NAS layer is fixed into LTE RRC `CONN_EST_FAILURE_CONN_REJECT` when the barring optimization is enabled with the remaining time. Remaining time = `<wait_time>` - elapsed time from the first RRC connection failure, unless it is configured with `<conn_est_latency>` by the OEM.

5.29. AT+QCFG="nwscanmodeex" Configure Network Searching Mode

AT+QCFG="nwscanmodeex" Configure Network Searching Mode

Write Command AT+QCFG="nwscanmodeex"[,<mode>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "nwscanmodeex",<mode> OK If the optional parameter is specified, set the network searching mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<mode> Integer type. Network searching mode. Range: 0–63. Default value: 63.

NOTE

When Bit 0 to Bit 5 are all set to 1, it corresponds to `<scan_mode>=0` in `AT+QCFG="nwscanmode"`.

- Bit 0: CDMA2000 1X
- Bit 1: CDMA2000 HRPD (1xEVDO)
- Bit 2: GSM
- Bit 3: WCDMA
- Bit 4: LTE

Bit 5: TD-SCDMA

For example, to configure network searching mode to LTE only, it indicates to set **<mode>** to 16, corresponding to 0001 0000 in hex.

Example

AT+QCFG="nwscanmodeex",28 //In hex, 28 is 0001 1100. Configure network searching mode to GSM, WCDMA, LTE.

OK

AT+QCFG="nwscanmodeex" //Query the current setting.

+QCFG: "nwscanmode",28

OK

5.30. AT+QCFG="assign_plmn_in_limit_search" Specify Operator for Camping on a Cell with Limited Service

The command specifies an operator for the module to camp on a cell with limited service when no (U)SIM card is inserted.

AT+QCFG="assign_plmn_in_limit_search" Specify Operator for Camping on a Cell with Limited Service

Write Command

AT+QCFG="assign_plmn_in_limit_search"
[,<enable>[,<plmn>]]

Response

If the optional parameters are omitted, query the current setting:

+QCFG: "assign_plmn_in_limit_search",<enable>,<plmn>

OK

If any of the optional parameters is specified, enable/disable specifying an operator for the module to camp on a cell with limit service when no (U)SIM card is inserted:

OK

If there is any error:

ERROR

Maximum Response Time

300 ms

Characteristic

The command takes effect after the module is rebooted

or **AT+CFUN=0/1**.
The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable/disable the feature of specifying an operator for the module to camp on a cell with limit service when no (U)SIM card is inserted. 0 Disable 1 Enable
<plmn>	String type. Operator code. For example, "46000" indicates China Mobile.

Example

```

AT+QCFG="assign_plmn_in_limit_search",1,"46000" //Specify China Mobile.
OK
AT+QCFG="assign_plmn_in_limit_search"           //Query current setting.
+QCFG: "assign_plmn_in_limit_search",1,46000

OK
AT+QCFG="assign_plmn_in_limit_search",0         //Disable the feature of specifying an operator
                                                for the module to camp on a cell with limit
                                                service when no (U)SIM card is inserted.

OK

```

5.31. AT+QCFG="iprulectl" Configure the Gateway Address Generation Rule

The command configures the gateway address generation rule when the module is used as a network card.

AT+QCFG="iprulectl" Configure the Gateway Address Generation Rule

Write Command AT+QCFG="iprulectl"[,<type>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "iprulectl",<type> OK If the optional parameter is specified, set the gateway address generation rule: OK
--	--

	If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately (The client needs re-connecting). The configuration is saved automatically.

Parameter

<type>	Integer type. Gateway address generation rule.
<u>0</u>	If the IP address is an odd integer, the gateway address is IP address plus 1. If the IP address is an even integer, the gateway address is IP address minus 1
1	The gateway address is equal to IP address minus 1

Example

```
AT+QCFG="iprulectl"
```

```
+QCFG: "iprulectl",0
```

```
OK
```

```
AT+QCFG="iprulectl",1
```

```
OK
```

5.32. AT+QCFG="disrplmn" Configure RPLMN and RPLMNACT for Network Searching

This command enables or disables RPLMN and RPLMNACT when searching network.

AT+QCFG="disrplmn" Configure RPLMN and RPLMNACT for Network Searching	
Write Command	Response
AT+QCFG="disrplmn"[,<RPLMN_disable>[,<RPLMNACT_disable>]]	If the optional parameters are omitted, query the current setting: +QCFG: "disrplmn",<RPLMN_disable>,<RPLMNACT_disable> e>
	OK
	If any of the optional parameters is specified, enable or disable RPLMN and RPLMNACT when searching network: OK

	If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristic	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<RPLMN_disable>	Integer type. Enable or disable RPLMN when searching network. <u>0</u> Enable RPLMN when searching network 1 Disable RPLMN when searching network
<RPLMNACT_disable>	Integer type. Enable or disable RPLMNACT when searching network. <u>0</u> Enable RPLMNACT when searching network 1 Disable RPLMNACT when searching network
<err>	Integer type. Error code. See Chapter 13 .

NOTE

Only the following Write Commands are valid:

- **AT+QCFG="disrplmn",0** Enable RPLMN and RPLMNACT when searching network
- **AT+QCFG="disrplmn",1** Disable RPLMN and RPLMNACT when searching network
- **AT+QCFG="disrplmn",0,1** Enable RPLMN and disable RPLMNACT when searching network

Example

```

AT+QCFG="disrplmn",1 //Disable RPLMN and RPLMNACT when searching network.
OK
AT+QCFG="disrplmn"
+QCFG: "disrplmn",1,1

OK
AT+QCFG="disrplmn",0 //Enable RPLMN and RPLMNACT when searching network.
OK
AT+QCFG="disrplmn"
+QCFG: "disrplmn",0,0

OK
AT+QCFG="disrplmn",0,1 //Enable RPLMN and disable RPLMNACT when searching network.
OK
AT+QCFG="disrplmn"

```

```
+QCFG: "disrplmn",0,1
```

```
OK
```

5.33. AT+QCFG="lte/preferfre" Set Preferred Frequency

This command sets preferred frequency for searching network.

AT+QCFG="lte/preferfre" Set Preferred Frequency

Write Command

```
AT+QCFG="lte/preferfre"[,<op>,<index>,<band>,<bandwidth>,<earfcn>,<mcc>,<mnc>]
```

Response

If the optional parameters are omitted, query the current setting:

```
[+QCFG: "lte/preferfre",<index>,<band>,<bandwidth>,<earfcn>,<mcc>,<mnc>]
```

OK

If the optional parameters are specified, set preferred frequency for searching network:

OK

If there is any error:

ERROR

Maximum Response Time

250 ms

Characteristic

The command takes effect after the module is rebooted.
The configurations are saved automatically.

Parameter

<op>	Integer type. Operation type.
	0 Add a preferred frequency 1 Delete a preferred frequency
<index>	Integer type. Preferred frequency index. Range: 1–10.
<band>	Integer type. Band index. Range: 0–41, 60–62.
	0 Band 1
	1 Band 2
	2 Band 3
	...
	41 Band 42
	60 Band 125
	61 Band 126
	62 Band 127

<bandwith>	Integer type. Reserved. Always be 101.
<earfcn>	Integer type. Frequency point.
<mcc>	Integer type. Mobile country code.
<mnc>	Integer type. Mobile network code.

Example

```
AT+QCFG="lte/preferfre",1,1,6,101,2452,460,03 //Delete the preferred frequency with index 1.
```

OK

```
AT+QCFG="lte/preferfre"
```

OK

5.34. AT+QCFG="cops_control" Enable/Disable Configurations of AT+COPS

This command enables or disables the configurations of **AT+COPS**.

AT+QCFG="cops_control" Enable/Disable Configurations of AT+COPS	
Write Command AT+QCFG="cops_control",<enable>	Response If the optional parameter is omitted, query the current setting: +QCFG: "cops_control",<enable> OK If the optional parameter is specified, enable/disable the configurations of AT+COPS: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect immediately. The configuration is not saved into NVRAM.

Parameter

<enable>	Integer type. Enable/disable the configurations of AT+COPS .
0	Disable

1 Enable

Examples

```
AT+QCFG="cops_control",1 //Enable the configurations of AT+COPS.
```

OK

```
AT+QCFG="cops_control"
```

```
+QCFG: "cops_control",1
```

OK

5.35. AT+QCFG="map_rej_cause7_to_cause14" Enable/Disable Network Rejection Cause Mapping

This command enables or disables network rejection cause mapping. When using roaming card, **GPRS NOT ALLOWED** is returned under the roaming network. After receiving the rejection code, the module marks the roaming card as PS INVALID, and stops searching PLMN. This command controls whether to modify REJECT CAUSE 7 to REJECT CAUSE 14 to make the module search PLMN continuously after receiving the rejection code.

AT+QCFG="map_rej_cause7_to_cause14" Enable/Disable Network Rejection Cause Mapping

Read command

```
AT+QCFG="map_rej_cause7_to_cause14",<flag>
```

Response

If the optional parameter is omitted, query the current setting:

```
+QCFG: "map_rej_cause7_to_cause14",<flag>
```

OK

If the optional parameter is specified, enable/disable network rejection cause mapping:

OK

If there is any error:

ERROR

Maximum Response Time

250 ms

Characteristic

The command takes effect after the module is rebooted.
The configuration is saved automatically.

Parameter

<flag>	Integer type. Enable/Disable network rejection cause mapping.
	0 Disable
	1 Enable

Example

```

AT+QCFG="map_rej_cause7_to_cause14"           //Query the current setting.
+QCFG: "map_rej_cause7_to_cause14",0

OK
AT+QCFG="map_rej_cause7_to_cause14",1         //Enable network rejection cause mapping.
OK

```

5.36. AT+QCFG="netmaskset" Enable/Disable Customized Netmask

This command enables or disables customer to set the netmask.

AT+QCFG="netmaskset" Enable/Disable Customized Netmask	
Write Command AT+QCFG="netmaskset"[,<enable> >[,<netmask>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "netmaskset",<enable> OK If any of the optional parameters is specified, enable or disable customized netmask: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect after reconnecting the network card. The configuration is saved automatically.

Parameter

<enable>	Integer type. Enable/ disable customized netmask.
	0 Disable. Netmask is set by the rule inside the module
	1 Enable. Netmask is set by <netmask>

<netmask> String type. Customized netmask. Only valid when **<enable>=1**.
For example: "192.0.2.2".

Example

```
AT+QCFG="netmaskset"           //Query whether customized netmask is enabled.
+QCFG: "netmaskset",0          //Customized netmask is disabled.

OK

AT+QCFG="netmaskset",1,"192.0.2.2" //Enable customized netmask and set netmask.
OK
AT+QCFG="netmaskset"
+QCFG: "netmaskset",1

OK
AT+QCFG="netmaskset",0          //Disable customized netmask and set netmask.
OK
```

5.37. AT+QCFG="pingdiscard" Configure Whether to Discard Ping Packet

This command configures whether to discard the Ping packet.

AT+QCFG="pingdiscard" Configure Whether to Discard Ping Packet

Write Command AT+QCFG="pingdiscard"[,<en>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "pingdiscard",<en> OK If the optional parameter is specified, configure whether to discard the Ping packet: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect immediately. The configuration is not saved.

Parameter

<en>	Integer type. Whether to discard Ping packet.
<u>0</u>	Do not discard
<u>1</u>	Discard Ping echo request packet sent from network

5.38. AT+QCFG="urc/ri/restart" Configure RI Pulse Timer

This command enables or disables restarting RI pulse timer when a new URC is reported but the last URC RI pulse is finished.

AT+QCFG="urc/ri/restart" Configure RI Pulse Timer	
Write Command AT+QCFG="urc/ri/restart"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urc/ri/restart",<enable> OK If the optional parameter is specified, configure RI pulse timer: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configuration is not saved.

Parameter

<enable>	Integer type. Enable/disable restarting RI pulse timer when a new URC is reported but the last URC RI pulse is finished.
<u>0</u>	Disable
<u>1</u>	Enable

Example

```
AT+QCFG="urc/ri/restart" //Query the current setting.
+QCFG: "urc/ri/restart",1

OK
```

```
AT+QCFG="urc/ri/restart",1 //Enable restarting RI pulse timer when a new URC is reported but
                             the last URC RI pulse is finished.
OK
```

5.39. AT+QCFG="ping/ri" Configure Ping Detection Function

This command configures Ping detection function.

AT+QCFG="ping/ri" Configure Ping Detection Function	
Writer Command AT+QCFG="ping/ri"[,<enable>[,<mode>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "ping/ri",<enable>,<mode> OK If any of the optional parameters is specified, configure Ping detection function: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable/disable Ping detection function. The value occupies one byte. <u>0</u> Disable 1 Enable
<mode>	Integer type. Reporting mode if Ping packet is detected. The value occupies one byte. <u>0</u> Report URC ping/ri 1 Pull RI pin without reporting URC

Example

```
AT+QCFG="ping/ri" //Query the current setting.
+QCFG: "ping/ri",0,0
OK
```

```
AT+QCFG="ping/ri",1,0 //Enable Ping detection and set reporting URC if Ping packet is detected.
OK
AT+QCFG="ping/ri"
+QCFG: "ping/ri",1,0
OK
```

5.40. AT+QCFG="defaultdns" Configure Default DNS for PDP Context

This command configures the default DNS for PDP context.

AT+QCFG="defaultdns" Configure Default DNS for PDP Context

Write Command

```
AT+QCFG="defaultdns"[,<enable>[
,<dns1>[,<dns2>]]]
```

Response

If the optional parameters are omitted, query the current setting:

```
+QCFG: "defaultdns",<enable>,<dns1>,<dns2>
```

OK

If **<enable>** is specified to 0, disable configuring default DNS for PDP context:

OK

If **<enable>** is specified to 1 and other optional parameters are omitted, set primary DNS to "8.8.8.8" and ignore secondary DNS:

OK

If only **<enable>** and **<dns1>** are specified, configure primary DNS, and set the secondary DNS to "8.8.8.8":

OK

If the optional parameters are specified, set default DNS for PDP context:

OK

If there is any error:

ERROR

Maximum Response Time

300 ms

Characteristic

The command takes effect immediately.
The configurations are not saved.

Parameter

<enable>	Integer type. Enable/disable configuring default DNS for PDP context. 0 Disable 1 Enable
<dns1>	String type. Customized primary DNS. For example: "192.0.2.2".
<dns2>	String type. Customized secondary DNS. For example: "192.0.2.2".

Example

```

AT+QCFG="defaultdns"
+QCFG: "defaultdns",0,"192.0.2.2","192.0.2.2"

OK
AT+QCFG="defaultdns",1
OK
AT+QCFG="defaultdns"
+QCFG: "defaultdns",1,"8.8.8.8","192.0.2.2"

OK
AT+QCFG="defaultdns",1,"192.0.2.0"
OK
AT+QCFG="defaultdns"
+QCFG: "defaultdns",1,"192.0.2.0","8.8.8.8"

OK
AT+QCFG="defaultdns",1,"192.0.2.2","192.0.2.0"
OK
AT+QCFG="defaultdns"
+QCFG: "defaultdns",1,"192.0.2.2","192.0.2.0"

OK
AT+QCFG="defaultdns",0
OK

```

5.41. AT+QCFG="lpm/dataind" Configure Wake-up Mechanism

This command configures wake-up mechanism.

AT+QCFG="lpm/dataind" Configure Wake-up Mechanism

Write Command

AT+QCFG="lpm/dataind"[,<enable>,<

Response

If the optional parameters are enabled, query the current

mask>]	setting: +QCFG: "lpm/dataind",<enable>,<mask> OK If the optional parameters are specified, configure wake-up mechanism: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable/disable the wake-up mechanism. The value occupies one byte. <u>0</u> Disable 1 Enable
<mask>	Integer type. Wake-up trigger mask. The value occupies one byte. If the corresponding bit is set to 1, the module is woken up when SCLK/DTR/USB receives data. Bit0 1 indicates detecting SLCK. If it is TRUE, wakes up the module <u>0</u> indicates ignoring SLCK Bit1 1 indicates detecting DTR. If it is TRUE, wakes up the module <u>0</u> indicates ignoring DTR Bit2 1 indicates detecting USB. If it is TRUE, wakes up the module <u>0</u> indicates ignoring USB Bit3–Bit7 Reserved. Always be 0

Example

```

AT+QCFG="lpm/dataind"
+QCFG: "lpm/dataind",0,0

OK
AT+QCFG="lpm/dataind",1,0
OK
AT+QCFG="lpm/dataind"
+QCFG: "lpm/dataind",1,0

OK

```

5.42. AT+QCFG="roamserviceex" Control Relevant Functions in Roaming State

AT+QCFG="roamserviceex" Control Relevant Functions in Roaming State	
Write Command AT+QCFG="roamserviceex"[,<roammode>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "roamserviceex",<roammode> OK If the optional parameter is specified, control the relevant functions in roaming state: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<roammode>	Integer type. Each bit corresponds to a feature. Set the bit to 1 indicates disabling the corresponding function. Range: 0–3. Default value: 0.
Bit 1	Disable dial-up Internet access function when UE is in roaming state
Bit 2	Disable voice call function when UE is in roaming state

Example

```

AT+QCFG="roamserviceex",1 //Disable dial-up internet access when UE is in roaming mode.
OK
AT+QCFG="roamserviceex"
+QCFG: "roamserviceex",1

OK
AT+QCFG="roamserviceex",2 //Disable voice call when UE is in roaming mode.
OK
AT+QCFG="roamserviceex"
+QCFG: "roamserviceex",2

```

OK

5.43. AT+QCFG="nwscanseq" Configure RATs Searching Sequence

This command configures the searching sequence of RATs or queries the current setting.

AT+QCFG="nwscanseq" Configure RATs Searching Sequence

Write Command AT+QCFG="nwscanseq"[,<scanseq>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "nwscanseq",<scanseq> OK If the optional parameter is specified, configure the RATs searching sequence: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristic	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<scanseq>	Integer type. RATs searching sequence. E.g., 0102030405 stands for GSM → TDS → WCDMA → LTE → CDMA. Default value: 0403010502. 00 Automatic 01 GSM 02 TDS 03 WCDMA 04 LTE 05 CDMA
<effect>	Integer type. When the command takes effect. 0 The command takes effect after UE reboots 1 The command takes effect immediately. (Not supported currently.)
<err>	Integer type. Error code. See Chapter 13 .

NOTE

The value of **<effect>** parameter can only be set to 0. It is not recommended to specify the **<effect>** parameter when Write Command is executed.

Example

```
AT+QCFG="nwscanseq",0403020105 //Set RATs searching sequence as LTE → WCDMA →
                                TDS → GSM → CDMA.

OK
//Reboot the module.

AT+QCFG="nwscanseq" //Read RATs searching sequence.
+QCFG: "nwscanseq",0403020105

OK
```

5.44. AT+QCFG="eps_only_creg_real" Configure CS Registration Reporting Mode in EPS-only Scenario

This command configures the CS registration reporting mode in EPS-only scenario or queries the current setting.

AT+QCFG="eps_only_creg_real" Configure CS Registration Reporting Mode in EPS-only Scenario

Write Command	Response
AT+QCFG="eps_only_creg_real"[,<mode>]	If the optional parameter is omitted, query the current setting: +QCFG: "eps_only_creg_real",<mode>
	OK
	If the optional parameter is specified, configure the EPS only CS registration report mode: OK
	If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms

Characteristic

The command takes effect immediately.
The configuration is saved automatically.

Parameter

<mode>

Integer type. CS registration reporting mode in EPS-only scenario.

0 After **AT+CFUN=0** or **AT+CFUN=1** is executed, the module forces the reported CS registration status to registered in EPS-only scenarios.

1 After **AT+CFUN=0** or **AT+CFUN=1** is executed, the module reports the actual CS registration status. If CS service is unavailable, the status will be reported as not registered.

<err>

Integer type. Error code. See **Chapter 13**.

Example

```
AT+QCFG="eps_only_creg_real",0
```

```
OK
```

```
AT+CFUN=0
```

```
OK
```

```
AT+CFUN=1
```

```
OK
```

```
AT+CREG?
```

```
+CREG: 1,1
```

```
OK
```

```
AT+QCFG="eps_only_creg_real",1
```

```
OK
```

```
AT+CFUN=0
```

```
OK
```

```
AT+CFUN=1
```

```
OK
```

```
AT+CREG?
```

```
+CREG: 1,0
```

```
OK
```

6 PS Commands

6.1. AT+QCFG="ntp" Specify the Maximum Re-transmission Counts and the Interval for NTP

The command specifies the maximum re-transmission times and the interval of NTP.

AT+QCFG="ntp" Specify the Maximum Re-transmission Counts and the Interval for NTP

Write Command AT+QCFG="ntp",<cnt>,<interval>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "ntp",<cnt>,<interval> OK If the optional parameters are not omitted, specify the maximum re-transmission counts and the interval for NTP: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configurations are saved automatically.

Parameter

<cnt>	Integer type. NTP re-transmission counts. Range: 1–10. Default value: 3.
<interval>	Integer type. NTP re-transmissions interval. Range: 5–60. Default value: 15.

Example

AT+QCFG="ntp" //Query the current setting.

```
+QCFG: "ntp",3,15

OK
AT+QCFG="ntp",5,20 //Set NTP re-transmission counts and interval.
OK
AT+QCFG="ntp"
+QCFG: "ntp",5,20 //Query the current setting.

OK
```

6.2. AT+QCFG="TCP/SendMode" Configure TCP Sending Mode

This command configures TCP sending mode.

AT+QCFG="TCP/SendMode" Configure TCP Sending Mode

Write Command	Response
AT+QCFG="TCP/SendMode"[,<mode>]	If optional parameter is omitted, query the current setting: +QCFG: "TCP/SendMode",<mode> OK If the optional parameter is specified, configure TCP sending mode: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configuration is not saved.

Parameter

<mode>	Integer type. Determine when to send SEND OK. <u>0</u> SEND OK is sent immediately after TCP socket sends data from serial port 1 SEND OK is sent after receiving an ACK from the remote TCP socket 2 <SocketID>,SEND OK is sent after receiving an ACK from the remote TCP socket
<err>	Integer type. Error code. See Chapter 13 .

Example

```
AT+QCFG="TCP/SendMode"
+QCFG: "TCP/SendMode",0

OK
AT+QCFG="TCP/SendMode",1
OK
```

6.3. AT+QCFG="tcp/windowsize" Configure TCP Window Available Size

This command configures the available size of TCP window when sending/receiving data.

AT+QCFG="tcp/windowsize" Configure TCP Window Available Size	
Write Command AT+QCFG="tcp/windowsize",<buffer>[,<window_size>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "tcp/windowsize",<buffer>,<window_size> OK If the optional parameter is specified, configure TCP window available size: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configurations are not saved.

Parameter

<buffer>	Integer type. Set the receiving and sending buffer sizes. 0 Receiving buffer size 1 Sending buffer size
<window_size>	Integer type. TCP window available size. Range: 16–100. Default value: 16.
<err>	Integer type. Error code. See Chapter 13 .

7 CS Commands

7.1. AT+QCFG="amrcodec" Configure AMR Codec

This command configures the bandwidth, rate, and byte alignment of the voice codec AMR in different network states. Parameter can be multi-selected (calculate incoming parameters with &).

AT+QCFG="amrcodec" Configure AMR Codec	
Write Command AT+QCFG="amrcodec"[,<preference>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "amrcodec",<preference> OK If the optional parameter is specified, configure AMR codec: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<preference>	Integer type. Configure AMR codec in ORed. e.g. 7 = 1 + 2 + 4 means GSM AMR NB & GSM AMR WB & GSM HR AMR.
0	No AMR configuration
1	GSM AMR NB
2	GSM AMR WB
4	GSM HR AMR
8	WCDMA AMR WB
16	IMS AMR WB (Mode Set)
32	IMS AMR WB (Octet aligned mode)

63 All above six AMR configurations
 64 Reserved
 128 Reserved

Example

```
AT+QCFG="AMRCODEC"
```

```
+QCFG: "amrcodec",5
```

OK

```
AT+QCFG="amrcodec",63
```

OK

```
AT+QCFG="amrcodec"
```

```
+QCFG: "amrcodec",63
```

OK

NOTE

The default value of **<preference>** varies between different modules.

7.2. AT+QCFG="frhrcodec" Configure GSM EFR/HR/FR Codec

This command configures GSM EFR/HR/FR codec.

AT+QCFG="frhrcodec" Configure GSM EFR/HR/FR Codec

Write Command

```
AT+QCFG="frhrcodec"[,<preference>]
```

Response

If the optional parameter is omitted, query the current setting:

```
+QCFG: "frhrcodec",<preference>
```

OK

If the optional parameter is specified, configure GSM EFR/HR/FR codec:

OK

If there is any error:

ERROR

Maximum Response Time

300 ms

Characteristic

The command takes effect after the module is rebooted.
The configuration is saved automatically.

Parameter

<preference>	Integer type. Configure GSM EFR/HR/FR codec in ORed. e.g. 7 = 1 + 2 + 4, means GSM EFR/HR/FR are selected. Default value: 7.
0	No codec configuration
1	GSM FR
2	GSM HR
4	GSM EFR

Example

```
AT+QCFG="frhrcodec"
+QCFG: "frhrcodec",7

OK
AT+QCFG="frhrcodec",3
OK
AT+QCFG="frhrcodec"
+QCFG: "frhrcodec",3

OK
```

7.3. AT+QCFG="bip/auth" Configure PDP Authentication Type in BIP Process

This command configures PDP authentication type in BIP data transmission process.

AT+QCFG= bip/auth" Configure PDP Authentication Type in BIP Process

Write Command

AT+QCFG="bip/auth"[,<n>]

Response

If the optional parameter is omitted, query the current setting:
+QCFG: "bip/auth",<n>

OK

If the optional parameter is specified, set the type of PDP authentication in the BIP process:

OK

	If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect immediately. The configuration is saved automatically.

Parameter

<n>	Integer type. PDP authentication type.
0	No PDP authentication
1	PAP
2	CHAP

NOTE

1. PDP in BIP process generally does not require authentication.
2. Currently this command is only supported for IDEMIA operator.

Example

```

AT+QCFG="bip/auth"
+QCFG: "bip/auth",0
OK
AT+QCFG="bip/auth",1 //Set PDP authentication type as PAP in the BIP process.
OK
AT+QCFG="bip/auth"
+QCFG: "bip/auth",1
OK

```

7.4. AT+QCFG="SMS/ListMsgMap" List Message Map

This command lists the message map with **<msgtype>** in the storage **<mem1>** specified by **AT+CPMS**. See **document [1]** for details about the command.

AT+QCFG="SMS/ListMsgMap" List Message Map	
Write Command AT+QCFG="SMS/ListMsgMap",<msg type>	Response +QCFG: "SMS/ListMsgMap",<msgtype>,<msgmap>

	OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristic	-

Parameter

<msgtype>	String type. Message type. "REC UNREAD" Received unread messages "REC READ" Received read messages "STO UNSENT" Stored unsent messages "STO SENT" Stored sent messages
<msgmap>	String type. Bit map of total messages in the storage specified by <mem1> of AT+CPMS . If the bit is 1, it means the message is on the type specified by <msgtype> . If the bit is 0, it means the message is not on the type specified by <msgtype> ; The position of the bit in bit map specified by <msgtype> indicates the message index in the storage specified by <mem1> of AT+CPMS .
<err>	Integer type. Error code. See Chapter 13 .

Example

AT+CPMS?

+CPMS: 24,40,24,40,24,40

OK

AT+QCFG="sms/listmsgmap","REC UNREAD" //List the received unread message map.

+QCFG: "sms/listmsgmap","REC UNREAD","000F5B0000"

OK

7.5. AT+QCFG="ims/ut" Enable/Disable IMS/UT Function

This command configures IMS/UT function.

AT+QCFG="ims/ut" Enable/Disable IMS/UT Function	
Write Command	Response

AT+QCFG="ims/ut"[,<n>]	If the optional parameter is omitted, query the current setting: +QCFG: "ims/ut",<n>,<ICS>,<USSD> OK If the optional parameter is specified, enable/disable the IMS/UT Function: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristic	This command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<n>	Integer type. Enable/disable IMS/UT function. 0 Disable 1 Enable
<ICS>	Integer type. Supplementary service over LTE state is available or not. 0 Unavailable 1 Available
<USSD>	Integer type. USSD over LTE state is available or not. 0 Unavailable 1 Available
<err>	Integer type. Error code. See Chapter 13 .

NOTE

1. UT is a sub function of IMS function. UT is running over IMS, and IMS is running over LTE.
2. If IMS/UT function is disabled, <ICS> MUST be 0 and supplementary service (eg: CCFC/CCWA) over LTE is unavailable and use CSFB instead.

Example

```

AT+QCFG="ims/ut"
+QCFG: "ims/ut",1,1,0 //UT is enabled, Supplementary service over LTE is available, and USSD over
                        LTE is unavailable.

OK
AT+QCFG="ims/ut",0 //Disable IMS/UT function and supplementary service uses CSFB.

```

```
OK
AT+QCFG="ims/ut"
+QCFG: "ims/ut",0,0,0
OK
```

7.6. AT+QCFG="ims" Configure IMS Function

This command configures IMS function.

AT+QCFG="ims" Configure IMS Function	
Write Command AT+QCFG="ims",<ims_conf>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "ims",<ims_conf>,<volte_cap> OK If the optional parameter is specified, configure IMS function: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristic	This command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<ims_conf>	Integer type. Configure IMS function. 0 Do not configure IMS. The default setting at MBN file is used 1 Forcedly enable IMS function 2 Forcedly disable IMS function
<volte_cap>	Integer type. Enabled/disable VoLTE. 0 Disable 1 Enable

Example

```
AT+QCFG="ims"
+QCFG: "ims",0,0

OK
AT+QCFG="ims",1
OK
AT+QCFG="ims"
+QCFG: "ims",1,1

OK
```

7.7. AT+QCFG="ltesms/format" Set SMS Format in LTE Mode

This command sets the SMS format in LTE mode.

AT+QCFG="ltesms/format" Set SMS Format in LTE Mode	
Write Command AT+QCFG="ltesms/format"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "ltesms/format",<n> OK If the optional parameter is specified, set SMS format in LTE mode: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristic	The command takes effect immediately. The configuration is not saved.

Parameter

<n>	Integer type. SMS format in LTE mode. For EC21-V and EC25-V modules, the default value is 0; for other modules, the default value is 1.
0	CDMA format
1	GSM format

<err> Integer type. Error code. See **Chapter 13**.

Example

```

AT+CMGF=1
OK
AT+QCFG="ltesms/format",0           //Set CDMA format for SMS in LTE mode.
OK
AT+CMGS="15021012496"               //Send CDMA format SMS in LTE mode.
> This is a test from Quectel
+CMGS: 24

OK
AT+QCFG="ltesms/format",1           //Set GSM format for SMS in LTE mode.
OK
AT+CMGS="15021012496"               //Send GSM format SMS in LTE mode.
> This is a test from Quectel
+CMGS: 25

OK

```

7.8. AT+QCFG="volte_disable" Enable/Disable VoLTE

This command enables or disables VoLTE.

AT+QCFG="volte_disable" Enable/Disable VoLTE	
Write Command AT+QCFG="volte_disable"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "volte_disable",<n> OK If the optional parameter is specified, enable/disable VoLTE function: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<n>	Integer type. Enable/disable VoLTE.
0	Enable
1	Disable

Example

```
AT+QCFG="volte_disable"
+QCFG: "volte_disable",0

OK
AT+QCFG="volte_disable",1 //VoLTE is disabled.
OK
```

7.9. AT+QCFG="sms/omadm" Set OMADM Message Parsing Mode

This command sets OMADM message parsing mode.

AT+QCFG="sms/omadm" Set OMADM Message Parsing Mode	
Write Command AT+QCFG="sms/omadm"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "sms/omadm",<n> OK If the optional parameter is specified, set the OMADM message parsing mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristic	This command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<n>	Integer type. OMADM message parsing mode.
0	OMADM short message is parsed
1	OMADM short message is not parsed

Example

```

AT+QCFG="sms/omadm"           //Query the current setting.
+QCFG: "sms/omadm",0

OK

AT+QCFG="sms/omadm",1         //Set the value of OMADM SMS to 1.
OK
AT+QCFG="sms/omadm"
+QCFG: "sms/omadm",0

OK

```

7.10. AT+QCFG="imsreg/iptype" Configure the IP Type for IMS Registration

This command configures the IP type for IMS registration.

AT+QCFG="imsreg/iptype" Configure the IP Type for IMS Registration	
Write Command AT+QCFG="imsreg/iptype"[,<n>]	Response If the optional parameter is omitted, query the current configuration: +QCFG: "imsreg/iptype",<n> OK If the optional parameter is specified, set the IP type for IMS registration: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<n>	Integer type. Configure IP type for IMS registration.
0	IPv4

Example

```

AT+QCFG="imsreg/iptype"
+QCFG: "imsreg/iptype",0           //The current configuration is IPv4.

OK
AT+QCFG="imsreg/iptype",1         //Configure the IP type when IMS registering to IPv6.
OK
AT+QCFG="imsreg/iptype"
+QCFG: "imsreg/iptype",1

OK
    
```

7.11. AT+QCFG="sim/recovery" Configure (U)SIM Card Hot-plug

This command configures (U)SIM card hot-plug.

AT+QCFG="sim/recovery" Configure (U)SIM Card Hot-plug	
Write Command AT+QCFG="sim/recovery"[,<recovery_count>,<auto_detect_period>,<auto_detect_count>]	Response If the optional parameters are omitted, query the current configuration: +QCFG: "sim/recovery",<recovery_count>,<auto_detect_period>,<auto_detect_count> OK If the optional parameters are specified, configure (U)SIM card hot-plug: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<recovery_count>	Integer type. The number of times to resend an APDU immediately after sending an APDU to receive an error response.
<auto_detect_period>	Integer type. Automatic detection cycle. Unit: second.
<auto_detect_count>	Integer type. The number of times of automatic detection.
<err>	Integer type. Error code. See Chapter 13 .

NOTE

This command is a software hot-plug implementation, which corresponds to the hardware hot-plug implementation through **AT+QSIMDET**.

Example

```
AT+QCFG="sim/recovery"
+QCFG: "sim/recovery",3,0,0           //The feature of software hot-plug is disabled.

OK
```

7.12. AT+QCFG="siminvalirecovery" Enable/Disable Re-attach Request

This command enables/disables re-attach request after (U)SIM card attachment failure.

AT+QCFG="siminvalirecovery" Enable/Disable Re-attach Request	
Write Command AT+QCFG="siminvalirecovery"[,<enable>,<timer>,<counter>]	Response If the optional parameters are omitted, query the current configuration: +QCFG: "siminvalirecovery",<enable>,<timer>,<counter> OK If the optional parameters are specified, enable/disable re-attach request after (U)SIM card attachment failure: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable/disable re-attach request. 1 Enable 0 Disable
<timer>	Integer type. Time interval between two attach requests. Unit: s. Range: 1–60. Default value: 5. This parameter is only valid when <enable> =1.
<counter>	Integer type. The maximum number of attaching request. Range: 1–255. Default value: 5. When the value is 255, it indicates unlimited number of attaching requests.

NOTE

An invalid (U)SIM card is required when testing this command.

Example

```
AT+QCFG="siminvalirecovery"
+QCFG: "siminvalirecovery",208,0,72
OK
```

7.13. AT+QCFG="roaming/voicecall" Enable/Disable Voice Call in Roaming Mode

This command enables/disables the feature of voice call in roaming mode.

AT+QCFG="roaming/voicecall" Enable/Disable Voice Call in Roaming Mode

Write Command AT+QCFG="roaming/voicecall"[,<voicecall_mode>]	Response If the optional parameter is omitted, query the current configuration: +QCFG: "roaming/voicecall",<voicecall_mode> OK If the optional parameter is specified, enable/disable the feature of voice call in roaming mode: OK If there is any error: ERROR
--	---

Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<voicecall_mode>	Integer type. Enable/disable the feature of Voice Call when UE is in the roaming mode.
0	Enable
1	Disable

7.14. AT+QCFG="voice_busytone" Control Busy Tone Playback

When the module registers on the MCC/MNC (311/480) network, and initiates a call to peer, but the peer hangs up the call caused by on call, busy tone will appear. This command controls busy tone playback.

AT+QCFG="voice_busytone" Control Busy Tone Playback

Write Command AT+QCFG="voice_busytone"[,<mode>]	Response If the optional parameter is omitted, query the current configuration: +QCFG: "voice_busytone",<mode> OK If the optional parameter is specified, control busy tone playback: OK If there is any error: ERROR
Maximum Response Time	250 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<mode>	Integer type. Enable/disable busy tone playback.
0	Disable
1	Enable

NOTE

1. Busy tone control is enabled by default if the module registers on the MCC/MNC (311/480) network. Disable this function through **AT+QCFG="voice_busytone",0**.
2. If this function has not been configured by the module through Write Command before, **ERROR** will be returned by Read Command.

Example

```

AT+QCFG=?                                //Return the supported parameter range.
...
+QCFG: "voice_busytone",(0,1)
...

OK
AT+QCFG="voice_busytone"                  //Query the current setting.
+QCFG: "voice_busytone",0

OK
AT+QCFG="voice_busytone",1                //Enable busy tone playback.
OK
    
```

7.15. AT+QCFG="call_control" Enable/Disable Module Voice Call Feature

This command enables/disables MO and MT voice call feature of the module.

AT+QCFG="call_control" Enable/Disable Module Voice Call Feature

Write Command	Response
AT+QCFG="call_control"[,<disableMO>,<disableMT>]	If the optional parameters are omitted, query the current configuration: +QCFG: "call_control",<disableMO>,<disableMT>
	OK
	If the optional parameter is specified, enable/disable MO and MT voice call feature of the module: OK
	If there is any error:

	ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<disableMO>	Integer type. Indicate whether to disable MO voice call feature. <u>0</u> Do not disable 1 Disable
<disableMT>	Integer type. Indicate whether to disable MT voice call feature. <u>0</u> Do not disable 1 Disable

Example

AT+QCFG=?

...

+QCFG: "call_control",(0,1),(0,1)

...

OK

AT+QCFG="call_control"

+QCFG: "call_control",0,0

OK

ATD10086; //Make a MO voice call.

OK

ATH

OK

AT+QCFG="call_control",1,0

OK

ATD10086; //Failed to make a MO voice call.

ERROR

8 PPP Command

8.1. AT+QCFG="ppp/termframe" Enable/Disable the PPP TERM Frame Sending

This command enables/disables the PPP TERM frame sending when PPP is hung up by module itself.

AT+QCFG="ppp/termframe" Enable/Disable the PPP TERM Frame Sending

Write Command AT+QCFG="ppp/termframe"[,<flag>]	Response If the optional parameter is omitted, query the current configuration: +QCFG: "ppp/termframe",<flag> OK If the configuration parameter is specified, enable/disable the PPP TERM frame sending: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<flag>	Integer type. Enable/disable TERM frame sending when hang up PPP by module itself. 0 Disable 1 Enable
<err>	Integer type. Error code. See Chapter 13 .

NOTE

If **AT+QPPPDROP** hangs up PPP with TERM frame, module will send TERM frame to MCU no matter whether **<flag>** is 0 or 1.

Example

```
AT+QCFG="ppp/termframe",1
```

```
OK
```

```
AT+QCFG="ppp/termframe"
```

```
+QCFG: "ppp/termframe",1
```

```
OK
```

9 USB Commands

9.1. AT+QCFG="usbnet" Configure the Network Card Type Interface

This command configures the network card type interface.

AT+QCFG ="usbnet" Configure the Network Card Type Interface	
Write Command AT+QCFG="usbnet"[,<net>]	Response If the optional parameter is omitted, query the current configuration: +QCFG: "usbnet",<net> OK If the configuration parameter is specified, set the network card type interface: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<net>	Integer type. Network card type interface.
	0 RmNet interface
	1 ECM interface
	2 MBIM interface
	3 RNIDS interface
<err>	Integer type. Error code. See Chapter 13 .

9.2. AT+QCFG="usbcfg" Configure VID, PID and Porting Settings

The command configures VID, PID and porting settings for the module.

AT+QCFG="usbcfg" Configure VID, PID and Porting Settings	
Write Command AT+QCFG="usbcfg" [<vid>,<pid>,<diag>,<nmea>,<at_port>,<modem>,<rmnet>,<adb>,<uac>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "usbcfg",<vid>,<pid>,<diag>,<nmea>,<at_port>,<modem>,<rmnet>,<adb>,<uac> OK If the optional parameters are specified, configure VID, PID and porting settings: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<vid>	Integer type. Vendor ID of USB device. The maximum value is 65535.
<pid>	Integer type. Product ID of USB device. The maximum value is 65535.
<diag>	Integer type. Status of USB DIAG port. 0 Disable <u>1</u> Enable
<nmea>	Integer type. Status of USB NMEA port. 0 Disable <u>1</u> Enable
<at_port>	Integer type. Status of USB AT port. 0 Disable <u>1</u> Enable
<modem>	Integer type. Status of USB Modem port. 0 Disable <u>1</u> Enable
<rmnet>	Integer type. Status of USB net device. 0 Disable <u>1</u> Enable

<adb>	Integer type. Status of USB ADB device.
<u>0</u>	Disable
<u>1</u>	Enable
<uac>	Integer type. UAC status.
<u>0</u>	Disable
<u>1</u>	Enable

Example

```

AT+QCFG="usbcfg",0x2C7C,0x0125,1,1,1,1,1,0,0
OK
AT+QCFG="usbcfg"
+QCFG: "usbcfg",0x2C7C,0x125,1,1,1,1,1,0,0
OK

```

9.3. AT+QCFG="usbee" Control the USB Device Loading

The command controls whether USB device loading needs to wait for modem to start.

AT+QCFG="usbee" Control the USB Device Loading	
Write Command AT+QCFG= "usbee"[,<enable>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "usbee",<enable> OK If the optional parameter is specified, control whether USB device loading needs to wait for modem to start: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<enable>	Integer type.
	0 The USB device loading not need to wait for Modem to start
	1 The USB device loading need to wait for Modem to start

9.4. AT+QCFG="usbmode" Get USB Mode

This command queries USB mode or enables/disables the module to automatically report URCs about bus mode change.

AT+QCFG="usbmode" Get USB Mode	
Write Command AT+QCFG="usbmode"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "usbmode",<n>,<state> OK If the optional parameter is specified, query USB mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<n>	Integer type. Enable/disable to automatically report URCs about USB mode change.
	0 Disable
	1 Enable
<state>	String type. Indicate the USB mode.
	"SUSPEND"
	"CONFIGURED"
	"DISCONNECTED"
	"CONNECTED"
	"UNKNOWN"

NOTE

1. When **<n>=1**, URCs can be reported to UART1.
2. Only when **<state>="CONFIGURED"**, data can be transferred via USB.
3. Only when VBUS of USB PHY is connected (such as charger), **<state>** can be switched to "CONNECTED".

Example

```
AT+QCFG="usbmode"
+QCFG: "usbmode",0,"SUSPEND"

OK
AT+QCFG="usbmode",1           //Set <n> to 1 for report URCs about bus mode change.

OK
+QCFG: "usbmode",1,"CONFIGURED" //The URC about USB mode "CONFIGURED".
```

9.5. AT+QCFG="spi/set" Configure SPI or UART Driver

AT+QCFG="spi/set" Configure SPI or UART Driver

Read command AT+QCFG="spi/set"[,<flag>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "spi/set",<flag> OK If the optional parameter is specified, set SPI or UART driver: OK If there is any error: ERROR
Maximum Response Time	250 ms
Characteristics	This command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<flag>	Integer type. Configure pin feature.
0	Configure pin as general GPIO
1	Initialize pin as uart6
2	initialize pin as spi6

Example

```

AT+QCFG=?           //Query the range of this command.
....
+QCFG: "spi/set",(0-2)

OK
AT+QCFG="spi/set",1 //Initialized pins as uart6.
OK
AT+QCFG="spi/set"   //Query the current setting.
+QCFG: "spi/set",1

OK

```

9.6. AT+QCFG="usbenum/seoctl" Enable Optimization of USB Enumeration Failure

AT+QCFG="usbenum/seoctl" Enable Optimization of USB Enumeration Failure

Write Command	Response
AT+QCFG="usbenum/seoctl"[,<enable>]	If the optional parameter is omitted, query the current setting: +QCFG: "usbenum/seoctl",<enable> OK If the optional parameter is specified, enable optimization of USB enumeration failure: OK If there is any error: ERROR
Maximum Response Time	300 ms

Characteristics

This command takes effect after the module is rebooted.
The configuration is saved automatically.

Parameter

<enable> Integer type. Indicate whether to enable optimizing USB enumeration failure.
0 Disable
 1 Enable

Example

```
AT+QCFG=? //Test command.
...
+QCFG: "usbnum/seoctl",(0,1)
...

OK
AT+QCFG="usbnum/seoctl",1 //Enable optimizing USB enumeration failure.
OK
AT+QCFG="usbnum/seoctl" //Query the current setting.
+QCFG: "usbnum/seoctl",1
OK
```

10 CDMA Commands

10.1. AT+QCFG="cdma/pppauth" Set PPP Authentication Optimization under CDMA

This command enables/disables the PPP authentication optimization under CDMA.

AT+QCFG="cdma/pppauth" Set PPP Authentication Optimization under CDMA	
Write Command AT+QCFG="cdma/pppauth"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "cdma/pppauth",<n> OK If the optional parameter is specified, enable/disable the PPP authentication optimization under CDMA: OK If there is any error: ERROR Or +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<n>	Integer type. Whether to enable the PPP authentication optimization under CDMA. 0 Disable 1 Enable
<err>	Integer type. Error code. See Chapter 13 .

Example

```
AT+QCFG="cdma/pppauth"
+QCFG: "cdma/pppauth",0    //The PPP authentication optimization is disabled by default.

OK
AT+QCFG="cdma/pppauth",1  //Enable the PPP authentication optimization under CDMA.
OK
AT+QCFG="cdma/pppauth"
+QCFG: "cdma/pppauth",1

OK
```

10.2. AT+QCFG="ehrpd" Configure CDMA Mode

This command configures the CDMA network mode which the module expects to use.

AT+QCFG="ehrpd" Configure CDMA Mode	
Write Command AT+QCFG="ehrpd"[,<mode>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "ehrpd",<mode> OK If the optional parameter is specified, set the CDMA mode: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<mode>	Integer type. Configure the network mode.
0	HDRSCP_REV0_PROTOCOLS_ONLY
1	HDRSCP_REVA_PROTOCOLS_WITH_MFPA
2	HDRSCP_REVA_PROTOCOLS_WITH_MFPA_AND_EMPA
3	HDRSCP_REVB_PROTOCOLS_WITH_MMPA
4	HDRSCP_REVA_PROTOCOLS_WITH_EHRPD

- | | |
|---|---|
| 5 | HDRSCP_REVB_PROTOCOLS_WITH_EHRPD |
| 6 | HDRSCP_REVA_PROTOCOLS_WITH_EHRPD_AND_IRAT |
| 7 | HDRSCP_REVB_PROTOCOLS_WITH_EHRPD_AND_IRAT |

NOTE

If this NV is not set, the module will use HDRSCP_REVA_PROTOCOLS_WITH_MFPA by default.

Example

```

AT+QCFG="ehrpd"           //Query the current network mode.
+QCFG: "ehrpd",2

OK

AT+QCFG="ehrpd",2         //Configure the network mode.
OK
    
```

10.3. AT+QCFG="cdmasms/cmtformat" Set CMT Format of CDMA SMS PDU

This command sets CMT format of CDMA SMS PDU.

AT+QCFG ="cdmasms/cmtformat" Set CMT Format of CDMA SMS PDU

Write Command	Response
AT+QCFG="cdmasms/cmtformat" [<n>]	If the optional parameter is omitted, query the current setting: +QCFG: "cdmasms/cmtformat",<n> OK If the optional parameter is specified, set CMT format of CDMA SMS PDU: OK If there is any error: ERROR Or +CME ERROR:<err>
Maximum Response Time	300 ms

Characteristics

The command takes effect after the module is rebooted.
The configuration is saved automatically.

Parameter

<n> Integer type. CMT format of CDMA SMS PDU.
0 CDMA
1 GSM
<err> Integer type. Error code. See **Chapter 13**.

Example

```
AT+CMGF=0
OK
AT+CNMI=2,2 //Show CDMA SMS content directly and not store it.
OK
AT+QCFG="cdmasms/cmtformat",0 //Set CDMA format.
OK

//Receive a new CDMA SMS
^HCMT: ,46
0000021002020702C6155968C69C0601FC081B00031D2B8001061022E831258003061610102128230
801000A0100
AT+QCFG="cdmasms/cmtformat",1 //Set GSM format.
OK

//Receive a new CDMA SMS.
+CMT: ,24
00000B818155563001F700006101011282320004AE207109
```

11 SMS Commands

11.1. AT+QCFG="urcport/sms" Set URC Output Port of Short Message

This command sets URC output port of short message.

AT+QCFG="urcport/sms" Set URC Output Port of Short Message	
Write Command AT+QCFG="urcport/sms"[,<n>]	Response If the optional parameter is omitted, query the current setting: +QCFG: "urcport/sms" OK If the optional parameter is specified, set URC output port of short message: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<n>	Integer type. URC output port of short message.
<u>0</u>	Using default URC output port
<u>1</u>	Set URC output port of short message as "uart2"

NOTE

Use **AT+QDIAGPORT=1** to configure debug UART port as AT port and restart module. See *document [1]* for details about the command.

Example

```

AT+QDIAGPORT=1           //Configure debug UART port as AT port.
OK

//Restart module

AT+QURCCFG="urcport","uart1" //Configuration of URC output port is "uart1".
OK
AT+QCFG="urcport/sms"
+QCFG: "urcport/sms",0     //Query URC output port of short message.

OK
AT+QCFG="urcport/sms",1    //Set URC output port of short message as "uart2".
OK
AT+QCFG="urcport/sms"
+QCFG: "urcport/sms",1     //Query URC output port of short message as "uart2".

OK

```

11.2. AT+QCFG="sms_retry" Configure SMS Retry Period and Interval

This command configures SMS retry period and interval.

AT+QCFG="sms_retry" Configure SMS Retry Period and Interval	
Write Command AT+QCFG="sms_retry"[,<interval>[,<period>]]	Response If the optional parameters are omitted, query the current setting: +QCFG: "sms_retry",<interval>,<period> OK If any of the optional parameters is specified, configure SMS retry period and interval: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<interval>	Integer type. SMS retry interval. Range: 0–255. Unit: second.
<period>	Integer type. SMS retry period. Range: 0–255. Unit: second.

NOTE

If <period> is set to 0, SMS will not retry when an error occurs.

Example

```

AT+QCFG=?
...
+QCFG: "sms_retry",(0-255),(0-255)
...

OK
AT+QCFG="sms_retry"
+QCFG: "sms_retry",45,180

OK
AT+QCFG="sms_retry",5
OK
AT+QCFG="sms_retry"
+QCFG: "sms_retry",5,180

OK
AT+QCFG="sms_retry",5,30
OK

AT+QCFG="sms_retry"
+QCFG: "sms_retry",5,30

OK

```

11.3. AT+QCFG="sms_control" Enable/Disable Delivering or Submitting SMS

This command enables/disables delivering or submitting SMS.

AT+QCFG="sms_control" Enable/Disable Delivering or Submitting SMS	
Write Command AT+QCFG="sms_control"[,<submit>,<deliver>]	Response If the optional parameters are omitted, query the current setting: +QCFG: "sms_control",<submit>,<deliver> OK If the optional parameters are specified, enable/disable delivering or submitting SMS: OK If there is any error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<submit>	Integer Type. Enable/disable submitting SMS.
0	Disable
<u>1</u>	Enable
<deliver>	Integer Type. Enable/disable delivering SMS.
0	Disable
<u>1</u>	Enable

NOTE

1. After disabling sending SMS, **AT+CMGS/AT+CMSS** will return an error. See *document [1]* for details about the two commands.
2. This command takes effect in both 3GPP and 3GPP2 messages.

Example

```
AT+QCFG="sms_control"           //Query SMS control configuration.
+QCFG: "sms_control",1,1

OK
AT+QCFG="sms_control",0,1       //Disable submitting SMS.
OK
AT+CMGS="17301836745"
+CMS ERROR: 302                 //The operation is not allowed.
AT+QCFG="sms_control",0,0       //Disable sending and receiving SMS.
OK
```

12 Appendix References

Table 3: Related Document

Document Name
[1] Quectel_EC2x&EG2x&EG9x&EM05_Series_AT_Commands_Manual
[2] Quectel_EC2x&EG2x&EG9x_Series_Power_Back-off_Application_Note
[3] Quectel_EC2x&EG2x&EG9x&EM05_Series_Software_Thermal_Management_Guide

Table 4: Terms and Abbreviations

Abbreviation	Description
3GPP	3rd Generation Partnership Project
AMR	Adaptive Multi-Rate
AP	Application Processor
APDU	Application Protocol Data Unit
APN	Access Point Name
BIP	Bearer Independent Protocol
CDMA	Code Division Multiple Access
CHAP	Challenge-Handshake Authentication Protocol
CP	Control Plane
CS	Circuit Switching
CSFB	Circuit Switched Fallback
DHCP	Dynamic Host Configuration Protocol

EFR	Enhanced Full Rate Speech Encoding
EFS	Embedded File System
EPC	Evolved Packet Core
ESM	EPS Session Management
ETWS	Earthquake and Tsunami Warning System
FPLMN	Forbidden Public Land Mobile Network
GPRS	General Packet Radio Service
GSM	Global System for Mobile Communications
HPLMN	Home Public Land Mobile Network
HSDPA	High Speed Downlink Packet Access
HSUPA	High Speed Uplink Packet Access
LTE	Long-Term Evolution
MCC/MNC	Mobile Country Code
ME	Mobile Equipment
MNC	Mobile Network Code
MO	Mobile Originated
MS	Mobile Station
MSC	Microsoft Snap-In Control
MT	Mobile Terminated
NTP	Network Time Protocol
NVRAM	Non-Volatile Random Access Memory
OEM	Original Equipment Manufacturer
OMADM	Open Mobile Alliance Device Management
PAP	Password Authentication Protocol
PCM	Pulse Code Modulation

PDN	Packet Data Network
PDP	Packet Data Protocol
PDU	Packet Data Unit
PLMN	Public Land Mobile Network
PPP	Point to Point Protocol
PS	Packet Switching
QMI	Qualcomm Message Interface
RAT	Radio Access Technology
RRC	Radio Resource Control
SAR	Specific Absorption Rate
SGSN	Serving GPRS Support Node
SMS	Short Message Service
SRLTE	Single Radio LTE
TA	Terminal Adapter
TCP	Transmission Control Protocol
TDD	Time Division Duplex
UDP	User Datagram Protocol
UE	User Equipment
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code
USB	Universal Serial Bus
(U)SIM	(Universal) Subscriber Identity Module
VID	Vendor ID
VoLTE	Voice (voice calls) over LTE
WCDMA	Wideband Code Division Multiple Access

13 Appendix Summary of <err> Code

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code shall be returned.

<err> values are mostly used by common message commands. The following table lists most of general and GRPS related **ERROR** codes. For some GSM protocol failure cause described in GSM specifications, the corresponding **ERROR** codes are not included.

Table 5: Different Coding Schemes of +CME ERROR: <err>

Code of <err>	Meaning
0	Phone failure
1	No connection to phone
2	Phone-adaptor link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy

15	SIM wrong
16	Incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	Memory full
21	Invalid index
22	Not found
23	Memory failure
24	Text string too long
25	Invalid characters in text string
26	Dial string too long
27	Invalid characters in dial string
30	No network service
31	Network timeout
32	Network not allowed - emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	Service provider personalization PIN required
45	Service provider personalization PUK required
46	Corporate personalization PIN required
47	Corporate personalization PUK required
901	Audio unknown error
902	Audio invalid parameters

903	Audio operation not supported
904	Audio device busy

14 Appendix List of Cause

14.1. Release Cause Text List of AT+QCFG="urc_cause_support"

Table 6: List of ESM Cause

Code of <causeID>	Text
8	Operator determined barring
26	Insufficient resources
27	Missing or unknown APN
28	Unknown PDP address or PDP type
29	User authentication failed
30	Activation rejected by Servicing GW or PDN GW
31	Activation rejected, unspecified
32	Service option not supported
33	Requested service option not specified
34	Service option temporarily out of order
35	PTI already in use
36	Regular deactivation
37	QoS not accepted
38	Network failure
39	Reactivation required
40	Feature not supported

41	Semantic error in the TFT operation
42	Syntactical error in the TFT operation
43	Unknown EPS bearer context
44	Semantic errors in packet filter
45	Syntactical errors in packet filter
46	Bearer context without TFT already active
47	PTI mismatch
49	PDN disconnected, not allowed
50	PDN type IPV4 only allowed
51	PDN type IPV6 only allowed
52	Single ADR bearers only allowed
53	ESM info not received
54	PDN connection does not exist
55	Multiple PDN connection for given APN not allowed
56	Collision with network init request
59	Unsupported QCI value
66	APN not supported in PLMN rat combination
81	Invalid PTI value
95	Semantically invalid message
96	Invalid mandatory information
97	Message non-existent/not implemented
98	Message type not compatible with state
99	Info element non-existent
100	Conditional IE error
101	Message type not compatible with state

111	Protocol error, unspecified
112	APN restrict value incompatible with ACT context
113	No failure

NOTE

The ESM cause information element is coded as shown in Figure 9.9.4.4.1 and Table 9.9.4.4.1 in TS24.301.

Table 7: List of EMM Cause

Code of <causeID>	Text
2	IMSI unknown in HSS
3	Illegal UE
5	IMEI not accepted
6	Illegal ME
7	EPS services not allowed
8	EPS services and non-EPS services not allowed
9	UE identity cannot be derived by the network
10	Implicitly detached
11	PLMN not allowed
12	Tracking area not allowed
13	Roaming not allowed in this tracking area
14	EPS services not allowed in this PLMN
15	No suitable cells in tracking area
16	MSC temporarily not reachable
17	Network failure
18	CS domain not available

19	ESM failure
20	MAC failure
21	Synch failure
22	Congestion
23	UE security capabilities mismatch
24	Security mode reject unspecified
25	Not authorized for this CSG
26	No EPS auth unacceptable
38	CS fallback call est not allowed
39	CS domain temp not available
40	No EPS bearer context activated
42	Severe network failure
95	Semantically incorrect msg
96	Invalid mandatory info
97	Non-existent msg type
98	Msg type incompatible with protocol state
99	Non-existent info
100	Conditional IE error
101	Msg incompatible with protocol state
111	Protocol error unspecified
256	No failure

NOTE

The EMM cause information element is coded as shown in Figure 9.9.3.9.1 and Table 9.9.3.9.1 in TS24.301.

Table 8: List of MO SMS CP Cause

Code of <causeID>	Text	Description
96	invalid mandatory information	MO/MT/SMMA/CP error

NOTE

GSM/WCDMA-specific Relay Protocol (RP) cause types. Refer to *TS 24.011*, Section 8.2.5.

Table 9: List of GMM Cause

Code of <causeID>	Text
1	No cause information available
2	IMSI unknown in HLR
3	Illegal MS
4	IMSI unknown in VLR
5	IMEI not accepted
6	Illegal ME
7	GPRS services not allowed
8	GPRS & non GPRS services not allowed
9	MS identity cannot be derived by the network
10	Implicitly detached
11	PLMN not allowed
12	Location area not allowed
13	Roaming not allowed in this location area
14	GPRS services not allowed in this PLMN
15	No suitable cells in location area
16	MSC temporarily not reachable

17	Network failure
20	MAC failure
21	Synch failure
22	Congestion
23	GSM authentication unacceptable
25	CSG not authorized
32	Service option not supported
33	Requested service option not subscribed
34	Service option temporarily out of order
38	Call cannot be identified
40	No PDP context activated
48-63	Retry upon entry into a new cell
95	Semantically incorrect message
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message type not compatible with the protocol state
99	Information element non-existent or not implemented
100	Conditional IE error
101	Message not compatible with the protocol state
111	Protocol error, unspecified

NOTE

The causes above are referenced from Table 10.5.147/3GPP TS 24.008: GMM cause information element.

Table 10: List of MM Cause

Code of <causeID>	Text
2	IMSI unknown in HLR
3	Illegal MS
4	IMSI unknown in VLR
5	IMEI not accepted
6	Illegal ME
7	GPRS services not allowed
8	GPRS services and non-GPRS services not allowed
9	MS identity cannot be derived by the network
10	Implicitly detached
11	PLMN not allowed
12	Location area not allowed
13	Roaming not allowed in this location area
14	GPRS services not allowed in this PLMN
15	No suitable cells in location area
16	MSC temporarily not reachable
17	Network failure
20	MAC failure
21	Synch failure
22	Congestion
23	GSM authentication unacceptable
25	Not authorized for this CSG
32	Service option not supported
33	Requested service option not subscribed

34	Service option temporarily out of order
38	Call cannot be identified
40	No PDP context activated
48-63	Retry upon entry into a new cell
95	Semantically incorrect message
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message type not compatible with protocol state
99	Information element non-existent or not implemented
100	Conditional IE error
101	Message not compatible with protocol state
111	Protocol error, unspecified

NOTE

The MM cause information element is coded as shown in Figure 4.4.4 in *TS24.008*.

Table 11: List of SM Cause

Code of <causeID>	Text
8	Operator Determined Barring
24	MBMS bearer capabilities insufficient for the service
25	LLC or SMDCP failure
26	Insufficient resources
27	Missing or unknown APN
28	Unknown PDP address or PDP type
29	User authentication failed

30	Activation rejected by GGSN
31	Activation rejected, unspecified
32	Service option not supported
33	Service option not subscribed
34	Service option temporarily out of order
35	NSAPI already used
36	Regular deactivation
37	QoS not accepted
38	Network failure
39	Reactivation required
40	Feature not supported
41	Semantic error in the TFT operation
42	Syntactical error in the TFT operation
43	Unknown PDP context
44	Semantic error in the packet filter
45	Syntactical error in the packet filter
46	PDP context without TFT already activated
47	MBMS group membership timeout
48	Activation rejected, BCM violation
50	PDP type IPv4 only allowed
51	PDP type IPv6 only allowed
52	Single address bearers only allowed
81	Invalid transaction identifier value
95	Semantically incorrect message
96	Invalid mandatory information

97	Message type non-existent or not implemented
98	Message type not compatible with the protocol state
99	Information element non-existent or not implemented
100	Conditional IE error
101	Message not compatible with the protocol state
111	Protocol error, unspecified
112	APN type conflict

NOTE

The causes above are referenced from Table 10.5.157/3GPP TS 24.008: SM cause information element.