

Broadcast GPS position every 60 s

Node already on **LONG_MODERATE**, role **CLIENT**, region **US**, primary channel sharing location. Setting names in English, with the Spanish label underneath.

1 Open the Position screen

Settings (*Ajustes*) > **Device configuration** (*Configuración del dispositivo*) > **Position** (*Posición*)

Not *Module configuration* — that one holds MQTT, Telemetry and the rest of the modules.

2 Change these three

CARD	SETTING	DEFAULT	SET TO
Position Packet <i>Paquetes de posición</i>	Broadcast Interval <i>Intervalo de transmisión</i>	15 minutes	1 minute
Position Packet	Smart Position <i>Ubicación inteligente</i>	ON	OFF
Device GPS <i>Dispositivo GPS</i>	GPS Polling Interval	2 minutes	40 seconds

All three are dropdowns or switches — nothing is typed in. Then tap **Save**: the node reboots and Bluetooth drops for a few seconds. Nothing applies until you save.

3 Watch for these while setting it

- Broadcast Interval** has no free-text field. Pick **1 minute** from the list (Unset, 1 minute, 90 seconds, 5 minutes, 15 minutes...).
- Smart Position off is confirmed** when the *Smart Interval* and *Smart Distance* fields disappear. If they are still there, the switch did not turn off.
- GPS Polling Interval has no 30 s option** — the list is 8 s, 20 s, **40 s**, 1 minute, 80 s, 2 minutes... Never go below 10 s: that keeps the GPS powered on permanently.
- Reopen **Position** after the reboot and confirm it still reads **1 minute**. That is the value the node actually accepted.

4 Verify

- Outdoors, wait for the first fix: **1 to 5 minutes** cold start. No fix means nothing is sent.
- Nodes** tab: the **last heard** counter must reset **every ~60 s**.
- Connect the app to **another node** and check it there too — that proves the LoRa path, not just Bluetooth.

TWO FIRMWARE RULES THAT OVERRIDE YOUR 60 S — SILENTLY

Channel utilisation gate: with the Client role, position packets are dropped while channel utilisation is $\geq 25\%$ (Tracker roles get 40%).

Node-count scaling: above 40 online nodes the interval is stretched automatically — on LONG_MODERATE, 50 nodes ≈ 158 s and 60 nodes ≈ 257 s.

Each packet holds the channel 1.5–2 s on this preset, so one node alone sits near 2–3 % utilisation continuously. Use 60 s only on the node you are actively tracking; 120–300 s otherwise.

To revert: Broadcast Interval back to 15 minutes, Smart Position back ON. Paths, labels and dropdown values verified against the Meshtastic Android app source and firmware.