Deployment instructions for VSE-IoTCore Adapter 0.8.2

Deployment On Arm

- SSH Log in must be available
- The last artifacts are to be found in gitlab, next to the pipeline, you need the artifacts for ARM
- Download the ZIP Archive and expand it on your local computer
- Open SSH session to the target and copy the contents of the expanded folder to

```
~/usr/local/bin/vse-iotcore-adapter
```

- Navigate to ~/usr/local/bin and execute

```
sudo chmod +x vse1xx-iotcore-adapter-process
```

- Excute the process by invoiking

```
./vse1xx-iotcore-adapter-process --vse-ip <DEVICE-IP> --iotcore-uri http://<RPI-IP>:<RPI-PORT>
```

For the available parameters, invoke the executable without any parameters

Deployment On Linux

Refer to the above section

Deployment On Windows

- The last artifacts are to be found in gitlab, next to the pipeline, you need the artifacts for Windows
- Download the artifacts and extract them in a folder of your choice
- Navigate to *binaries/winx64* in this folder and from there you can start the executable *vse-iotcore-adapter-process*

```
vse1xx-iotcore-adapter-process --vse-ip <DEVICE-IP> --iotcore-uri http://<RPI-IP>:<RPI-PORT>
```

For the available parameters, invoke the executable without any parameters

Logging configuration

There are two files included, which configure the logging for the adapter components:

- log4net.adapter.config
- log4net.driver.config

Those are configuring the logging for the adapter and for the VSE Communication driver respectively. For more information how to reconfigure them, check:

- https://logging.apache.org/log4net/release/manual/configuration.html
- https://blog.elmah.io/log4net-tutorial-the-complete-guide-for-beginners-and-pros/ in the section *Commonly used appenders*

Please note, that not all appenders are supported on each target. Also, it is (currently) not possible to log from both components to the same file. The only possibility is to log to the console, if you want to get an unified log.