


Fault Code: 339 (Aftermarket and OEM)

Idle Shutdown Vehicle Accessories Relay Driver Circuit - Voltage Below Normal or Shorted to Low Source

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 339 PID(P): SPN: FMI: Lamp: SRT:	Idle Shutdown Vehicle Accessories Relay Driver Circuit - Voltage Below Normal or Shorted to Low Source. Less than 6 VDC detected at the ignition bus relay output circuit when high voltage was expected by the ICON™ idle control module.	The ICON™ system will be disabled. Only mandatory shutdown will be enabled. Engine can be started normally. Constant power will be at the keyswitch ignition circuit.



Circuit Description

The ignition bus relay controls ignition circuits powering the heating/air conditioning controls and other equipment connected to the ignition bus relay 1 and ignition bus relay 2. These relays are controlled by the ignition relay positive (+) signal from the ICON™ B connector pin 4. The

above circuit diagram can vary, such as connector or pins, depending on the vehicle make or model. OEM installations can possibly provide the harnessing between the idle control module and other ICON™ devices.

Component Location

The ignition bus relay is typically located under the dash inside the vehicle cab. The ICON™ module can be located in a different location depending on the vehicle application.

Shoptalk

This fault typically indicates a short circuit to ground or an open circuit from the ICON™ idle control module B connector pin 4, ignition relay positive (+). Ignition relay positive (+) (pin 4) outputs 12 VDC to open the ignition bus 1 and 2 relays when the ICON™ system has powered down the vehicle and needs to disconnect power going to the cab circuit. The ignition bus 1 and 2 relays are normally closed when no power is applied.

The ICON™ system can display **only** the present active fault code. If more than one fault code is active at the same time, the ICON system flashes out the highest priority fault. After the fault has been corrected then the next active fault will be flashed out.

Note: The ICON™ electronic service tool can display more than one active and or inactive fault codes at the same time.

Warnings and Cautions

⚠ CAUTION ⚠

To reduce the possibility of damaging a new ICON™ idle control module, all other active fault codes must be investigated prior to replacing the ICON™ idle control module.

⚠ CAUTION ⚠

To reduce the possibility of pin and harness damage, use the following test leads when taking a measurement:

Part Number 3822758 - male Deutsch/AMP/Metri-Pack test lead

Part Number 3822917 - female Deutsch/AMP/Metri-Pack test lead.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Read the fault codes.	

STEPS		SPECIFICATIONS
	STEP 1A. Read the fault codes with the ICON™ electronic service tool or by using the fault flashout feature.	Fault Code 339 inactive
STEP 2.	Check the ignition bus relay.	
	STEP 2A. Inspect the ignition bus relay(s) pins.	No damaged pins
	STEP 2B. Check the ignition bus relay coil resistance.	70 to 100 ohms
STEP 3.	Check the ICON™ harnesses.	
	STEP 3A. Inspect the ICON™ engine harness, cab harness, and ICON™ idle control module connector pins.	No damaged pins
	STEP 3B. Check the complete harness for a short circuit from pin to pin.	More than 100k ohms
	STEP 3B-1. Identify whether the ICON™ system is an Aftermarket.	ICON™ system is Aftermarket
	STEP 3B-2. Check the cab harness for a short circuit from pin to pin.	More than 100k ohms
	STEP 3C. Check the complete harness for a short circuit to ground.	More than 100k ohms
	STEP 3C-1. Identify whether the ICON™ system is an Aftermarket.	ICON™ system is Aftermarket
	STEP 3C-2. Check the cab harness for a short circuit to ground.	More than 100k ohms
STEP 4.	Clear the fault code.	
	STEP 4A. Disable the fault code.	Fault Code 339 cleared

STEP 1. Read the fault codes.

STEP 1A. Read the fault codes with the ICON™ electronic service tool or by using the fault flashout feature.

Conditions :

- Connect all components.
- Turn keyswitch ON.
- Connect the ICON™ electronic service tool.

Action	Specification/Repair	Next Step
Check the ignition bus relay with the service tool. With the keyswitch ON, initiate the Ignition Bus Relay Test button and determine if the relay will turn the fans OFF.	Fault Code 339 inactive. Refer to Inactive or Intermittent Fault Codes, Procedure 019-362 (/qs3/pubsys2/xml/en/procedures/99/99-019-362.html).	4A
		2A

STEP 2. Check the ignition bus relay.

STEP 2A. Inspect the ignition bus relay(s) pins.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ignition bus relay(s) from the cab harness.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

• Corroded pins • Bent or broken pins • Pushed back or expanded pins • Wire insulation damage • Moisture in or on the connector • Missing or damaged connector seals • Connector shell broken • Dirt or debris in or on the connector pins. For general inspection techniques, refer to Component Connector and Pin Inspection, Procedure 019-361 (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html).	No damaged pins	2B
	Replace the relay(s). • Flush the dirt, debris, or moisture from the relay pins using electrical contact cleaner, Part Number 3824510. • Install the appropriate connector seal if it is damaged or missing. • Replace the ignition bus relay(s). Refer to Procedure 019-301 (/qs3/pubsys2/xml/en/procedures/97/97-019-301.html).	4A

STEP 2B. Check the ignition bus relay coil resistance.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ignition bus relay(s) from the cab harness.

Action	Specification/Repair	Next Step

Measure the resistance from pin 85 to pin 86 of the relay(s). Refer to the wiring diagram or the circuit description at the beginning of this fault code for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	70 to 100 ohms	3A
	Replace the relay(s). Refer to Procedure 019-301 (/qs3/pubsys2/xml/en/procedures/97/97-019-301.html).	4A

STEP 3. Check the ICON™ harnesses.

STEP 3A. Inspect the ICON™ engine harness, cab harness, and ICON™ idle control module connector pins.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ICON™ idle control module B connector from the ICON™ idle control module.
- Disconnect the 14-pin pass-through connector at the vehicle firewall.
- Disconnect the ignition bus relay(s) from the cab harness.

Action	Specification/Repair	Next Step

- Corroded pins
- Bent or broken pins
- Pushed back or expanded pins
- Wire insulation damage
- Moisture in or on the connector
- Missing or damaged connector seals
- Connector shell broken
- Dirt or debris in or on the connector pins.

No damaged pins

3B

For general inspection techniques, refer to Component Connector and Pin Inspection, Procedure 019-361 (</qs3/pubsys2/xml/en/procedures/99/99-019-361.html>).

Repair the damaged pins

4A

- Flush the dirt, debris, or moisture from the connector pins using electrical contact cleaner, Part Number 3824510.
- Install the appropriate connector seal if it is damaged or missing.
- Repair the ICON™ engine harness. Refer to Procedure 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html).
- Replace the ICON™ engine harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/97/97-019-043.html).
- Repair the cab harness. Refer to Procedure 019-205 (/qs3/pubsys2/xml/en/procedures/99/99-019-205.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html).
- Replace the cab harness. Refer to Procedure 019-305 (/qs3/pubsys2/xml/en/procedures/97/97-019-305.html).
- Replace the ICON™ idle control module. Refer

to Procedure 019-358 (/qs3/pubsys2/xml/en/procedures/97/97-019-358.html).

- Repair or replace the OEM wiring harness as necessary.

STEP 3B. Check the complete harness for a short circuit from pin to pin.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ICON™ idle control module A and B connectors from the ICON™ idle control module.
- Disconnect the ignition bus relay(s) from the cab harness.

Action	Specification/Repair	Next Step
• Measure the resistance from pin 4 in the ICON™ idle control module B harness connector to all other pins in the A and B harness connectors. Refer to the wiring diagram or the circuit description at the beginning of this fault code for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	More than 100k ohms	3C
		3B-1

STEP 3B-1. Identify whether the ICON™ system is an Aftermarket.

Conditions :

None

Action	Specification/Repair	Next Step
Refer to Procedure 209-017 (/qs3/pubsys2/xml/en/procedures/97/97-209-017.html).	ICON™ system is Aftermarket	3B-2
	Check the OEM wiring harness pin to pin for a short in the ignition bus relay circuit.	4A

STEP 3B-2. Check the cab harness for a short circuit from pin to pin.**Conditions :**

- Turn keyswitch OFF.
- Disconnect the 14-pin pass-through connector.
- Disconnect the ignition bus relay(s) from the cab harness.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

• Measure the resistance from pin F of the 14-pin cab harness, cab harness side, to all other pins in the connector. Refer to the wiring diagram or the circuit description at the beginning of this fault code for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	More than 100k ohms Repair or replace the ICON™ engine harness • Repair the ICON™ engine harness. Refer to Procedure 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). • Replace the ICON™ engine harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/97/97-019-043.html).	4A
	Repair or replace the ICON™ cab harness • Repair the cab harness. Refer to Procedure 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). • Replace the cab harness. Refer to Procedure 019-305 (/qs3/pubsys2/xml/en/procedures/97/97-019-305.html).	4A

STEP 3C. Check the complete harness for a short circuit to ground.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ICON™ idle control module B connector from the ICON™ idle control module.
- Disconnect the ignition bus relay(s) from the cab harness.

Action	Specification/Repair	Next Step
Measure the resistance from pin 4 of the ICON™ idle control module B harness connector to engine block ground. Refer to the wiring diagram or the circuit description at the beginning of this fault code for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	More than 100k ohms Replace the ICON™ idle control module. Refer to Procedure 019-358 (/qs3/pubsys2/xml/en/procedures/97/97-019-358.html).	Repair Complete
		3C-1

STEP 3C-1. Identify whether the ICON™ system is an Aftermarket.

Conditions : None		
Action	Specification/Repair	Next Step
Refer to Procedure 209-017 (/qs3/pubsys2/xml/en/procedures/97/97-209-017.html).	ICON™ system is Aftermarket	3C-2
	Check the OEM wiring harness pin to pin for a short to ground in the ignition bus relay circuit.	4A

STEP 3C-2. Check the cab harness for a short circuit to ground.

Conditions : - Turn keyswitch OFF. - Disconnect the 14-pin pass-through connector. - Disconnect the ignition bus relay(s) from the cab harness.		
Action	Specification/Repair	Next Step

• Measure the resistance from pin F of the 14-pin cab harness connector, cab harness side, to engine block ground. Refer to the wiring diagram or the circuit description at the beginning of this fault code for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	More than 100k ohms Repair or replace the ICON™ engine harness • Repair the ICON™ engine harness. Refer to Procedure 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). • Replace the ICON™ engine harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/97/97-019-043.html).	4A
	Repair or replace the ICON™ cab harness • Repair the cab harness. Refer to Procedure 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). • Replace the cab harness. Refer to Procedure 019-305 (/qs3/pubsys2/xml/en/procedures/97/97-019-305.html).	4A

STEP 4. Clear the fault code.

STEP 4A. Disable the fault code.

Conditions :

- Connect all components.
- Turn keyswitch ON.

Action	Specification/Repair	Next Step
• Cycle the keyswitch to verify the fault code is inactive.	Fault Code 339 cleared	Repair complete
	Troubleshoot any remaining active fault codes.	Appropriate troubleshooting charts

Last Modified: 04-Oct-2004
