


Fault Code: 584 (Aftermarket and OEM)

Starter Relay Circuit - Voltage Above Normal or Shorted to High Source

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 584 PID(P): SPN: FMI: Lamp: SRT:	Starter Relay Circuit - Voltage Above Normal or Shorted to High Source. High voltage detected at the starter relay circuit when low voltage was expected by the ICON™ idle control module.	The ICON™ system will be disabled. Only mandatory shutdown will be enabled. Engine can possibly not be started normally.



Circuit Description

The starter relay connects power to the starter magnetic switch for starting the engine. The above circuit diagram can vary, such as connector or pins, depending on the vehicle make or model. OEM installations can possibly provide the harnessing between the idle control module and other ICON™ devices.

Component Location

The starter relay is typically mounted on the vehicle's bulkhead on the intake side of the engine.

The ICON™ module can be located in a different location depending on the vehicle application.

Shoptalk

This fault typically indicates a short circuit to battery voltage. If there is a short circuit to battery, the engine can **not** be started.

The ICON™ system can display **only** the present active fault code. If more than one fault code is active at the same time, the ICON™ system flashes out the highest priority fault. After the fault has been corrected then the next active fault will be flashed out.

Note: The ICON™ electronic service tool can display more than one active and or inactive fault codes at the same time.

Warnings and Cautions

CAUTION

To reduce the possibility of pin and harness damage, use the following test leads when taking a measurement:

Part Number 3822758 - male Deutsch/AMP/Metri-Pack test lead

Part Number 3822917 - female Deutsch/AMP/Metri-Pack test lead.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Read the fault codes.	
	STEP 1A. Use the fault flashout feature or the ICON™ electronic service tool to read the fault codes.	Fault Code 584 inactive
STEP 2.	Starter Test	
	STEP 2A. Run starter test.	Starter operates properly
STEP 3.	Check the starter relay.	
	STEP 3A. Inspect the starter relay connector pins.	No damaged pins

STEPS		SPECIFICATIONS
	STEP 3B. Check the starter relay coil resistance.	30 to 99 ohms
	STEP 3C. Check for a short circuit.	More than 100k ohms
STEP 4.	Check the ICON™ harnesses.	
	STEP 4A. Inspect the ICON™ engine harness, cab harness, and ICON™ idle control module connector pins.	No damaged pins
	STEP 4B. Check for a short circuit from pin to pin.	More than 100k ohms
	STEP 4C. Check for a short circuit to the battery.	Less than 0.5 VDC
STEP 5.	Clear the fault code.	
	STEP 5A. Disable the fault code.	Fault Code 584 cleared

STEP 1. Read the fault codes.

STEP 1A. Use the fault flashout feature or the ICON™ electronic service tool read the fault codes.

Conditions :

- Connect all components.
- Turn keyswitch ON.
- Connect the ICON™ electronic service tool.

Action	Specification/Repair	Next Step
Use the fault flashout feature or the ICON™ electronic service tool read the fault codes.	Fault Code 584 inactive.	2A
		3A

STEP 2. Starter Test

STEP 2A. Run starter test.

Conditions :

- Turn keyswitch ON.
- Connect the ICON™ electronic service tool.

Action	Specification/Repair	Next Step
Run the starter test.	Starter operates properly Refer to Inactive or Intermittent Fault Codes, Procedure 019-362 (/qs3/pubsys2/xml/en/procedures/99/99-019-362.html).	5A
		3A

STEP 3. Check the starter relay.

STEP 3A. Inspect the starter relay connector pins.

Conditions :

- Turn keyswitch OFF.
- Disconnect the starter relay from the ICON™ engine harness.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Inspect the starter relay for the following: • Loose connector • Corroded pins • Bent or broken pins • Pushed back or expanded pins • Moisture in or on the connector • Missing or damaged connector seals • Dirt or debris on or in the connector pins • Connector shell broken • Wire insulation damage • Damaged connector locking tab. For general inspection techniques, refer to Component Connector and Pin Inspection, Procedure 019-361 (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html).	No damaged pins	3B
	Replace the relay • Flush the dirt, debris, or moisture from the relay connector pins using electrical contact cleaner, Part Number 3824510. • Install the appropriate connector seal if it is damaged or missing. • Replace the starter relay. Refer to Procedure 019-302 (/qs3/pubsys2/xml/en/procedures/97/97-019-302.html).	5A

STEP 3B. Check the starter relay coil resistance.

Conditions :

- Turn keyswitch OFF.
- Disconnect the starter relay from the ICON™ engine harness.

Action	Specification/Repair	Next Step

Check the starter relay coil resistance. Measure the resistance from pin 85 of the starter relay to pin 86 of the relay. Refer to the wiring diagram or the circuit diagram for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	30 to 99 ohms	3C
	Replace the relay. Refer to Procedure 019-302 (/qs3/pubsys2/xml/en/procedures/97/97-019-302.html).	5A

STEP 3C. Check for a short circuit.

Conditions :

- Turn keyswitch OFF.
- Disconnect the starter relay from the ICON™ engine harness.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for a shorted contact. • Measure the resistance from pin 87 of the starter relay to all other pins except pin 87A. NOTE: This is a normally open relay. Refer to the wiring diagram or the circuit diagram for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	More than 100k ohms	4A
	Replace the relay. Refer to Procedure 019-302 (/qs3/pubsys2/xml/en/procedures/97/97-019-302.html).	5A

STEP 4. Check the ICON™ harnesses.

STEP 4A. Inspect the ICON™ engine harness and ICON™ idle control module connector pins.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ICON™ idle control module B connector from the ICON™ idle control module.
- Disconnect the starter relay.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Inspect the ICON™ engine harness, cab harness, and ICON™ idle control module connector pins for the following: • Loose connector • Corroded pins • Bent or broken pins • Pushed back or expanded pins • Moisture in or on the connector • Missing or damaged connector seals • Dirt or debris on or in the connector pins • Connector shell broken • Wire insulation damage • Damaged connector locking tab. For general inspection techniques, refer to Component Connector and Pin Inspection, Procedure 019-361 (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html).	No damaged pins	4B
	Repair the damaged pins. • Flush the dirt, debris, or moisture from the connector pins using electrical contact cleaner, Part Number 3824510. • Install the appropriate connector seal if it is damaged or missing. • Repair the ICON™ engine harness. Refer to Procedure 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). • Replace the ICON™ engine harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/97/97-019-043.html).	5A

STEP 4B. Check for a short circuit from pin to pin.

Conditions :

- Turn keyswitch OFF.
- Disconnect the ICON™ idle control module A and B connectors from the ICON™ idle control module.
- Disconnect the engine OEM ECM connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for a short circuit from pin to pin. Measure the resistance from pin 6 in the Aftermarket or OEM ICON™ B harness connector to all other pins in the ICON™ A and B harness connectors, except pin 5 in ICON™ B harness connector. Refer to the wiring diagram or the circuit diagram for connector pin identification. For general resistance measurement techniques, refer to the Resistance Measurements Using a Multimeter and Wiring Diagram, Procedure 019-360 (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html).	More than 100k ohms	4C
	- Repair the ICON™ engine harness. Refer to Procedure 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). - Replace the ICON™ engine harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/99/99-019-043.html). - Repair the cab harness. Refer to 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). - Replace the cab harness. Refer to Procedure 019-305 (/qs3/pubsys2/xml/en/procedures/97/97-019-305.html). - Repair or replace the OEM wiring harness as necessary.	5A

STEP 4C. Check for a short circuit to the battery.

Conditions :

- Disconnect the ICON™ idle control module B connector from the ICON™ idle control module.
- Turn keyswitch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for a short circuit to the battery. Measure the voltage from pin 6 of the Aftermarket or OEM ICON™ B harness connector to engine block ground.	Less than 0.5 VDC Replace the ICON™ idle control module. Refer to Procedure 019-358 (/qs3/pubsys2/xml/en/procedures/97/97-019-358.html).	Repair complete
	- Repair the ICON™ engine harness. Refer to Procedure 019-206 (/qs3/pubsys2/xml/en/procedures/99/99-019-206.html) or 019-207 (/qs3/pubsys2/xml/en/procedures/99/99-019-207.html). - Replace the ICON™ engine harness. Refer to Procedure 019-043 (/qs3/pubsys2/xml/en/procedures/99/99-019-043.html). - Repair or replace the OEM wiring harness as necessary.	5A

STEP 5. Clear the fault code.

STEP 5A. Disable the fault code.

Conditions :

- Connect all components.
- Turn keyswitch ON.

Action	Specification/Repair	Next Step

Clear the inactive fault code. • Cycle the keyswitch to verify the fault code is inactive.	Fault Code 584 cleared	Repair complete
	Troubleshoot any remaining active fault codes.	Appropriate troubleshooting charts