

FAULT CODE 1543 - Auxiliary Pressure Sensor Input 1 Circuit - Voltage Below Normal or Shorted to Low Source

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check for fault codes.	
	STEP 1A. Check for sensor supply fault codes.	Fault Code 352 active?
STEP 2.	Check the original equipment manufacturer (OEM) pressure sensor and circuit.	
	STEP 2A. Inspect the OEM pressure sensor and connector pins.	Dirty or damaged pins?
	STEP 2B. Check the sensor supply voltage and return circuit.	4.75-VDC to 5.25-VDC?
	STEP 2C. Check the circuit response.	Fault Code 1542 active and Fault Code 1543 inactive?
	STEP 2D. Check the fault codes and verify sensor condition.	Fault Code 1543 active?
STEP 3.	Check the engine control module (ECM) and OEM harness.	
	STEP 3A. Inspect ECM and OEM harness connector pins.	Dirty or damaged pins?
	STEP 3B. Check for an open circuit in the OEM harness.	Less than 10 ohms?
	STEP 3C. Check for an open circuit in the OEM harness.	Less than 10 ohms?
	STEP 3D. Check for a pin-to-pin short circuit in the OEM harness.	Greater than 100K ohms?

STEPS		SPECIFICATIONS
	STEP 3E. Check for a pin-to-ground short circuit.	Greater than 100K ohms?
	STEP 3F. Check for an inactive fault code.	Fault Code 1543 inactive?
STEP 4.	Clear the fault code.	
	STEP 4A. Disable the fault code.	Fault Code 1543 inactive?
	STEP 4B. Clear the fault codes.	All fault codes cleared?

STEP 1. Check for fault codes.

STEP 1A. Check for sensor supply fault codes.

Conditions :

- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Check for sensor supply fault codes. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 352 active? YES	Fault Code 352 troubleshooting tree
	Fault Code 352 active? NO	2A

STEP 2. Check the OEM pressure sensor and circuit.

STEP 2A. Inspect the OEM pressure sensor and connector pins.

Conditions :

- Turn keyswitch OFF.
- Disconnect the OEM pressure sensor from the OEM harness.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Inspect the OEM harness and OEM pressure sensor connector pins for the following: • Loose connector • Corroded pins • Bent or broken pins • Pushed back or expanded pins • Moisture in or on the connector • Missing or damaged connector seals • Dirt or debris in or on the connector pins • Connector shell broken • Wire insulation damage • Damaged connector locking tab. Use the following procedure for general inspection techniques. Refer to Procedure 019-361 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html)	Dirty or damaged pins? YES Repair : A damaged connection has been detected in the sensor or harness connector. Clean the connector and pins. Repair the damaged harness, connector, or pins, if possible. Refer to Procedure 019-071 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-071.html)	4A
	Dirty or damaged pins? NO	2B

STEP 2B. Check the sensor supply voltage and return circuit.

Conditions :

- Turn keyswitch OFF
- Disconnect the OEM pressure sensor from the OEM harness
- Turn keyswitch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the supply voltage and return circuit. Measure the voltage between the OEM pressure +5 volt SUPPLY pin and the OEM pressure RETURN pin at the sensor connector of the OEM harness. Refer to the circuit diagram or the wiring diagram for connector pin identification.	4.75-VDC to 5.25-VDC? YES	2C
	4.75-VDC to 5.25-VDC? NO	3A

STEP 2C. Check the circuit response.

Conditions :

- Turn keyswitch OFF.
- Disconnect the OEM pressure sensor from the OEM harness.
- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Check for the appropriate circuit response after 30 seconds. - Place a jumper wire between the OEM pressure SUPPLY pin and the OEM pressure SIGNAL pin at the OEM pressure sensor connector of the OEM harness. - Use INSITE™ electronic service tool to read the fault codes.	Fault Code 1542 active and Fault Code 1543 inactive? YES	2D
	Fault Code 1542 active and Fault Code 1543 inactive? NO	3A

STEP 2D. Check the fault codes and verify sensor condition.

Conditions :

- Turn keyswitch OFF.
- Connect the OEM pressure sensor to the OEM harness.
- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Check for the appropriate circuit response after 30 seconds. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 1543 active? YES Repair : A damaged sensor has been detected. Replace the OEM pressure sensor. Refer to the OEM service manual.	4A
	Fault Code 1543 active? NO Repair : None. The removal and installation of the connector corrected the fault.	4A

STEP 3. Check the ECM and OEM harness.

STEP 3A. Inspect ECM and OEM harness connector pins.

Conditions :

- Turn keyswitch OFF
- Disconnect the OEM harness from the ECM connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Inspect the OEM harness and ECM connector pins for the following: • Loose connector • Corroded pins • Bent or broken pins • Pushed back or expanded pins • Moisture in or on the connector • Missing or damaged connector seals • Dirt or debris in or on the connector pins • Connector shell broken • Wire insulation damage • Damaged connector locking tab. Use the following procedure for general inspection techniques. Refer to Procedure 019-361 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-361.html)	Dirty or damaged pins? YES Repair : A damaged connection has been detected in the ECM connector or OEM harness connector. Clean the connector and pins. Repair the damaged harness, connector, or pins, if possible. Refer to Procedure 019-071 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-071.html)	4A
	Dirty or damaged pins? NO	3B

STEP 3B. Check for an open circuit in the OEM harness.

Conditions : • Turn keyswitch OFF. • Disconnect the OEM harness from the ECM connector. • Disconnect the OEM pressure sensor from the OEM harness.		
Action	Specification/Repair	Next Step

Check for an open circuit. Measure the resistance between the OEM harness ECM connector OEM pressure RETURN pin and the OEM harness OEM pressure sensor connector RETURN pin. Refer to the circuit diagram or the wiring diagram for connector pin identification. Use the following procedure for general resistance measurement techniques. Refer to Procedure 019-360 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html)	Less than 10 ohms? YES	3C
	Less than 10 ohms? NO Repair : An open RETURN circuit has been detected in the OEM harness. Troubleshoot each harness connected in series to determine which contains the open return circuit. Repair the OEM harness. Refer to Procedure 019-071 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-071.html)	4A

STEP 3C. Check for an open circuit in the OEM harness.

Conditions : - Turn keyswitch OFF. - Disconnect the OEM harness from the ECM connector. - Disconnect the OEM pressure sensor from the OEM harness.		
Action	Specification/Repair	Next Step

Check for an open circuit. Measure the resistance between the OEM harness ECM connector OEM pressure SIGNAL pin and the OEM harness OEM pressure sensor connector SIGNAL pin. Refer to the circuit diagram or the wiring diagram for connector pin identification. Use the following procedure for general resistance measurement techniques. Refer to Procedure 019-360 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html)	Less than 10 ohms? YES	3D
	Less than 10 ohms? NO Repair : An open SIGNAL circuit has been detected in the OEM harness. Troubleshoot each harness connected in series to determine which contains the open signal circuit. Repair the OEM harness. Refer to Procedure 019-071 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-071.html)	4A

STEP 3D. Check for a pin-to-pin short circuit in the OEM harness.

Conditions : - Turn keyswitch OFF. - Disconnect the OEM harness from the ECM connector. - Disconnect the OEM pressure sensor from the OEM harness.		
Action	Specification/Repair	Next Step

Check for a pin-to-pin short. Measure the resistance between the OEM pressure SIGNAL pin in the OEM harness ECM connector and all other pins in the OEM connector. Refer to the circuit diagram or the wiring diagram for connector pin identification. Use the following procedure for general resistance measurement techniques. Refer to Procedure 019-360 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html)	Grater than 100K ohms? YES	3E
	Grater than 100K ohms? NO Repair : A pin-to-pin short circuit on the SIGNAL wire has been detected in the OEM harness. Troubleshoot each harness connected in series to determine which contains the pin-to-pin shorted signal circuit. Repair the OEM harness. Refer to Procedure 019-071 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-071.html)	4A

STEP 3E. Check for a pin-to-ground short circuit.

Conditions :

- Turn keyswitch OFF.
- Disconnect the OEM harness from the ECM connector.
- Disconnect the OEM pressure sensor from the OEM harness.

Action	Specification/Repair	Next Step

Check for a pin-to-ground short. • Measure the resistance between the OEM pressure SIGNAL pin in the OEM harness ECM connector and ground. Refer to the circuit diagram or the wiring diagram for connector pin identification. Use the following procedure for general resistance measurement techniques. Refer to Procedure 019-360 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-360.html)	Greater than 100K ohms? YES	3F
	Greater than 100K ohms? NO Repair : A pin-to-ground short circuit on the SIGNAL wire has been detected in the OEM harness. Troubleshoot each harness connected in series to determine which contains the shorted signal circuit to ground. Repair the OEM harness. Refer to Procedure 019-071 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-071.html)	4A

STEP 3F. Check for an inactive fault code.

Conditions :

- Connect all components
- Turn keyswitch ON
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for the appropriate circuit response after 30 seconds. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 1543 inactive? YES Repair : None. The removal and installation of the connector corrected the fault.	4A
	Fault Code 1543 inactive? NO Repair : Replace the ECM. Refer to Procedure 019-031 in Section 19. (/qs3/pubsys2/xml/en/procedures/105/105-019-031.html)	4A

STEP 4. Check for fault codes.

STEP 4A. Disable the fault code.

Conditions :

- Connect all components
- Turn keyswitch ON
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step

Disable the fault code. - Start the engine and let it idle for 1 minute. - Use INSITE™ electronic service tool to read the fault codes.	Fault Code 1543 inactive? YES	4B
	Fault Code 1543 inactive? NO Repair : Return to the troubleshooting steps or contact a Cummins® Authorized Repair Location if all steps have been completed and checked again.	1A

STEP 4B. Clear the fault codes.

Conditions :

- Connect all components
- Turn keyswitch ON
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Clear the inactive fault codes. Use INSITE™ electronic service tool to clear the fault codes.	All fault codes cleared? YES	Repair complete
	All fault codes cleared? NO Repair : Troubleshoot any remaining active fault codes.	Appropriate troubleshooting steps