

FAULT CODE 418 – Water In Fuel Indicator

- Data Valid But Above Normal Operating Range - Least Severe Level

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes	
	STEP 1A. Check for Fault Code 418.	Active or inactive counts of Fault Code 418?
STEP 2.	Check engine control module (ECM) calibration and clear fault codes.	
	STEP 2A. Check if an ECM calibration update is available.	If a calibration update for this fault code is available, does the ECM contain that revision or higher?
	STEP 2B. Disable the fault code.	Fault code inactive?

STEP 1. Check the fault codes

STEP 1A. Check for Fault Code 418.

Conditions :

- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for fault codes. • Use INSITE™ electronic service tool to read the fault codes.	Active or inactive counts of Fault Code 418? YES Repair : Drain the water from the fuel filter.	2A
	Active or inactive counts of Fault Code 418? NO	Repair complete

STEP 2. Check ECM calibration and clear fault codes.

STEP 2A. Check if an ECM calibration update is available.

Conditions :

- Connect all components.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Compare the ECM code and revision number in the ECM to the calibration revisions listed in the ECM Calibration Revision History for applicable changes related to this fault code. • Use INSITE™ electronic service tool to find the present ECM code and revision number in the ECM. The ECM code and revision number are found in the Calibration Information section of System ID and Dataplate in Features and Parameters	If a calibration update for this fault code is available, does the ECM contain that revision or higher? YES	2B
	If a calibration update for this fault code is available, does the ECM contain that revision or higher? NO Repair : If necessary, calibrate the ECM. Refer to Procedure 019-032 in Section 19 (/qs3/pubsys2/xml/en/procedures/105/105-019-032.html).	2B

STEP 2B. Disable the fault code.

Conditions :

- Connect all components.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Disable and clear the fault code. • Operate the engine within the "Conditions for Clearing the Fault Code" found in the Overview section of this troubleshooting procedure.	Fault code inactive? YES	Repair Complete
	Fault code inactive? NO Repair : Return to the troubleshooting steps or contact a Cummins® Authorized Repair Location, if all the steps have been completed and checked again.	1A