

Trainings ▾

Inspect

Measure the clearance between the outer fan hub member and inner fan hub member (retainer). If the clearance is less than 2.54 mm [0.100 in], it indicates the hub has moved on the retainer.

If less than 2.54 mm [0.100 in], refer to a Cummins Authorized Repair Location for repair instructions.

