

Trainings ▾

Remove

Remove the three capscrews.

Remove the camshaft cover.

Remove and discard the gasket.

