

Trainings ▾

Install

⚠ WARNING ⚠

This component or assembly weighs greater than 23 kg [50 lb]. To prevent serious personal injury, be sure to have assistance or use appropriate lifting equipment to lift this component or assembly.

⚠ CAUTION ⚠

Use a lifting strap that will not damage the crankshaft. Do not drop the crankshaft on the bearings.

Use a lint free cloth to clean the crankshaft bearing journals.

The end of the crankshaft with the smallest diameter **must** point toward the front of the block. Install the crankshaft.

