

Trainings ▾

General Information

To measure the cylinder liner protrusion, the cylinder head **must** be removed. If the cylinder head is **not** removed, Refer to Procedure 002-004 (</qs3/pubsys2/xml/en/procedures/20/20-002-004-tr.html>) for instructions on removing the cylinder head.

Refer to Procedure 001-028 (</qs3/pubsys2/xml/en/procedures/20/20-001-028-tr.html>) for instructions on installing the cylinder liner.

Refer to Procedure 001-028 (</qs3/pubsys2/xml/en/procedures/20/20-001-028-tr.html>) for instructions on measuring cylinder liner protrusion.

