

Trainings ▾

Remove with Mechanically Actuated Injector

Remove the 12 capscrews.

Remove the **front** fuel manifold.

Discard the o-rings.

Repeat this process for the removal of the **rear** fuel manifold.

