

Trainings ▾

Install

Remove the plastic shipping plugs from the new oil cooler elements.

Install the gaskets, oil cooler elements, and capscrews.

Tighten the capscrews.

Torque Value: 45 n•m [33 ft-lb]

