

Trainings ▾

Remove

Note : There is little clearance between the capscrews and the block on some engines. If necessary, use a drift and a mallet to tap the loosened capscrews from the oil cooler housing.

Remove the eight capscrews and the two oil cooler elements.

Remove and discard the gaskets.

