

Trainings ▾

Install

Install the gasket, filter head and six capscrews.

Tighten the capscrews.

Torque Value: 45 n•m [33 ft-lb]

