

Trainings ▾

Remove

Remove the 18 capscrews.

Remove the lubricating oil pan adapter cover plate.

Remove and discard the gasket.

