

Trainings ▾

Remove

Remove the three capscrews from the oil pump mounting flange.

Use a pry bar and gently pry the oil pump out of the engine block.

Remove and discard the two o-rings and the seal ring from the lubricating oil pump.

