

Trainings ▾

Remove

Remove the capscrews and oil cooler housing.

Remove and discard the gaskets.

