

Trainings ▾

Maintenance Check

Inspect the sea water pump for evidence of water or oil indicating seal leakage.

Inspect the inlet and outlet connections for leakage.

Inspect the housing's mating area for leakage.

Inspect the pump to block mating area for oil leakage.

