

Trainings ▾

Inspect

Start engine, and inspect all hoses and connections for deterioration or leaks. Replace any damaged hoses and clamps, if necessary. Refer to the OEM troubleshooting and repair manual.

