

## Trainings ▾

### Remove

Remove the water pump drive assembly.

Remove and discard the gasket.

**Note :** If necessary, tap on the end of the shaft with a mallet.

