

Trainings ▾

General Information

Torque Valve			
Component	Wrench Size	N•m	ft-lb
Air Compressor Mounting Capscrews (Single Cylinder)	9/16	45	35
Air Compressor Mounting Capscrews (Two Cylinder)	3/8	60	45
Air Compressor Support Bracket (Single Cylinder):			
• Mounting Capscrews to Air Compressor	9/16	45	35
• Mounting Capscrews to Engine Block	9/16	45	35
Air Compressor Support Bracket (Two Cylinder):			
• Mounting Capscrews to Air Compressor	9/16	45	35
• Mounting Capscrews to Engine Block	9/16	60	45
Air Compressor Unloader Valve Capscrews	1/2	15	120 in-lb
Cooling Fan Mounting Capscrews	3/4	135	100
Cooling System Hose Clamps	5/16	5.6	50 in-lb

Torque Valve			
Component	Wrench Size	N•m	ft-lb
Fan Hub, Belt-Driven Mounting Nuts	9/16	45	35
Fuel Pump Mounting Capscrews:			
• Without Air Compressor with Mechanical Injectors	9/16	45	35
• With Air Compressor with Mechanical Injectors	3/8	45	35
• Fuel Pump Mounting Capscrews for electronic Injectors	M15	112.5	83
• Fuel Pump Mounting Nuts Without Air Compressor	11/16	45	35
Vibration Damper Mounting Pulley to Crankshaft Capscrews	3/4	445	330
Vibration Damper Mounting Damper to Pulley Capscrews	1/2	140	105