

Trainings ▾

Remove

Remove the six capscrews which hold the ECM to the control valve body.

Remove the ECM from the control valve body.

