

## Trainings ▾

### Remove

Disconnect the engine speed sensor (ESS) connectors from the engine harness.

Loosen the locknut.

Remove the ESS from the cylinder block.

