

Trainings ▾

Install

Make sure the new sensor has an o-ring around the surface where it seals against the engine block.

Install the sensor in the engine block.

Torque Value: 14 n•m [10 ft-lb]

Push the connectors together until they lock.

