

Trainings ▾

Remove

Lift up the tab and disconnect the connector from the sensor.

Remove the sensor from the engine block. Use a deep flank drive socket, Part No. 3823843.

