

Trainings ▾

Maintenance Check

Note : Engine mounts that act as isolators are **not** supplied by Cummins Inc. Refer to the OEM service manual.

Check the torque on the nuts and bolts. Tighten any that are loose. Inspect the rubber for deterioration and age hardening. Replace any broken or lost bolts, capscrews, or damaged rubber.

Capscrew size and grade vary with the flywheel housing and mounting arrangement. Determine the size and grade of the mounting bolts. Refer to Procedure 018-006 (</qs3/pubsys2/xml/en/procedures/28/28-018-006-om.html>) (Engine Component Torque Values) in Section V for capscrew torque specification.

