

Trainings ▾

General Information

Component	Wrench size (mm)	Wrench Size (inch)	Torque Value (N•m)	Torque Value [ft-lb]
Oil pan drain plug		1-1/4	102	75
Turbocharger mounting nuts		9/16	40	30
Fuel pump mounting capscrews (Mechanical Actuated Injector only)		5/8	48	35
Rocker cover capscrews		9/16	40	30
Injector hold-down capscrew (Electronically Actuated Injector)	13 mm		30 N•m plus 60 degrees	22 plus 30 degrees
Injector hold-down capscrews (Mechanical Actuated Injector only)		1/2	16	142 [in-lb]
Rocker lever shaft capscrews		3/4	90	65
Rocker adjust screw locknut (with adapter)		3/4	47	35
Rocker adjust screw locknut (without adapter)		3/4	60	45

Component	Wrench size (mm)	Wrench Size (inch)	Torque Value (N•m)	Torque Value [ft-lb]
Injector adjust screw locknut (with adapter) (Mechanical Actuated Injector only)		3/4	47	35
Injector adjust screw locknut (without adapter) (Mechanical Actuated Injector only)		3/4	60	45
Fuel shutoff valve solenoid nut (Mechanical Actuated Injector only)		3/8	2	18 [in-lb]
Fuel Pump Mounting Capscrews (Electronically Actuated Injector)	15 mm		112	83
Zinc anode (marine only)		7/8	44	33
Eliminator vent plug		1-1/8	20	177 [in-lb]
Eliminator drain plug		3/4	20	177 [in-lb]
Eliminator cover capscrews		9/16	25	221 [in-lb]
ECM mounting capscrews (Phillips head)		N/A	14	124 [in-lb]

