

Trainings ▾

General Information

Barring Mechanism

The barring mechanism is inside the front cover. The front cover **must** be removed from the engine to service or rebuild the barring mechanism.

The barring mechanism contains a spring-loaded worm gear. The worm gear engages the camshaft gear when the barring shaft is pushed in the front cover and turned in a **counterclockwise** direction. The barring mechanism will **only** turn the engine in the direction of normal rotation. Turn the barring shaft in a **clockwise** direction to disengage the worm gear. If the worm gear remains engaged accidentally during engine start-up, engine rotation will disengage the barring mechanism without damage to it.