

Trainings ▾

Inspect

Engines equipped with a PRELUBricating oil system **must not** be operated when the PRELUBricating oil system is **not** working.

Make sure the PRELUBricating oil system wiring is connected. Start the engine. Refer to Procedure 101-014 in Section 1. (</qs3/pubsys2/xml/en/procedures/56/56-101-014.html>) The starting motor will **not** engage until adequate oil pressure is obtained. If the engine has **not** been in operation for some time there will be a delay before the starting motor is engaged. This delay (up to 30-seconds) is normal.

