

Trainings ▾

Maintenance Check

Inspect the fan drive idler arm assembly for the following:

- Deterioration
- Cracks
- Broken capscrews.

Replace any damaged parts.

