

Trainings ▾

General Information

WARNING

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [120°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

WARNING

Before starting engine from short term storage, verify if breather tubes are blocked or capped. Oil pans can explode under pressure if capped. To reduce the possibility of engine damage or personal injury, always ensure both breather tubes are free of any blockage.

WARNING

Coolant is toxic. Keep away from children and pets. If not reused, dispose of in accordance with local environmental regulations.

WARNING

To reduce the possibility of personal injury, avoid contact of hot oil with your skin.

WARNING

Some state and federal agencies have determined that used engine oil can be carcinogenic and cause reproductive toxicity. Avoid inhalation of vapors, ingestion, and prolonged contact with used engine oil. If not reused, dispose of in accordance with local environmental regulations.

This procedure describes the proper method for the short term storage (one to six months) of an engine.

Operate the engine at high idle until the coolant temperature is 70°C [160°F].

Turn the keyswitch to the OFF position.

Disconnect the fuel lines to the engine fuel filter and the injector return line.

Fill one container with diesel fuel and the second container with preservative oil. Put both fuel lines in the container of diesel fuel.

Start the engine.

After the engine is operating smoothly, transfer the fuel supply line to the container of preservative oil.

Operate the engine until the preservative oil flows out of the injector return line.

Turn the keyswitch to the OFF position.

Connect the fuel lines to the fuel filter and the injector return line.

Drain the oil pan sump, oil filters, and fuel filters.

Install the drain plugs in the oil pan. The pan can remain empty until the engine is ready to be put in a service application.

Disconnect the electrical wiring from the fuel pump solenoid.

Turn the fuel pump manual shutoff valve **counterclockwise** until it stops.

Crank the engine slowly. Spray lubricating oil into the intake manifold and the inlet of the air compressor.

Drain the coolant.

It is **not** necessary to drain the coolant if it is a permanent-type antifreeze with a rust inhibitor.

Install a caution tag on the engine which reads:

- The engine does **not** contain oil. Do **not** operate the engine.

Store the engine in an area that is dry and has a uniform temperature.

Bar the crankshaft two or three revolutions every three to four weeks.

The following instructions are used to prime the lubricating, fuel, and coolant system after short term engine storage:

- Fill the oil pan sump, oil filters, and fuel filters.
- Fill the coolant system, if necessary.

For Generator-Drive and Generator Set engines:

- Disconnect the electrical cable from the fuel pumps.
- Rotate the crankshaft by the starting motor until oil pressure appears on the gauge or the warning light goes off.
- Connect the electrical cable to the fuel pumps.
- Start the engine. Refer to the Starting Procedure After Extended Shutdown or Oil Change in Section 1.

