

Trainings ▾

Maintenance Check

Inspect the turbocharger every 6,000 hours or 2 years.

Remove the air intake and the exhaust piping. Contact a Cummins® Authorized Repair Location for assistance.

Look for damaged or cracked compressor or turbine blades.

The turbocharger shaft **must** spin freely.

There **must** be no contact between the compressor/turbine wheels and the housing when using light finger pressure.

If the inspection indicates a problem, contact a Cummins® Authorized Repair Location for assistance. Use the model number on the turbocharger dataplate as reference.

Note : For engines operating with a high altitude calibration, the turbocharger **must** be replaced at 10,000 hours or engine half life, whichever comes first.

