

Trainings ▾

Maintenance Service

Remove the wing nut (1) that secures the bottom cover (2) to the cleaner housing (3). Remove the cover.

Pull the element (6) down from the center bolt (4).

⚠ CAUTION ⚠

Pull the cover and the element straight out when removing them from the housing to avoid damage to the element.

Remove the gasket (5) from the outlet end (7) of the housing. Inspect the gasket. Replace the gasket if necessary. Assemble the bottom cover to the cleaner housing.

