

Trainings ▾

General Specifications

Component	Wrench Size	Torque Value	
		N•m	[ft-lb]
Oil drain plug	12	60	45
Crosshead adjusting screw locknut with adapter	17	45	35
Crosshead adjusting screw locknut without adapter	17	60	45
Valve adjusting screw locknut with adapter	17	45	35
Valve adjusting screw locknut without adapter	17	60	45
Rocker lever cover	12	7	62 in-lb
Thermostat housing mounting capscrews	17	115	85
Fan belt idler assembly	[5/8]	60	45
Fan belt tensioner capscrews	17	60	45
Air compressor unloader valve body capscrew	[9/16]	14	10
Air compressor unloader valve cap	[9/16]	40	30
Fan idler control rod capscrews	[5/8]	90	65
Fan idler capscrew	17	45	35
Fan idler control rod adjusting screw locknut	[5/16]	60	45

Component	Wrench Size	Torque Value	
Fan idler arm shock absorber	[5/8]	60	45
Adjusting link and alternator mounting capscrews	17	55	40
Fuel supply lines (low-pressure)		27	20
Fuel lines (high-pressure)		24	17
Fuel tube locknut	18	39	29
Fuel line support clamps		10	7
Fuel filter relief valve		11	95 in-lb
Overflow valve/Overflow connection		27	20
Fuel drain line manifold banjo capscrew		9	80 in-lb
Fuel return line spill tube banjo capscrew		9	80 in-lb
Injector clamp capscrew		65	48
Fuel pump bracket mounting capscrews		65	48
Open drive fuel pump coupling capscrews	19	108	80
Flange mounting capscrews		65	48
Two piece fuel pump drive gear capscrews		115	84
Fan hub assembly to fan support (12 pt capscrew)	[5/8]	290	215
Fuel pump locking pin cap		30	22
Venturi combo adapter capscrews		18	159 in-lb
Electric lift pump housing capscrews		67	48

Component	Wrench Size	Torque Value	
Electric lift pump mounting capscrews		67	48
Electric lift pump outlet banjo capscrew	16	40	30

Last Modified: 22-Nov-2002
