

Trainings ▾

Specifications

CAUTION

Engine intake air must be filtered to prevent dirt and debris from entering the engine. If the air intake piping is damaged or loose, unfiltered air will enter the engine and cause premature wear.

Maximum intake restriction with heavy-duty cleaner:

With clean filter element 305 mm H₂O [12 in H₂O] With dirty filter element 635 mm H₂O [25 in H₂O]