

Fault Code: 167

Fuel Rack Position 1 Sensor Circuit - Voltage Below Normal or Shorted to Low Source

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 167 PID(P): S24 SPN: 1210 FMI: 4/4 Lamp: Amber SRT:	Low signal voltage detected on the fuel rack position sensor signal circuit.	Possible reduced engine performance.



Fuel Rack Position Sensor Circuit

Circuit Description

The fuel rack position sensor circuit is supplied with a varying current source from the ECM. The fuel rack position uses this current to change the position of the control rack, which regulates the amount of fuel delivered from the fuel pump. The fuel rack position feedback sensor circuit relays the fuel rack position back to the ECM.

Component Location

The fuel rack position sensor is internal to the fuel pump.

Conditions For Running The Diagnostics

This diagnostic runs continuously when the generator set controller is active or when the engine is running.

Conditions For Setting The Fault Codes

The Engine Control Module (ECM) detected the fuel rack position sensor circuit voltage is out of range low.

Action Taken When The Fault Code Is Active

- The generator set controller displays a warning fault immediately when the diagnostics runs and fails.

Conditions For Clearing The Fault Code

- To validate the repair, start the engine and let it run for 1 minute at no load.
- The generator set controller will turn off the warning indicator immediately after the user presses reset.
- The "Reset All Faults" command in the recommended Cummins® electronic service tool or equivalent can be used to clear active faults.

Shoptalk

Possible causes of this fault code include:

- Malfunctioning or damaged engine wiring harness.
- Damaged or malfunctioning fuel rack position sensor
- Damaged or loose connections.

Refer to Troubleshooting Fault Code 167 . (</qs3/pubsys2/xml/en/procedures/60/60-t05-167.html>)