

Fault Code: 172

Fuel Rack Actuator Driver - Mechanical System Not Responding or Out of Adjustment

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 172 PID(P): S23 SPN: 638 FMI: 7/7 Lamp: Red SRT:	Fuel control rack is in a stuck position.	Engine will shut down.



Fuel Rack Actuator Driver Circuit

Circuit Description

The fuel control rack and solenoid determine the quantity of fuel metered to the engine.

Component Location

The fuel control rack and solenoid are internal parts of the fuel injection pump.

Conditions For Running The Diagnostics

This diagnostic runs continuously when the generator set controller is active.

Conditions For Setting The Fault Codes

The Engine Control Module (ECM) detected the fuel rack is stuck or **not** responding to fueling commands.

Action Taken When The Fault Code Is Active

- The generator set controller displays a shutdown fault immediately when the diagnostics runs and fails.
- The engine will be shut down.

Conditions For Clearing The Fault Code

- To validate the repair, start the engine and let it run for 1 minute at no load.
- The generator set controller will turn off the shutdown indicator immediately after the user presses the reset.
- The "Reset All Faults" command in the recommended Cummins® electronic service tool or equivalent can be used to clear active faults.

Shoptalk

Possible causes of this fault code include:

- Loose or damaged actuator connector.
- Malfunctioning fuel pump.

Refer to Troubleshooting Fault Code 172 . (</qs3/pubsys2/xml/en/procedures/60/60-t05-172.html>)