

Fault Code: 415

Engine Oil Rifle Pressure - Data Valid But Below Normal Operating Range - Most Severe Level

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 415 PID(P): P100 SPN: 100 FMI: 1/1 Lamp: Red SRT:	Oil pressure is below the engine protection critical limit.	Engine will shut down.



Engine Oil Rifle Pressure Sensor Circuit

Circuit Description

The engine oil rifle pressure sensor is a variable resistance sensor used by the ECM to monitor the lubricating oil pressure. The engine oil rifle pressure sensor has three circuits: 5 volt supply, return, and signal circuits. The signal circuit voltage indicates the oil pressure in the oil rifle.

Component Location

The engine oil pressure sensor is located in the oil rifle.

Conditions For Running The Diagnostics

This diagnostic runs continuously when the engine is running.

Conditions For Setting The Fault Codes

The Engine Control Module (ECM) detected the engine oil rifle pressure is below the engine protection limits.

Action Taken When The Fault Code Is Active

- The generator set controller displays a shutdown fault immediately when the diagnostics runs and fails.
- The engine will be shut down.
- The torque output of the engine will be reduced.

Conditions For Clearing The Fault Code

- To validate the repair, bring the engine up to operating temperature and run it in normal loaded conditions for 15 minutes.
- The generator set controller will turn off the shutdown indicator immediately after the user presses the reset.
- The "Reset All Faults" command in the recommended Cummins® electronic service tool or equivalent can be used to clear active faults.

Shoptalk

Possible causes of this fault code include:

- Lubricating oil level is above or below specification.
- Plugged or restricted lubricating oil filter.
- Lubrication oil pressure sensor is malfunctioning.
- Main oil pressure regulator is malfunctioning
- Lubricating oil suction or transfer tube is malfunctioning.
- Internal engine damage.

