



Fault Code: 442-ECM2

Battery 1 Voltage High - Data Valid but Above Normal Operational Range - Moderately Severe Level



Overview

Codes	Reason	Effect
Fault Code: 442 PID(P): SPN: 168 FMI: 1/18 Lamp: Amber SRT:	Battery 1 Voltage High - Data Valid but Above Normal Operational Range - Moderately Severe Level. ECM supply voltage is above the minimum system voltage level.	Engine can stop running or be difficult to start.



Unswitched Battery Supply - QST30 Power Generation Interface Engine

Circuit Description

The ECM receives constant voltage from the batteries through the battery 1 voltage wires that are connected directly to the positive (+) battery post. There is one 10-ampere fuse in the battery 1 voltage wires to protect the harness and ECM. The ECM receives switched battery input through the ignition wire when the ignition is turned on. The battery return wires are connected directly to the negative (-) battery post.

Component Location

The ECMs are located on a support bracket above the flywheel housing at the rear of the engine. ECM1 is the left most mounted ECM. ECM2 is in the middle and ECM3 is the right most mounted ECM. The ECMs are connected to the battery by the OEM harness and engine harness. This direct link provides a constant power supply for the ECMs. The location of the battery will vary with the OEM. Reference the OEM troubleshooting and repair manual for battery location.

Shoptalk

There are multiple ECMs. Each ECM has an individual source address that displays when INSITE™ electronic service tool is connected. When troubleshooting a fault code, use the source address displayed in INSITE™ electronic service tool to determine which ECM and circuit is affected.

This fault code is logged when the ECM battery supply voltage drops below the minimum system voltage level.

- Verify that the ECM unswitched power is coming from the batteries and **not** the starter or other device. Check for possible weak batteries.
- If the ECM battery 1 voltage supply is taken from the starter, check for low voltage during cranking. Low voltage during cranking can cause the ECM power supply to drop below specifications and log Fault Code 441.

Refer to Troubleshooting Fault Code t05-442 (</qs3/pubsys2/xml/en/procedures/60/60-t05-442.html>)